

[Manuals.plus](#) /

› [SANODESK](#) /

› SANODESK L-Shaped Electric Adjustable Height Standing Desk User Manual

## SANODESK 63x48

# SANODESK L-Shaped Electric Adjustable Height Standing Desk User Manual

Model: 63x48 Rustic Brown

### IMPORTANT SAFETY INFORMATION

Always ensure the desk is properly anchored to the floor to prevent tipping. Do not exceed the weight limit of 220 lbs. Use caution when adjusting the height of the desk to prevent injury.

### PRODUCT OVERVIEW

The SANODESK L-Shaped Electric Adjustable Height Standing Desk provides a versatile workspace with electric height adjustment. It features a sturdy frame and a durable desktop, designed for various office or gaming setups.



**Figure 1:** SANODESK L-Shaped Electric Adjustable Height Standing Desk in a gaming environment.



Figure 2: SANODESK L-Shaped Electric Adjustable Height Standing Desk in an office setting.

## PACKAGE CONTENTS

Before beginning assembly, verify all components are present and undamaged. Refer to the included parts list for detailed identification.

- Desk Frame Components (legs, crossbeams, motors)
- Desktop Panels (L-shaped, multi-piece)
- Control Panel and Power Adapter
- Hardware Kit (screws, dowels, tools)
- Cable Management Accessories

## ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to have a second person assist with certain steps, especially when handling larger components. The desk can be assembled with the longer side on either the left or right, depending on your preference.

Your browser does not support the video tag.

**Video 1:** E2L Installation Guide (Left Return). This video demonstrates the complete assembly process for a left-oriented L-shaped desk, including frame and desktop installation. For a right-oriented setup, refer to the E2L Installation Guide (Right Return) video.

## 1. Frame Assembly

Begin by assembling the desk frame components. Ensure all connections are secure.

### 1.1. Install Middle Column Connecting Plate

Attach the middle column connecting plate to the central leg component using the provided screws and hex key. Ensure a snug fit.

### 1.2. Install Desk Feet

Secure the long and short side feet to the bottom of the desk legs. Pay attention to the orientation of each foot as indicated in the assembly video.

### 1.3. Install Crossbeams

Connect the short and long crossbeams between the leg assemblies. Ensure the motor and drive rod connections are correctly aligned and secured.

### 1.4. Install Drive Rods

Loosen the drive rod connections, insert the drive rods into the motor and leg mechanisms, then tighten to secure. This ensures synchronized height adjustment.

### 1.5. Install Support Plate

Attach the support plate to the frame, ensuring it is properly aligned with the pre-drilled holes.

## 2. Desktop Assembly

Assemble the desktop panels before attaching them to the frame.

### 2.1. Insert Dowels and Connect Desktop Panels

Insert the wooden dowels into the designated holes on the desktop panels. Carefully align and connect the panels, then secure them with the provided metal plates and screws.

## 3. Attaching Frame to Desktop

Carefully place the assembled frame onto the underside of the desktop. Align the pilot holes and secure the frame to the desktop using the provided screws.

## 4. Controller and Wiring

Install the control panel and power adapter to the underside of the desk. Connect all necessary wiring according to the instructions. Use the baffle to manage cables neatly.

## 5. Final Orientation

Once fully assembled, carefully turn the desk over to its upright position. Ensure all connections are tight and the desk is stable.

## OPERATING INSTRUCTIONS

This section details how to use your SANODESK L-Shaped Electric Adjustable Height Standing Desk.

Your browser does not support the video tag.

**Video 2:** SANODESK L-Shaped Standing Desk overview. This video demonstrates the desk's smooth height adjustment, stability, and versatile workstation capabilities.

## Height Adjustment

The desk features a quiet and robust electric lift system, allowing seamless transitions between sitting and standing heights (28.3" to 45.9").

- Use the **Up** and **Down** arrow buttons on the control panel to manually adjust the desk height.
- The LED display shows the current height in inches.

## Memory Presets

The intuitive control panel allows you to preset up to four preferred heights for quick adjustments.

1. Adjust the desk to your desired height using the Up/Down arrows.
2. Press the "M" button (or "I" button, depending on model) followed by a number button (1, 2, 3, or 4) to save the current height to that preset.
3. To recall a saved height, simply press the corresponding number button.



Figure 3: Control panel with LED display and memory presets.

## Anti-Collision Feature

The desk is equipped with an anti-collision system. If the desk encounters an obstruction during height adjustment, it will automatically stop

and reverse slightly to prevent damage.



Figure 4: Anti-collision mechanism in action.

## MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your desk.

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Inspections:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.
- **Cable Management:** Ensure all cables are neatly organized and not pinched or tangled to prevent damage to the wiring or motors.

## TROUBLESHOOTING

If you encounter any issues, refer to the following common troubleshooting steps:

| Problem | Possible Cause | Solution |
|---------|----------------|----------|
|---------|----------------|----------|

| Problem                              | Possible Cause                                  | Solution                                                                                                |
|--------------------------------------|-------------------------------------------------|---------------------------------------------------------------------------------------------------------|
| Desk does not move.                  | Power cable disconnected, control panel error.  | Check power connections. Reset the control panel (refer to specific control panel manual if available). |
| Uneven height adjustment.            | Drive rods not properly installed or tightened. | Ensure drive rods are correctly inserted and tightened in both leg mechanisms.                          |
| Anti-collision activates frequently. | Obstruction under or above the desk.            | Clear any objects that may be interfering with the desk's movement path.                                |
| Desk makes unusual noises.           | Loose connections or internal component issue.  | Check all screws and connections. If noise persists, contact customer support.                          |

## SPECIFICATIONS

| Feature                       | Detail                                              |
|-------------------------------|-----------------------------------------------------|
| Brand                         | SANODESK                                            |
| Model                         | 63x48                                               |
| Product Dimensions            | 48"D x 63"W x 28.3"H (Minimum Height)               |
| Adjustable Height Range       | 28.3" to 45.9"                                      |
| Color                         | Rustic Brown                                        |
| Top Material Type             | Engineered Wood (1" Thick Commercial-Grade Desktop) |
| Base Material                 | Steel (Leg)                                         |
| Maximum Weight Recommendation | 220 Pounds                                          |
| Assembly Required             | Yes (Includes All Assembly Tools)                   |
| Certifications                | FSC-Certified wood, BIFMA certifications            |

## WARRANTY AND SUPPORT

Your SANODESK L-Shaped Electric Adjustable Height Standing Desk is backed by a comprehensive warranty and dedicated customer support.

- **Frame Warranty:** 5 years
- **Motor Coverage:** 2 years
- **Customer Service:** 24/7 support available for any inquiries or assistance.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**