

FLEXISPOT B0DV52YNPL

FLEXISPOT L-Shaped Electric Height Adjustable Standing Desk (Model: B0DV52YNPL) User Manual

Comprehensive instructions for assembly, operation, and maintenance.

INTRODUCTION

This manual provides detailed instructions for the FLEXISPOT L-Shaped Electric Height Adjustable Standing Desk, Model B0DV52YNPL. It covers assembly, operation, maintenance, and troubleshooting to ensure safe and efficient use of your new workstation. This desk is designed to offer a versatile and ergonomic workspace with electric height adjustment and a spacious L-shaped desktop.

IMPORTANT SAFETY INFORMATION

Always follow the assembly instructions carefully. Keep fingers and other body parts away from moving parts when adjusting the desk height. Secure the desk to the wall or floor to prevent tipping, especially when using the height adjustment feature. Drill carefully when installing the drawer to avoid injury or damage to the desk.

PACKAGE CONTENTS

Your FLEXISPOT L-Shaped Standing Desk is shipped in two separate packages, which may arrive on different days. Please ensure all components are present before beginning assembly.

- L-Shaped Desktop (Black Top, 63x55 inches)
- 3-Legged Electric Height Adjustable Frame (Black)
- Integrated Drawer (20.6" x 11.0" x 1.6")
- Control Panel with LED Display
- Power Adapter and Cables
- Assembly Hardware (screws, bolts, tools)
- Instruction Manual




Figure 1: The desk components are delivered in two separate packages.

SETUP AND ASSEMBLY

1. **Unpacking:** Carefully unpack all components and verify against the package contents list. Keep all packaging materials until assembly is complete.
2. **Preparation:** Clear a spacious area for assembly. It is recommended to have two people for assembly, especially when handling the heavy desktop and flipping the assembled desk upright.
3. **Frame Assembly:** Follow the detailed instructions provided in the separate assembly guide for the electric frame. Ensure all connections are secure.
4. **Desktop Attachment:** Position the desktop onto the assembled frame. The L-shaped desktop is designed for flexible orientation, allowing the wider section to be placed on either the left or right side to suit your workspace. Note that pre-drilled holes on the desktop are for reference; additional drilling may be required for optimal alignment.
5. **Drawer Installation:** The integrated drawer requires drilling for installation. Exercise caution and follow the specific instructions for drawer mounting to prevent damage or injury.

6. **Cable Management:** Utilize any included cable management tools to organize power cords and other cables for a neat and tidy workspace.
7. **Leveling:** Adjust the desk feet to ensure the desk is stable and level on your floor surface.

FLEXIBLE RIGHT/LEFT ORIENTATION

L-shaped standing desk can be left-sided or right-sided, allowing for even more flexibility



Figure 2: The L-shaped desk offers flexible left or right orientation during assembly.



Figure 3: The fully assembled FLEXISPOT L-Shaped Standing Desk with integrated drawer.

OPERATING INSTRUCTIONS

Control Panel Overview

The desk features an intuitive LED control panel for easy height adjustments and memory settings.



Figure 4: The Smart Control Panel with height display and memory presets.

- **Up/Down Buttons:** Use the arrow buttons to manually adjust the desk height.
- **Memory Presets (1-4):** Save up to four preferred height settings. To save a height, adjust the desk to the desired level, then press and hold one of the numbered memory buttons until the display flashes or beeps.
- **Anti-Collision Feature:** The desk is equipped with an anti-collision system that automatically stops and slightly reverses movement if it encounters an obstruction during height adjustment.

Height Adjustment Range

The desk offers a wide range of height adjustments to accommodate various user preferences and activities, from sitting to standing positions.

LARGE ADJUSTABLE RANGE

Perfect size for your home office



Figure 5: The desk's adjustable height range, from 28.3 inches (minimum) to 45.9 inches (maximum).

ANTI-COLLISION

Rebound immediately




Figure 6: The anti-collision system ensures safety by stopping movement when an obstruction is detected.

MAINTENANCE

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. For stubborn marks, a mild cleaning solution can be used. Avoid abrasive cleaners. The black desktop may show smudges or paw prints easily but is simple to clean.
- **Regular Checks:** Periodically check all screws and bolts to ensure they are tight. Loose connections can affect stability and operation.
- **Motor Care:** The electric motor is designed for durability. Avoid overloading the desk beyond its maximum weight capacity of 220 lbs.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Desk does not move or respond to controls.	Power cable disconnected; motor overload; control panel issue.	Check power connections. Ensure the desk is plugged into a working outlet. Reduce weight on the desk if overloaded. Contact support if the issue persists.
Desk moves unevenly or makes unusual noises.	Loose connections; uneven weight distribution; obstruction.	Verify all assembly screws are tight. Redistribute items on the desktop. Check for any obstructions under the desk.
Desktop sections do not align perfectly.	Minor manufacturing tolerance; reference holes not perfectly aligned.	This can be a minor aesthetic issue due to manufacturing tolerances. If significant, ensure all frame components are correctly seated and tightened. Re-drilling pilot holes for better alignment may be an option, as pre-drilled holes are for reference.
Anti-collision feature triggers frequently.	Obstruction in the desk's path.	Ensure there are no objects (e.g., cabinets, chairs, cables) in the desk's path during height adjustment.

SPECIFICATIONS

Feature	Detail
Brand	FLEXISPOT
Model Number (ASIN)	B0DV52YNPL
Product Dimensions (D x W x H)	55.1"D x 63"W x 45.9"H
Desktop Size	63x55" (L-shaped)
Desktop Thickness	1 Inch
Color	Black Frame + Black Top
Base Material	Alloy Steel
Top Material Type	Wood
Minimum Height	28 Inches
Maximum Height	45.9 Inches
Number of Height Positions	4 (Memory Presets)
Maximum Weight Recommendation	220 Pounds
Drawer Dimensions	20.6" x 11.0" x 1.6"
Required Assembly	Yes
UPC	840460438391

WARRANTY AND SUPPORT

FLEXISPOT provides the following warranty coverage for your L-Shaped Electric Height Adjustable Standing Desk:







- **5-Year Coverage:** Applies to the desk frame and motor.
- **2-Year Coverage:** Applies to the control panel and other electronics.

For customer support, warranty claims, or further assistance, please visit the official FLEXISPOT website or contact their customer service department. You can also refer to the [FlexiSpot Seller Page on Amazon](#) for contact information.



© 2023 FLEXISPOT. All rights reserved.

Related Documents - B0DV52YNPL

	<p>FlexiSpot EG1S/EG1W/EG1B Series Height-Adjustable Desk: Installation Guide & Limited Warranty</p> <p>Comprehensive installation guide and limited warranty details for FlexiSpot EG1S, EG1W, and EG1B series height-adjustable desks, covering setup, specifications, troubleshooting, and warranty coverage.</p>
	<p>FlexiSpot E7CB/E7CW/E7CS Height Adjustable Standing Desk Installation Guide</p> <p>Comprehensive installation guide for FlexiSpot E7CB, E7CW, and E7CS electric height adjustable standing desks. Includes specifications, parts list, step-by-step assembly instructions, operating instructions, troubleshooting, and limited warranty information.</p>
	<p>FlexiSpot E4B/E4W Electric Standing Desk User Manual</p> <p>Comprehensive user manual for the FlexiSpot E4B/E4W electric standing desk, covering specifications, assembly instructions, keypad operation, troubleshooting, and warranty information.</p>
	<p>FlexiSpot M7L-US Computer Riser Installation Guide and Warranty</p> <p>Official installation guide and limited warranty information for the FlexiSpot M7L-US Sit-Stand Desktop Workstation. Learn how to assemble, use, and understand the warranty terms for your FlexiSpot computer riser.</p>
	<p>FlexiSpot EM7L Motorized Computer Riser Installation Guide</p> <p>Comprehensive installation guide for the FlexiSpot EM7L Motorized Computer Riser. Features include specifications, parts list, step-by-step assembly instructions, troubleshooting tips, and limited warranty information.</p>
	<p>FlexiSpot ML2B/ML2W Computer Riser Installation Guide and Warranty</p> <p>Comprehensive installation guide and limited warranty details for the FlexiSpot ML2B/ML2W Computer Riser. This sit-stand desktop workstation guide covers specifications, parts, assembly steps, usage instructions, and warranty coverage from FlexiSpot.</p>

