

manuals.plus /

› [FLEXISPOT](#) /

› [FLEXISPOT L Shaped Standing Desk \(71x63 Inch, 3-Legged\) Instruction Manual](#)

## FLEXISPOT 71x63"Top (3-Legged)

# FLEXISPOT L Shaped Standing Desk (71x63 Inch, 3-Legged) Instruction Manual

Model: 71x63"Top (3-Legged) | Brand: FLEXISPOT

### 1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your new FLEXISPOT L Shaped Standing Desk. Please read this manual thoroughly before assembly and use to ensure proper function and safety. This electric height adjustable desk is designed to provide a versatile and ergonomic workspace for your home or office.




Image 1.1: FLEXISPOT L Shaped Standing Desk in a typical office setup, illustrating its spacious design and the ability to switch its L-shape orientation.

## 2. SAFETY INFORMATION

---

Please observe the following safety guidelines to prevent injury or damage to the product:

- Always ensure the desk is properly assembled and anchored to the floor to prevent tipping.
- Do not exceed the maximum weight capacity of **220 lbs (100 kg)** to maintain stability.
- Follow the assembly instructions carefully to avoid injury.
- Keep children and pets away from the desk during operation.
- Ensure no obstacles are in the desk's path when adjusting height to prevent damage or injury.
- Do not sit or stand on the desk.

## 3. PACKAGE CONTENTS

---

Your FLEXISPOT L Shaped Standing Desk ships in two separate packages, which may arrive on different days. Please verify all components are present before beginning assembly.



Image 3.1: The desk components are shipped in two packages. The desk has a maximum weight capacity of 220 lbs.

### Expected Components:

- Desktop sections (L-shaped)
- Desk frame components (legs, crossbars)
- Control panel with LED display
- Power adapter and cables
- Hardware kit (screws, tools)
- Assembly instructions guide

## 4. SETUP AND ASSEMBLY INSTRUCTIONS

---

Assembly requires careful attention to detail. It is recommended to have assistance due to the weight of the components. Refer to the separate assembly guide included in your package for step-by-step visual instructions.

### Key Assembly Points:

- **Flexible Orientation:** The L-shaped desktop can be configured for either a left-sided or right-sided return, allowing customization to fit your space. Decide your preferred orientation before starting assembly.



Image 4.1: The L-shaped desk can be assembled with either a left or right orientation.

- **Desktop Thickness:** The desk features a 1-inch thick commercial-grade desktop, suitable for monitor mounts.




Image 4.2: The 1-inch thick desktop provides durability and support for monitor mounts.

- **Frame Assembly:** Assemble the industrial-grade steel frame according to the provided guide. Ensure all connections are secure.
- **Desktop Attachment:** Carefully attach the desktop sections to the assembled frame. Some pilot holes may need to be drilled if not pre-existing, as noted by some users.
- **Cable Management:** Route all power and control cables neatly to prevent entanglement and damage.

## 5. OPERATING INSTRUCTIONS

---

### Control Panel Overview:

The desk is equipped with an LED control panel for easy height adjustment and memory functions.



# SMART CONTROL PANEL



Up/Down Button



4 Height  
Memory Pre-set



Anti-collision

Image 5.1: The smart control panel features up/down buttons, four memory presets, and an anti-collision function.

- **Up/Down Buttons:** Use the ▲ (Up) and ▼ (Down) buttons to manually adjust the desk height.
- **Memory Presets (1, 2, 3, 4):** The control panel allows you to save up to four preferred height settings. To set a memory position:
  1. Adjust the desk to your desired height using the Up/Down buttons.
  2. Press the 'M' or 'Set' button (if available, otherwise hold the number).
  3. Press the desired number button (1, 2, 3, or 4) until you hear a beep or see a confirmation on the LED display. The height is now saved.

To use a memory preset, simply press the corresponding number button, and the desk will automatically move to the saved height.

- **Anti-Collision Feature:** The desk is equipped with an anti-collision system. If the desk encounters an obstacle during height adjustment, it will stop and slightly reverse direction to prevent damage.




Image 5.2: The anti-collision feature prevents damage by reversing movement when an obstacle is detected.

- **Adjustable Height Range:** The desk can be adjusted from a minimum height of 28.3 inches to a maximum height of 45.9 inches.



Image 5.3: The desk offers a large adjustable height range from 28.3 inches to 45.9 inches.

## 6. MAINTENANCE

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight and secure.
- **Cable Management:** Ensure cables are not pinched or tangled, which could affect desk operation.

## 7. TROUBLESHOOTING

If you encounter issues with your desk, refer to the following common solutions:

Problem	Possible Cause	Solution
Desk does not move	Power cable disconnected, control panel error, overload.	Check power connections. Unplug and replug the desk. Reduce weight on the desk.



Problem	Possible Cause	Solution
Uneven height adjustment	Obstruction, uneven weight distribution.	Clear any obstructions. Redistribute weight evenly on the desktop.
Anti-collision feature triggers frequently	Sensitive setting, minor obstructions.	Ensure the area around the desk is clear. Consult the full assembly guide for potential sensitivity adjustments (if applicable).
Noise during operation	Normal motor sound, loose components.	A low hum is normal. Check for any loose screws or components and tighten if necessary.

If the problem persists after attempting these solutions, please contact FLEXISPOT customer service for further assistance.

8. SPECIFICATIONS



Image 8.1: Detailed dimensions of the FLEXISPOT L Shaped Standing Desk.

Feature	Detail
Brand	FLEXISPOT
Model	71x63"Top (3-Legged)
Product Dimensions	63"D x 70.9"W x 45.9"H
Minimum Height	28.3 Inches
Maximum Height	45.9 Inches
Top Material Type	Wood
Tabletop Thickness	1 Inch
Base Material	Alloy Steel
Maximum Weight Capacity	220 Pounds
Number of Height Positions	4 (Memory Presets)
Special Feature	Corded, Anti-collision
Assembly Required	Yes
UPC	840460438469



## 9. WARRANTY AND SUPPORT





FLEXISPOT provides the following warranty coverage for your L Shaped Standing Desk:

- **5-Year Coverage:** Applies to the desk frame and motor.
- **2-Year Protection:** Applies to the control panel and electronics.

For warranty claims, technical support, or any questions not covered in this manual, please contact FLEXISPOT customer service. Refer to the contact information provided with your purchase or visit the official FLEXISPOT website.

### Related Documents - 71x63"Top (3-Legged)

	<p><a href="#">FlexiSpot EG1S/EG1W/EG1B Series Height-Adjustable Desk: Installation Guide &amp; Limited Warranty</a></p> <p>Comprehensive installation guide and limited warranty details for FlexiSpot EG1S, EG1W, and EG1B series height-adjustable desks, covering setup, specifications, troubleshooting, and warranty coverage.</p>
	<p><a href="#">FlexiSpot E7CB/E7CW/E7CS Height Adjustable Standing Desk Installation Guide</a></p> <p>Comprehensive installation guide for FlexiSpot E7CB, E7CW, and E7CS electric height adjustable standing desks. Includes specifications, parts list, step-by-step assembly instructions, operating instructions, troubleshooting, and limited warranty information.</p>

	<p><a href="#">FlexiSpot E4B/E4W Electric Standing Desk User Manual</a></p> <p>Comprehensive user manual for the FlexiSpot E4B/E4W electric standing desk, covering specifications, assembly instructions, keypad operation, troubleshooting, and warranty information.</p>
	<p><a href="#">FlexiSpot M7L-US Computer Riser Installation Guide and Warranty</a></p> <p>Official installation guide and limited warranty information for the FlexiSpot M7L-US Sit-Stand Desktop Workstation. Learn how to assemble, use, and understand the warranty terms for your FlexiSpot computer riser.</p>
	<p><a href="#">FlexiSpot EM7L Motorized Computer Riser Installation Guide</a></p> <p>Comprehensive installation guide for the FlexiSpot EM7L Motorized Computer Riser. Features include specifications, parts list, step-by-step assembly instructions, troubleshooting tips, and limited warranty information.</p>
	<p><a href="#">FlexiSpot ML2B/ML2W Computer Riser Installation Guide and Warranty</a></p> <p>Comprehensive installation guide and limited warranty details for the FlexiSpot ML2B/ML2W Computer Riser. This sit-stand desktop workstation guide covers specifications, parts, assembly steps, usage instructions, and warranty coverage from FlexiSpot.</p>