

## FLEXISPOT B0DV54QLX4

# FLEXISPOT L-Shaped Electric Standing Desk User Manual

Model: B0DV54QLX4

## 1. INTRODUCTION

Thank you for choosing the FLEXISPOT L-Shaped Electric Standing Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read it thoroughly before use and retain it for future reference.

The FLEXISPOT L-Shaped Electric Standing Desk offers a spacious 63.0" x 55.1" work surface with electric height adjustment, allowing seamless transitions between sitting and standing positions. It features a robust 3-legged frame, a preset controller for personalized height settings, and a versatile orientation to fit various office layouts.

## 2. SAFETY INFORMATION

Always ensure the desk is properly assembled and anchored to the floor to prevent tipping. Do not exceed the maximum weight capacity of 220 lbs (100 kg) to maintain stability. Be cautious when adjusting the desk height to avoid injury. Keep children and pets away from the desk during operation. Ensure all cables are managed to prevent tripping hazards or damage during height adjustments.

## 3. PACKAGE CONTENTS

Your FLEXISPOT L-Shaped Electric Standing Desk ships in two separate packages, which may arrive on different days. Please verify all components against the included packing list before beginning assembly. If any parts are missing or damaged, contact FLEXISPOT customer support immediately.

## 4. SETUP AND ASSEMBLY

Assembly of the FLEXISPOT L-Shaped Electric Standing Desk requires careful attention to detail. It is recommended to have two people for certain steps, especially when handling the desktop and flipping the assembled unit. The desk features a flexible design, allowing the wider desktop section to be positioned on either the left or right side to best suit your workspace.

## 4.1 Unpacking and Preparation

1. Carefully unpack all components from both boxes.
2. Lay out all parts on a clean, soft surface (e.g., a blanket or carpet) to prevent scratches.
3. Identify all components using the provided parts list.

## 4.2 Frame Assembly

Follow the detailed instructions in the separate assembly guide provided with your desk. Ensure all screws are tightened securely. The robust industrial-grade steel frame provides stability for your workstation.




Image: Assembled FLEXISPOT L-Shaped Electric Standing Desk.

## 4.3 Desktop Attachment and Orientation

The expansive L-shaped desktop can be configured for either a left-hand or right-hand setup. Decide on your preferred orientation before attaching the desktop to the frame. The desktop is crafted from environmentally sourced splice board, measuring 63.0" x 55.1".

# FLEXIBLE RIGHT/LEFT ORIENTATION

L-shaped standing desk can be left-sided or right-sided, allowing for even more flexibility



Image: Flexible right/left orientation options for the L-shaped desk.

## 4.4 Cable Management

Utilize the included cable management tools to keep your workspace tidy and prevent cables from interfering with the desk's movement.



Image: The desk ships in two packages and has a 220 lbs weight capacity.

## 5. OPERATING INSTRUCTIONS

Your FLEXISPOT L-Shaped Electric Standing Desk is equipped with an intuitive LED control panel for easy height adjustments and memory presets.

### 5.1 Adjusting Desk Height

- Use the **Up (▲)** and **Down (▼)** buttons on the control panel to manually adjust the desk to your desired height.
- The desk offers a large adjustable range, from a minimum height of 28.3 inches to a maximum height of 45.9 inches.



# LARGE ADJUSTABLE RANGE

Perfect size for your home office



Image: Large adjustable height range of the desk.

## 5.2 Using Memory Presets

The LED control panel allows you to save up to four preferred height settings for quick transitions.

1. Adjust the desk to your desired height using the Up/Down buttons.
2. Press the **M** button (Memory) followed by one of the numbered preset buttons **1**, **2**, **3**, or **4** to save the current height.
3. To recall a saved height, simply press the corresponding numbered preset button.

## SMART CONTROL PANEL



Up/Down Button



4 Height  
Memory Pre-set



Anti-collision

Image: Smart LED control panel with memory presets.

### 5.3 Anti-Collision Feature

The desk is equipped with an anti-collision system. If the desk encounters an obstacle during height adjustment, it will automatically stop and rebound slightly to prevent damage or injury.

# ANTI-COLLISION

Rebound immediately




Image: Anti-collision feature in action.

## 6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your standing desk.

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Inspections:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary.
- **Cable Management:** Ensure power cords and other cables are not pinched or tangled, especially during height adjustments.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 220 lbs to prevent strain on the motor and frame.

## 7. TROUBLESHOOTING

If you encounter issues with your FLEXISPOT L-Shaped Electric Standing Desk, refer to the following common troubleshooting steps:

- **Desk Not Moving:**

- Check if the power cord is securely plugged into both the desk and a working power outlet.
- Ensure no objects are obstructing the desk's movement.
- Try resetting the desk by unplugging it for 30 seconds and then plugging it back in.

- **Uneven Movement/Wobbling:**

- Verify that all assembly screws are tightened.
- Ensure the desk is on a level surface. Adjust the leveling feet if necessary.
- Confirm that the weight distribution on the desktop is balanced and within the maximum capacity.

- **Control Panel Not Responding:**

- Perform a power cycle (unplug and replug).
- Check for any visible damage to the control panel or its cable.

If these steps do not resolve the issue, please contact FLEXISPOT customer support.

## 8. SPECIFICATIONS

Brand	FLEXISPOT
Model	B0DV54QLX4
Product Dimensions	55.1"D x 63"W x 45.9"H
Color	Black Frame + Black Top
Style	Modern
Base Material	Alloy Steel
Top Material Type	Wood
Tabletop Thickness	1 Inch
Minimum Height	28 Inches
Maximum Height	45.9 Inches
Maximum Weight Recommendation	220 Pounds
Special Feature	Corded, Preset Controller, Anti-collision
Required Assembly	Yes
UPC	840460438384

## 9. WARRANTY AND SUPPORT

### 9.1 Warranty Information

FLEXISPOT provides the following warranty coverage for your L-Shaped Electric Standing Desk:

- **5-Year Coverage:** Applies to the desk frame and motor.









- **2-Year Protection:** Applies to the control panel and electronics.

Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal use.

## 9.2 Customer Support

For any questions, assistance with assembly, troubleshooting, or warranty inquiries, please contact FLEXISPOT customer support. You can find contact information on the official FLEXISPOT website or through your purchase platform.

### Related Documents - B0DV54QLX4

	<p><a href="#">FlexiSpot EG1S/EG1W/EG1B Series Height-Adjustable Desk: Installation Guide &amp; Limited Warranty</a></p> <p>Comprehensive installation guide and limited warranty details for FlexiSpot EG1S, EG1W, and EG1B series height-adjustable desks, covering setup, specifications, troubleshooting, and warranty coverage.</p>
	<p><a href="#">FlexiSpot E7CB/E7CW/E7CS Height Adjustable Standing Desk Installation Guide</a></p> <p>Comprehensive installation guide for FlexiSpot E7CB, E7CW, and E7CS electric height adjustable standing desks. Includes specifications, parts list, step-by-step assembly instructions, operating instructions, troubleshooting, and limited warranty information.</p>
	<p><a href="#">FlexiSpot E4B/E4W Electric Standing Desk User Manual</a></p> <p>Comprehensive user manual for the FlexiSpot E4B/E4W electric standing desk, covering specifications, assembly instructions, keypad operation, troubleshooting, and warranty information.</p>
	<p><a href="#">FlexiSpot M7L-US Computer Riser Installation Guide and Warranty</a></p> <p>Official installation guide and limited warranty information for the FlexiSpot M7L-US Sit-Stand Desktop Workstation. Learn how to assemble, use, and understand the warranty terms for your FlexiSpot computer riser.</p>
	<p><a href="#">FlexiSpot EM7L Motorized Computer Riser Installation Guide</a></p> <p>Comprehensive installation guide for the FlexiSpot EM7L Motorized Computer Riser. Features include specifications, parts list, step-by-step assembly instructions, troubleshooting tips, and limited warranty information.</p>
	<p><a href="#">FlexiSpot ML2B/ML2W Computer Riser Installation Guide and Warranty</a></p> <p>Comprehensive installation guide and limited warranty details for the FlexiSpot ML2B/ML2W Computer Riser. This sit-stand desktop workstation guide covers specifications, parts, assembly steps, usage instructions, and warranty coverage from FlexiSpot.</p>