

[Manuals.plus](#) /

› [OLIXIS](#) /

› OLIXIS Criss Cross Armless Office Chair Instruction Manual (Model AOL-J37261BU)

OLIXIS AOL-J37261BU

OLIXIS Criss Cross Armless Office Chair Instruction Manual

Model: AOL-J37261BU

INTRODUCTION

Thank you for choosing the OLIXIS Criss Cross Armless Office Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. Please read these instructions carefully before use and retain them for future reference.



Figure 1: OLIXIS Criss Cross Armless Office Chair, Medium Blue Fabric.

SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly.
- Do not stand on the chair.
- Do not use the chair if any parts are missing, damaged, or worn.
- Keep children away from moving parts during assembly.
- Maximum weight capacity: 300 pounds.

PARTS LIST

Please verify that all components are included in your package:

- Seat Cushion with Backrest (1)

- Chair Base (1)
- Gas Lift Cylinder (1)
- Gas Lift Cover (1)
- Assembly Tool (1)
- Screws and Washers (as specified in detailed assembly instructions)

ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your OLIXIS Criss Cross Armless Office Chair. An installation video is typically provided with the product for visual guidance.

1. **Attach the Base:** Place the chair base on a flat, stable surface.
2. **Insert Gas Lift:** Insert the gas lift cylinder into the center hole of the chair base. Place the gas lift cover over the gas lift cylinder.
3. **Attach Seat to Base:** Align the mounting plate on the underside of the seat cushion with the top of the gas lift cylinder. Carefully lower the seat onto the gas lift, ensuring it is securely seated.
4. **Secure Backrest:** If the backrest is separate, attach it to the seat cushion using the provided screws and assembly tool. Ensure all screws are tightened securely.
5. **Final Check:** Verify that all connections are tight and the chair is stable before use.

OPERATING INSTRUCTIONS

Your OLIXIS Criss Cross Armless Office Chair features several adjustable functions for optimal comfort:



Figure 2: Illustration of the chair's rocking function, rocking function knob, and height adjustment lever.

- **Height Adjustment:** To adjust the seat height, pull the lever located under the seat upwards while sitting on the chair to lower it, or while standing to raise it. Release the lever at your desired height. The adjustable height range is 15.94 inches to 19.69 inches.
- **Rocking Function:** The chair features a rocking mechanism. Pull out the lever to enable the seat to rock back and forth. Push the lever in to lock the chair in an upright position.
- **Rocking Tension Adjustment:** A knob under the seat allows you to adjust the tension of the rocking function. Turn the knob clockwise to increase tension (making it harder to rock) or counter-clockwise to decrease tension (making it easier to rock).

Five FUNCTIONS

- 1 Supportive Shell-shaped Backrest
- 2 Rocking Function Knob
- 3 3.75" Height Adjustable
- 4 Tilt Rock
- 5 Armless Design Does Not Take Up Much Space



Figure 3: Overview of the chair's five main functions, including supportive backrest, rocking mechanism, height adjustment, tilt, and armless design for space efficiency.

MAINTENANCE

- **Cleaning:** For fabric upholstery, spot clean with a mild detergent and a damp cloth. Avoid harsh chemicals. For faux leather, wipe with a damp cloth.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading or damage to the upholstery.

TROUBLESHOOTING

- **Chair is wobbly:** Check all assembly screws and ensure they are tightened. Ensure the chair is on a flat, even surface.
- **Height adjustment not working:** Ensure the gas lift lever is fully engaged or disengaged as required. Check for any obstructions around the gas lift cylinder.
- **Rocking function not working:** Ensure the rocking lever is pulled out to enable rocking. Adjust the rocking tension knob to your preference.

SPECIFICATIONS

Product Dimensions

Weight Capacity:300lbs



Figure 4: Key dimensions and weight capacity of the chair.

Feature	Detail
Brand	OLIXIS
Model Name	Criss Cross Legged Chairs
Item Model Number	AOL-J37261BU
Color	Medium Blue
Style	Fabric (No Wheels)
Material	Fabric, Metal
Product Dimensions (D x W x H)	19.5"D x 26"W x 30.7"H
Seat Height Adjustment Range	15.94" to 19.69"

Maximum Weight Recommendation	300 Pounds
Special Features	Adjustable Height, Ergonomic, Swivel, Rocking Function
UPC	762501428195



Figure 5: Details on the chair's ergonomic design, including padded backrest, skin-friendly fabric, and high-density foam cushion for comfort.

U Shape Seat Cushion

Thickened seat cushion semi wrapped design to support the hip sedentary not tired



High Permeability



High Elastic Sponge

Figure 6: Close-up of the U-shape seat cushion, highlighting its high permeability and elastic sponge for prolonged comfort.

Larger Seat Size

Armless design for easy cross-legged sitting
Switch sitting position as you like



Figure 7: The chair's larger seat size and armless design allow for comfortable cross-legged sitting.



Figure 8: The chair's durable gas spring, sturdy metal base, and anti-slip rubber bottom ensure stability and longevity.

WARRANTY AND SUPPORT

This product is covered by Amazon's standard return policy, allowing for refunds or replacements within 30 days of purchase. For specific warranty details or further assistance, please refer to the product listing on Amazon or contact OLIXIS customer support directly.

For additional support or inquiries, please visit the [OLIXIS Store on Amazon](#).

© 2026 OLIXIS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DV5LLN2Q>

More documents and user manuals: <https://manuals.plus/>