Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RAF R.7973

RAF R.7973 Electric Kettle User Manual

Model: R.7973 | Brand: RAF

1. Introduction

Thank you for purchasing the RAF R.7973 Electric Kettle. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before first use and retain them for future reference.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or the kettle base in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the heating cycle.
- Ensure the lid is securely closed before operating.
- Do not fill above the 'MAX' line or below the 'MIN' line to prevent boiling over or boil-dry operation.

- This appliance is for household use only.

3. Product Overview

The RAF R.7973 Electric Kettle features a durable stainless steel and plastic construction, a 360-degree swivel base for easy placement, and safety features like boil-dry and overheat protection.



Figure 3.1: Front view of the RAF R.7973 Electric Kettle, showing the spout, lid, handle, and power button.



Figure 3.2: The kettle highlighting key features such as 360-degree swivel base, LED indicator, and BPA-free interior.



Figure 3.3: Side view of the kettle, illustrating its ergonomic handle and compact design.



Figure 3.4: Back view of the kettle, showing the power cord storage area on the base.



Figure 3.5: View of the kettle's bottom and its detachable 360-degree swivel power base.

4. Setup

1. **Unpacking:** Carefully remove the kettle and all accessories from the packaging. Retain packaging for future storage or transport.
2. **First Use Cleaning:** Before first use, fill the kettle with clean water to the maximum level. Boil the water, then discard it. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Placement:** Place the power base on a dry, flat, stable, and heat-resistant surface. Ensure the power cord is not dangling or in contact with hot surfaces.
4. **Power Connection:** Plug the power base into a grounded electrical outlet.

5. Operating Instructions

1. **Filling the Kettle:** Remove the kettle from its power base. Open the lid and fill the kettle with the desired amount of fresh

water. Do not fill below the minimum mark or above the maximum mark indicated on the water level indicator. Close the lid securely.

2. **Placing on Base:** Place the kettle firmly onto its power base. The 360-degree swivel base allows for easy placement from any angle.
3. **Boiling Water:** Press the power switch (usually located on the handle or base) to the 'ON' position. An indicator light will illuminate, signifying that the kettle is heating.
4. **Automatic Shut-off:** The kettle will automatically switch off once the water has boiled. The indicator light will turn off.
5. **Pouring:** Carefully lift the kettle from the base and pour the hot water. Be cautious of steam escaping from the spout and lid.
6. **Re-boiling:** If the kettle has just boiled, allow a few moments for the internal thermostat to reset before attempting to re-boil.

6. Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your kettle.

Exterior Cleaning

- Always unplug the kettle and allow it to cool completely before cleaning.
- Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- Never immerse the kettle or its power base in water or any other liquid.

Descaling

Mineral deposits (limescale) from tap water can build up inside the kettle. Descale regularly to maintain performance and efficiency.

- Fill the kettle with a solution of one part white vinegar to two parts water.
- Bring the solution to a boil and let it stand for at least 30 minutes, or longer for heavy scale.
- Empty the kettle and rinse thoroughly with fresh water several times.
- For stubborn deposits, repeat the process or use a commercial descaling agent following its instructions.

7. Troubleshooting

Problem	Possible Cause	Solution
Kettle does not turn on.	No power supply; Kettle not properly seated on base; Boil-dry protection activated.	Check power outlet; Ensure kettle is correctly placed on base; Allow kettle to cool down, then refill with water.
Water does not boil.	Lid not closed properly; Insufficient water.	Ensure lid is securely closed; Fill water above the minimum level.
Kettle switches off before boiling.	Excessive limescale buildup.	Descale the kettle as per maintenance instructions.
Water tastes metallic or has particles.	New kettle residue; Limescale buildup.	Perform first-use cleaning again; Descale the kettle.

8. Specifications

The following are the technical specifications for the RAF R.7973 Electric Kettle:



Figure 8.1: Dimensions of the RAF R.7973 Electric Kettle.

Feature	Detail
Brand	RAF
Model Number	R.7973
Color	Multi-color
Capacity	2 Liters
Power	2000 Watt
Material	Stainless Steel, Plastic

Feature	Detail
Special Features	360-degree Swivel Base, Boil-Dry Protection, Overheat Protection, Fast Heating, Time and Electricity Saving
Item Weight	1.2 Kilograms
Product Dimensions (L x W x H)	25 cm x 15 cm x 15 cm
Included Components	Kettle

9. Warranty and Support

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details. For technical support, service, or warranty claims, please contact the retailer or the manufacturer's customer service department. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DV5T6233

More documents and user manuals: **https://manuals.plus/**