Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EMMA + OLIVER EOH-DZSB-136825

EMMA + OLIVER Dani Manual Glider Rocking Recliner User Manual

Model: EOH-DZSB-136825

1. Introduction

Thank you for choosing the EMMA + OLIVER Dani Manual Glider Rocking Recliner. This versatile 3-in-1 chair is designed to provide ultimate comfort and practicality, functioning as a rocking chair, a 3-position recliner, and a 360-degree swivel glider. Its elegant wingback design and durable fabric make it a perfect addition to any living room, bedroom, or nursery.

The recliner features water-repellent, stain-resistant, and fire-retardant upholstery, ensuring safety and longevity. With its simple structure, assembly is quick and easy, typically taking less than 30 minutes. Please read this manual thoroughly before assembly and use to ensure proper operation and maintenance of your new recliner.



Image: The EMMA + OLIVER Dani Manual Glider Rocking Recliner in Dark Gray, positioned in a modern living room with a sofa and decorative elements.

2. Safety Information

Please observe the following safety precautions to prevent injury or damage to the product:

- Ensure all parts are correctly assembled and tightened before use.
- Do not allow children to play on or around the recliner unsupervised.
- Do not stand on the recliner.
- Do not exceed the maximum static weight capacity of 300 lbs.
- Keep hands and feet clear of the reclining mechanism when operating to avoid pinching.
- Avoid placing the recliner near heat sources or in direct sunlight for prolonged periods to prevent fabric damage.
- Do not use harsh chemicals or abrasive cleaners on the fabric.

3. Setup and Assembly

Your EMMA + OLIVER recliner is designed for quick and easy assembly, typically completed in under 30 minutes. Follow these general steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches. Verify all components are present according to the packing list (not provided in this manual, refer to product packaging).
2. **Attach Swivel Base:** Securely attach the 20-inch round swivel base to the bottom of the chair frame. Ensure all bolts are tightened firmly.
3. **Connect Backrest:** Slide the backrest onto the seat base until it clicks securely into place. Ensure both sides are fully engaged.
4. **Final Check:** Once assembled, gently rock and swivel the chair to ensure all mechanisms move freely and the chair is stable.



Image: An assembled EMMA + OLIVER Dani Manual Glider Rocking Recliner, showcasing its wingback design and dark gray fabric.

4. Operating Instructions

The Dani recliner offers three primary functions for your comfort:

4.1. Reclining Function

To recline the chair, locate the manual lever on the side of the recliner (typically on the right side when seated). Pull the lever firmly to release the footrest and lean back to achieve your desired reclining position. The chair supports multiple reclining angles. To return to the upright position, push the footrest down with your legs until it locks into place, and the backrest will return to its original position.



Image: The recliner shown in a partially reclined position, demonstrating the extended footrest for comfort.

4.2. Rocking Function

The chair is designed to rock gently when in the upright position. Simply lean back and forth to initiate the rocking motion. This feature is ideal for relaxation or for use in a nursery setting.

4.3. Swivel Function

The 360-degree swivel base allows you to rotate the chair in any direction without moving the entire unit. Simply push off the floor with your feet to rotate the chair to your desired orientation.



Image: A composite image highlighting the recliner's key features: 3-in-1 functionality (rocker, glider, recliner), stain-resistant and water-repellent upholstery, and a 360-degree swivel base.

5. Maintenance and Care

Proper care will extend the life and appearance of your recliner:

- **Regular Cleaning:** Vacuum or lightly brush the fabric regularly to remove dust and loose debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. For stubborn stains, use a mild soap solution and a damp cloth, then blot dry. Always test on an inconspicuous area first.
- **Avoid Harsh Chemicals:** Do not use bleach, abrasive cleaners, or solvents, as these can damage the fabric and finish.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading of the fabric.
- **Mechanism Check:** Periodically check all bolts and connections to ensure they remain tight.

6. Troubleshooting

If you encounter any issues with your recliner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Recliner not engaging/footrest not extending.	Lever not fully pulled; mechanism obstructed; parts not fully connected.	Ensure the lever is pulled completely. Check for any objects obstructing the mechanism. Verify the backrest is securely attached.
Swivel or rocking motion is stiff.	Base not level; debris in mechanism; lack of lubrication.	Ensure the chair is on a flat, even surface. Check for any debris under the base. If persistent, contact customer support.
Chair feels unstable or wobbly.	Loose connections; uneven assembly.	Re-check all assembly points, especially where the base connects to the seat and the backrest to the seat. Tighten any loose bolts.

If the issue persists after attempting these solutions, please contact customer support for further assistance.

7. Specifications

Key specifications for the EMMA + OLIVER Dani Manual Glider Rocking Recliner:

Feature	Detail
Product Dimensions (Overall)	29.25"W x 35.5"D x 38.75"H
Seat Dimensions	22.75"W x 21.75"D x 20"H (from floor)
Backrest Dimensions	29.25"W x 24.5"H
Arm Height	25.5"H (from floor); 4.75"H (from seat)
Wall Clearance	11.5"
Weight Capacity (Static)	300 lbs
Material	Fabric (Water Repellent, Stain Resistant, Fire Retardant), Polyurethane Foam Fill
Color	Dark Gray
Swivel Base	20 inch round, 360-degree swivel
Assembly Time	Under 30 minutes
Item Weight	59 pounds
Country of Origin	Malaysia



Image: A visual representation of the recliner's dimensions, including height, depth, and width.

8. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact EMMA + OLIVER customer service directly. Keep your purchase receipt for warranty claims.

For further assistance, please visit the official EMMA + OLIVER website or contact their customer support line.

© 2025 EMMA + OLIVER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DV77YMXK

More documents and user manuals: **https://manuals.plus/**