Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Carson /
- > Carson 500204036 1:8 Virus V21 2.4G RTR Nitro RC Buggy Instruction Manual

Carson Virus V21

Carson 500204036 1:8 Virus V21 2.4G RTR Nitro RC Buggy Instruction Manual

Model: Virus V21

Brand: Carson

INTRODUCTION

This manual provides essential information for the safe and effective operation, maintenance, and setup of your Carson 500204036 1:8 Virus V21 2.4G RTR Nitro RC Buggy. Please read this manual thoroughly before using the product to ensure proper handling and to maximize your enjoyment.

The Virus V21 is a high-performance 1:8 scale RC buggy designed for ambitious RC enthusiasts. With its 3.5 ccm Force nitro engine and numerous configuration options, it provides impressive driving fun both off-road and on asphalt. It features a 2.4 GHz interference-free remote control system, a robust competition aluminum chassis, and high-quality components like three steel differentials and powerful 9kg servos.

SAFETY WARNINGS

WARNING!

- Not recommended for children under 14 years of age.
- · Please keep these indications for any query.
- Images may differ from the product found in the packaging.
- TAMIYA-CARSON reserves the right to make improvements and modifications.
- Always operate the RC buggy in a safe and open area, away from people, pets, and obstacles.
- Never operate the RC buggy near public roads or in areas where it could cause a disturbance.
- Ensure proper ventilation when operating the nitro engine.
- Handle fuel with care and store it in a safe, well-ventilated area away from ignition sources.

SETUP

1. Unpacking and Component Identification

Carefully remove all components from the packaging. Verify that all parts are present according to the packing list. The package includes the fully assembled RC buggy with a combustion engine and a 2.4 GHz remote control system.

- Carson 1:8 Virus V21 RC Buggy
- 2.4 GHz Reflex Wheel Remote Control
- Nitro Combustion Engine (3.5 ccm Force engine)
- Instruction Manual
- Additional accessories (check packaging for full list)



Image: The Carson 1:8 Virus V21 RC Buggy shown with its 2.4 GHz Reflex Wheel remote control.

2. Initial Checks and Preparation

- 1. **Remote Control Batteries:** Install the required batteries (not included) into the 2.4 GHz Reflex Wheel remote control. Ensure correct polarity.
- 2. Receiver Batteries: Install the receiver batteries (not included) into the RC buggy.
- 3. **Fueling:** This model uses nitro fuel. Carefully fill the fuel tank with appropriate nitro fuel (not included). Refer to the engine manufacturer's recommendations for fuel type.
- 4. **Engine Priming:** Before the first start, prime the engine according to the nitro engine manual. This usually involves covering the exhaust and pulling the starter cord a few times until fuel reaches the carburetor.
- 5. Glow Plug: Ensure the glow plug is properly installed and connected to a glow plug igniter (not included).
- 6. Binding (if necessary): If the remote control and receiver are not pre-bound, follow the instructions in the remote

OPERATING INSTRUCTIONS

1. Starting the Engine

- 1. Place the RC buggy on a stable surface.
- 2. Turn on the remote control, then turn on the receiver in the buggy.
- 3. Attach the glow plug igniter to the glow plug.
- 4. Use the pull starter to start the engine. If the engine does not start after a few pulls, check the fuel flow and glow plug.
- 5. Once the engine starts, remove the glow plug igniter.

2. Driving Controls

- Throttle: Use the trigger on the remote control to accelerate (pull) and brake/reverse (push).
- Steering: Use the steering wheel on the remote control to turn left or right.
- **Trims:** Adjust the steering and throttle trims on the remote control to ensure the buggy drives straight and stops when the throttle is neutral.

3. Driving Tips

- Off-road Driving: The robust chassis and large-diameter oil pressure shock absorbers are designed for challenging off-road conditions. Maintain control on uneven terrain and adjust speed accordingly.
- **Asphalt Driving:** The buggy can also be driven on asphalt. Adjusting convergence and camber can optimize performance for smoother surfaces.
- Maximum Speed: The Carson Virus V21 can reach speeds of up to 65 km/h. Always be aware of your surroundings and drive responsibly.



Image: The Carson 1:8 Virus V21 RC Buggy in action on a gravel surface, demonstrating its off-road capability.

Your browser does not support the video tag.

Video: A demonstration of the Carson 1:8 King of Dirt Buggy 4S RTR in action, showcasing its off-road capabilities and durability. This video is from the brand and illustrates similar product performance.

MAINTENANCE

Regular maintenance is crucial for the longevity and performance of your Carson Virus V21 RC Buggy.

1. General Cleaning

- After each use, especially in dusty or muddy conditions, clean the buggy thoroughly. Use a soft brush or compressed air to remove dirt and debris.
- Avoid using water directly on electronic components. If necessary, use a damp cloth and ensure all parts are dry before next use.

2. Engine Maintenance (Nitro Engine)

- After-Run Oil: Apply after-run oil to the engine after each running session to prevent corrosion, especially if storing for extended periods.
- Air Filter: Regularly clean and re-oil the air filter to protect the engine from dust and dirt.
- Glow Plug: Inspect the glow plug periodically and replace it if it shows signs of wear or damage.
- Carburetor Settings: Refer to the engine manual for proper carburetor tuning. Incorrect settings can lead to poor performance or engine damage.

3. Component Checks

• Bearings: The vehicle is fully ball-bearing mounted. Check bearings for smooth operation and replace if they feel

rough.

- **Differentials:** The buggy features three steel differentials. Inspect them for wear and ensure they are properly lubricated.
- **Shock Absorbers:** Check the large-diameter oil pressure shock absorbers for leaks or damage. Ensure they provide consistent damping.
- Servos: Verify that the 9kg steering and throttle/brake servos operate smoothly and respond accurately to remote control inputs.
- Chassis and Suspension: Regularly inspect the aluminum chassis, solid wishbones, and pivot ball suspension for any damage or loose connections.

TROUBLESHOOTING

This section addresses common issues you might encounter with your RC buggy.

Problem	Possible Cause	Solution
Engine won't start	No fuel, faulty glow plug, incorrect carburetor settings, dead receiver/remote batteries.	Check fuel level, replace glow plug, adjust carburetor, replace batteries.
Loss of control/erratic behavior	Low remote/receiver battery, interference, loose wiring, damaged servo.	Replace batteries, check for interference sources, inspect wiring, check servo connections.
Poor performance/lack of power	Incorrect engine tuning, dirty air filter, worn engine components.	Adjust carburetor, clean/replace air filter, inspect engine for wear.
Vehicle not moving	No power to motor, transmission issue, remote not bound.	Check battery connections, inspect drivetrain, rebind remote.

If you encounter issues not listed here, please consult the detailed engine manual or contact Carson customer support.

SPECIFICATIONS

Feature	Detail
Model Number	500204036
Scale	1:8
Engine	Nitro Force 3.5 ccm (1.9 HP)
Remote Control System	2.4 GHz Reflex Wheel
Maximum Speed	65 km/h
Chassis	Competition Aluminum Chassis (3 mm extra-flat)
Drive System	Three Steel Differentials
Clutch	Hardened Solid Steel Clutch
Servos	Powerful 9kg servo for steering and throttle/brake

Feature	Detail
Suspension	Large-diameter Oil Pressure Shock Absorbers with Aluminum Thread, Pivot Ball Suspension
Dimensions (L x W x H)	495 mm x 305 mm x 205 mm
Weight	3235 g (approx. 4.66 kg packaged)
Material	Plastic (body), Aluminum (chassis), Steel (differentials, clutch)
Recommended Age	14 years and up

WARRANTY AND SUPPORT

Carson products are known for their quality. For warranty claims or technical support, please refer to the contact information provided with your product packaging or visit the official Carson website. Keep your proof of purchase for any warranty-related inquiries.

As a specialist in remote-controlled vehicles, Carson has been guaranteeing exceptional quality and product safety for 30 years.

Related Documents - Virus V21



Carson Virus 4.0 GP RTR Model: V21/V32/V36 Instruction Manual

Comprehensive instruction manual for the Carson Virus 4.0 GP RTR model, covering setup, operation, maintenance, and troubleshooting for V21, V32, and V36 variants. Includes safety guidelines and essential accessories.



Water-Proof Brushless Speed Controller (RTR Version) User Manual

User manual for the Water-Proof Brushless Speed Controller (RTR Version) ESC. Covers features, specifications, setup, programming, calibration, troubleshooting, and optional accessories for RC cars and trucks.



CARSON RC Boats: Radio Controlled Boat RTR User Manual and Safety Guide

Comprehensive user manual and safety guide for CARSON RC Boats (Ready to Run) models 500108031, 500108032, and 500108033. Includes setup, operation, battery handling, and safety precautions.



CARSON FE-LINE 2.4 GHz: 100% RTR Ready-to-Run Model Instruction Manual

Official instruction manual for the CARSON FE-LINE 2.4 GHz, a 100% Ready-to-Run (RTR) remote-controlled model car. Includes setup, operation, and safety guidelines.



CARSON Drift Burner 2.4 GHz RC Car Instruction Manual

Comprehensive instruction manual for the CARSON Drift Burner 2.4 GHz RC car, covering setup, operation, safety precautions, and battery handling. Features detailed descriptions of controls, charging, and maintenance.



CARSON Bella Luisa 2.4 GHz RTR Model Boat - User Manual

Discover the CARSON Bella Luisa 2.4 GHz RTR model boat. This comprehensive manual provides essential setup, operation, and safety instructions for your radio-controlled boat, ensuring an optimal and enjoyable experience for hobbyists. Explore the features and guidelines to get the most out of your CARSON Bella Luisa boat.