Signature Design by Ashley 3740694

Signature Design by Ashley Frohn Manual Reclining Loveseat with Console

Model: 3740694

1. Safety Information

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Ensure all components are securely fastened before use.
- Do not allow children to play on or around the reclining mechanism.
- Keep hands and feet clear of moving parts during reclining operation.
- Avoid placing heavy objects on the console lid or armrests.

2. Product Overview

The Frohn Manual Reclining Loveseat with Console is designed for comfort and functionality. It features plush, ultra-soft polyester upholstery, a manual pull-tab reclining motion, and a center console with two cup holders and hidden storage.



Front view of the Frohn Manual Reclining Loveseat with Console in Grey.

3. Setup and Assembly

This loveseat requires minimal assembly. It is recommended that two people assemble the unit.

3.1 Unpacking

- Carefully remove all components from the packaging.
- Verify all parts are present according to the packing list.
- Retain packaging materials until assembly is complete in case of missing parts.

3.2 Assembly Steps

For detailed assembly instructions, please refer to the official PDF manual:

Download Assembly Instructions (PDF)

Tools Recommended: A screwdriver may be helpful for certain steps.



AVAILABLE IN THREE COLORS



SNOW



GRAPHITE



CHOCOLATE

This product requires assembly.

3.3 Placement Considerations

- **Minimum Doorway Width:** Ensure your doorway is at least 32 inches wide for delivery and placement.
- **Wall Clearance:** Allow at least 3 inches of clearance between the recliner and the wall for full reclining motion.



FULLY ASSEMBLED : 80" W X 40" D X 42" H

Arm height: 27"
Seat depth: 22"
Seat height: 22"
Footrest height: 19"

Fully reclined length: 70"
Distance between arms: 56"
Distance between recliner and wall: 3"



Diagram showing the dimensions of the loveseat, including width, depth, height, and required doorway width.

4. Operating Instructions

4.1 Reclining Function

- Locate the pull tab on the side of the loveseat.
- Pull the tab to release the footrest and recline the backrest.
- Lean back to achieve your desired reclining position. The loveseat offers 3 reclining positions.
- To return to the upright position, push down on the footrest with your legs until it locks into place.

ALSO AVAILABLE IN THIS COLLECTION





The manual pull tab for operating the reclining function.

4.2 Center Console Use

- The center console features two integrated cup holders.
- Lift the console lid to access the hidden storage compartment, ideal for remotes or small items.




The center console provides convenient cup holders and hidden storage.

5. Maintenance and Care

5.1 Cleaning Instructions

- **Upholstery:** Spot clean the polyester upholstery with a damp cloth. Use a mild, water-based cleaning agent if necessary. Test in an inconspicuous area first.
- **Cleaning Code:** W (Water-based cleaner).
- Avoid harsh chemicals or abrasive cleaners, as these can damage the fabric.



The plush polyester upholstery requires spot cleaning with a damp cloth.

5.2 General Maintenance

- Periodically check all bolts and screws to ensure they are tight.
- Avoid prolonged exposure to direct sunlight to prevent fading.
- Keep the loveseat away from heat sources.

6. Troubleshooting

If you encounter any issues with your loveseat, please review the assembly instructions and ensure all parts are correctly installed. For persistent problems or concerns, contact Signature Design by Ashley customer support.

7. Specifications

Feature	Detail
Brand	Signature Design by Ashley
Model Name	Frohn
Model Number	3740694

Color	Grey
Type	Loveseat
Style	Contemporary
Seating Capacity	2
Product Dimensions (D x W x H)	40"D x 80"W x 42"H
Item Weight	201 Pounds
Reclined Length	70 Inches
Furniture Wall Clearance	3 Inches
Minimum Required Door Width	32 Inches
Upholstery Fabric Type	Polyester
Upholstery Cleaning Code	W
Frame Material Type	Engineered Wood, Metal, Wood
Seat Fill Material	Fiber Wrapped Foam
Additional Features	Console, Cup Holder, Recliner, Storage
Assembly Required	Yes
Recommended People for Assembly	2

8. Warranty and Support

8.1 Product Warranty

For specific warranty details, please refer to the product description on the store page or contact Signature Design by Ashley directly. The manufacturer warranty type is Limited.

8.2 Customer Support

For further assistance, questions, or to report any issues, please visit the official Signature Design by Ashley store or contact their customer service department.

Visit the Signature Design by Ashley Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question