

ZEBRONICS EnergiPod 10MR1

ZEBRONICS EnergiPod 10MR1 10000mAh 22.5W Power Bank User Manual

Model: EnergiPod 10MR1 (Zeb-PB 13)

Brand: ZEBRONICS

INTRODUCTION

The ZEBRONICS EnergiPod 10MR1 is a 10000mAh power bank designed for portable charging of various electronic devices. It features 22.5W fast charging capabilities, multiple output ports including Type-C and USB-A, and built-in safety protections. This manual provides essential information for the safe and efficient use of your power bank.



Image: The ZEBRONICS EnergiPod 10MR1 Power Bank, a compact grey device, held in a user's hand, showcasing its portable design.

PACKAGE CONTENTS

Please verify that all items are present in the package:

- 1 x ZEBRONICS EnergiPod 10MR1 Power Bank
- 1 x Charging Cable
- 1 x QR Code Guide

SETUP AND INITIAL CHARGING

Before using your power bank for the first time, it is recommended to fully charge it.

1. **Connect the Power Bank:** Use the provided charging cable to connect the power bank's Type-C input port (labeled "IN" or "IN/OUT") to a compatible USB wall adapter (not included).
2. **Power Source:** Plug the USB wall adapter into a power outlet.
3. **Charging Indication:** The LED indicator on the power bank will illuminate to show the charging status and remaining battery percentage. Allow the power bank to charge until the LED indicator shows 100%

or a full charge.




Image: A close-up view of the ZEBRONICS EnergiPod 10MR1 Power Bank's ports, showing the USB Out, Power Button, Type C In, and Type C In/Out ports with their respective labels.

OPERATING INSTRUCTIONS

Charging Your Devices

1. **Connect Your Device:** Use a compatible charging cable (your device's original cable or the one provided with the power bank) to connect your smartphone, tablet, or other USB-powered device to one of the power bank's output ports (USB-A or Type-C).
2. **Initiate Charging:** The power bank should automatically begin charging your device. If not, press the power button once to activate charging.
3. **Monitor Charging:** The LED indicator on the power bank will show the remaining battery level. Your device's screen will indicate that it is charging.
4. **Disconnect:** Once your device is fully charged, disconnect it from the power bank.



Image: The ZEBRONICS EnergiPod 10MR1 Power Bank connected via cable, actively charging a smartphone, with a "22.5W (Max) Output" label indicating its fast charging capability.



Image: The ZEBRONICS EnergiPod 10MR1 Power Bank simultaneously charging a smartphone and a tablet, highlighting its PD 3.0 Type C Output for versatile device compatibility.

LED Indicator

The LED indicator displays the remaining battery percentage of the power bank. Refer to the QR Code Guide for specific interpretations of the LED patterns.

MAINTENANCE AND CARE

- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cleaning:** Use a soft, dry cloth to clean the surface of the power bank. Do not use liquid cleaners or abrasive materials.
- **Avoid Drops:** Protect the power bank from drops and impacts, as this can damage internal components.
- **Regular Use:** To maintain battery health, use and recharge the power bank at least once every three months.
- **Safety:** Do not disassemble, puncture, or expose the power bank to fire or water.

SAFETY PROTECTIONS

The ZEBRONICS EnergiPod 10MR1 is equipped with multiple safety features to protect both the power bank and your connected devices:

- **Overcharge Protection:** Prevents the power bank from being overcharged, extending battery lifespan.
- **Overload Protection:** Protects against excessive current draw, preventing damage to connected devices.
- **Short-Circuit Protection:** Automatically shuts down power in case of a short circuit to prevent damage.



Image: The ZEBRONICS EnergiPod 10MR1 Power Bank charging a phone, accompanied by icons representing Overcharge Protection, Short Circuit Protection, and Overload Protection, emphasizing its safety features.

TROUBLESHOOTING

- **Power Bank Not Charging:**
 - Ensure the charging cable is securely connected to both the power bank and the wall adapter.
 - Verify that the wall adapter is functioning and the power outlet is active.
 - Try a different charging cable or wall adapter.
- **Device Not Charging from Power Bank:**
 - Ensure the power bank has sufficient charge. Check the LED indicator.

- Press the power button on the power bank to activate output.
 - Verify that the charging cable connecting your device to the power bank is functional and securely connected.
 - Try a different output port on the power bank.
 - Ensure your device is compatible with the power bank's output specifications.
- **Slow Charging:**
 - Ensure you are using a fast-charging compatible cable and your device supports fast charging.
 - Some devices may limit charging speed if they are in heavy use or if their battery is nearly full.

SPECIFICATIONS

Feature	Detail
Model Number	EnergiPod 10MR1 (Zeb-PB 13)
Battery Capacity	10000 mAh
Max Output Power	22.5W
Input Connectivity	Type-C1 / C2: DC 5V/3A, 9V/2A, 12V/1.5A
Output Connectivity	Type-C2 Output: DC 5V/3A, 9V/2.22A, 12V/1.67A, 5~11V/2A (PPS) Type-C Output: PD 3.0 (with PPS) USB-A Output: DC 5V/3A, 9V/2A, 12V/1.85A
Connector Type	1 x USB A, 2 x USB Type C
LED Indicator	Yes, for battery percentage
Body Material	Metal
Color	Grey
Dimensions	17 x 9.9 x 2.1 cm
Item Weight	628 g
Manufacturer	Zebronics India Private Limited
Country of Origin	India

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official ZEBRONICS website or contact their customer service directly. The QR Code Guide included in your package may also provide direct links to support resources.

Manufacturer: Zebronics India Private Limited

Manufacturer Address: No.13/7, Smith Road, Royapettah, Chennai - 600 002

Date First Available: 27 January 2025

For further assistance, visit the [ZEBRONICS Store on Amazon](#).

