



[Manuals.plus](#) /

> [Flamaker](#) /

> Flamaker 80 Gallon Outdoor Storage Bench Instruction Manual

Flamaker LCRC24-0431

Flamaker 80 Gallon Outdoor Storage Bench Instruction Manual

Model: LCRC24-0431

1. PRODUCT OVERVIEW

The Flamaker 80 Gallon Outdoor Storage Bench is a versatile furniture piece designed for both seating and storage. Constructed from durable resin, it is suitable for outdoor and indoor environments, offering resistance to various weather conditions. Its design includes a spacious internal compartment and a reinforced structure capable of supporting multiple individuals.



Image 1.1: The Flamaker 80 Gallon Outdoor Storage Bench in a typical outdoor setting.

Key Features:

- **Spacious Storage Capacity:** Offers 80 gallons of storage for various items.
- **All-Weather Design:** Crafted from high-quality resin to withstand sun and rain.
- **Reinforced Structure:** Supports up to 600 lbs, accommodating 2-3 people.
- **Lockable Design:** Provides an option for securing stored items (lock not included).
- **Easy Mobility:** Integrated handles facilitate repositioning.

2. SETUP AND ASSEMBLY

Assembly of the Flamaker 80 Gallon Outdoor Storage Bench is required. The process typically involves 9 pieces and 6 screws, and can be completed in approximately 15-20 minutes following the provided instructions. A screwdriver may be helpful, though some components are designed for tool-free assembly.



▶ PRODUCT DIMENSION ◀



Image 2.1: Product dimensions for assembly planning.

Assembly Steps:

1. Unpack all components and verify against the parts list (not provided in this manual).
2. Connect the side panels to the front and back panels, ensuring all tabs and slots align.
3. Attach the base panel to the assembled sides.
4. Secure the bench backrest to the main body.
5. Install the armrests, ensuring a snug fit.
6. Attach the lid to the main storage compartment using the designated hinges.
7. Insert any required screws to reinforce connections, particularly for the lid mechanism.
8. Ensure all parts are securely fastened before use.

Tip: When attaching end pieces, tilting the unit upright can facilitate easier alignment.

3. OPERATING INSTRUCTIONS

The Flamaker 80 Gallon Outdoor Storage Bench serves a dual purpose: comfortable seating and secure storage.

Using as a Bench:

- The bench is designed to comfortably seat 2-3 adults, with a maximum weight capacity of 600 pounds.
- Ensure the bench is placed on a stable, level surface before seating.

- Avoid standing on the bench or applying excessive localized pressure.



Image 3.1: The bench provides comfortable seating for multiple individuals.

Using as Storage:

- To access the storage compartment, lift the lid using the integrated handle.
- The spacious interior is suitable for storing outdoor toys, gardening equipment, patio cushions, and seasonal decor.
- To secure your belongings, a lock can be attached to the designated area on the lid (lock not included).
- Ensure the lid is fully closed to protect contents from dust and moisture.



Image 3.2: The interior storage compartment can hold a variety of items.

4. MAINTENANCE

Proper maintenance ensures the longevity and appearance of your Flamaker 80 Gallon Outdoor Storage Bench.

Cleaning:

- For general cleaning, use mild soap and water.
- Wipe the surfaces with a soft cloth or sponge.
- Rinse thoroughly with clean water and allow to air dry completely.
- Avoid using harsh chemicals, abrasive cleaners, or stiff brushes, as these can damage the resin material.



Image 4.1: The resin material is designed for easy cleaning and weather resistance.

Storage and Care:

- Do not expose the bench to extreme temperatures or direct sunlight for extended periods when not in use, as this may affect material integrity over time.
- While the bench is weather-resistant, prolonged exposure to heavy rain may lead to some moisture inside the storage compartment. Consider placing sensitive items in waterproof bags.
- Always ensure the bench is securely placed and not overloaded beyond 600 lbs.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your storage bench.

Lid Does Not Close Properly:

- Check for any obstructions inside the storage compartment or along the lid's edges.
- Ensure the bench is on a level surface, as uneven ground can cause misalignment.
- Verify that all assembly screws and connections for the lid and hinges are tight and correctly installed.

Water Inside Storage Compartment:

- While designed to be weather-resistant, the bench may not be completely watertight during heavy downpours.
- Ensure the lid is fully closed and properly seated.
- Check for any cracks or damage to the resin material that might compromise its water resistance.
- For sensitive items, consider using additional waterproof containers or bags inside the bench.

Bench Feels Unstable:

- Confirm that the bench is placed on a firm, level surface.
- Inspect all connections and screws to ensure they are tightened securely.
- Do not exceed the maximum weight capacity of 600 lbs.

6. SPECIFICATIONS

Feature	Specification
Product Dimensions (D x W x H)	23.2" x 53.1" x 31.5"

Feature	Specification
Material	Resin
Color	Brown
Storage Capacity	80 Gallons
Maximum Weight Recommendation	600 Pounds
Seating Capacity	3 people
Item Weight	44 Pounds
Model Number	LCRC24-0431
Required Assembly	Yes

7. WARRANTY INFORMATION

Specific warranty details for the Flamaker 80 Gallon Outdoor Storage Bench are not provided in the available product information. Please refer to your purchase documentation or contact the retailer for warranty terms and conditions.

8. SUPPORT AND CONTACT

For further assistance, questions, or to report any issues with your Flamaker 80 Gallon Outdoor Storage Bench, please contact Flamaker customer support through the retailer where the product was purchased. Contact information may also be available on the official Flamaker website or within your product packaging.