

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [EKO](#) /
- › [EKO Pack Flash Inspiria Smartwatch and TWS Jeez Earbuds User Manual](#)

## EKO Inspiria Smartwatch and TWS Jeez Earbuds

# EKO Pack Flash: Inspiria Smartwatch and TWS Jeez Earbuds User Manual

Comprehensive guide for setup, operation, and maintenance.



## 1. INTRODUCTION

---

This manual provides essential instructions for the EKO Pack Flash, which includes the Inspiria Smartwatch and TWS Jeez Earbuds. Please read this guide carefully before using your devices to ensure proper operation and longevity.

## 2. PACKAGE CONTENTS

---

- EKO Inspiria Smartwatch
- TWS Jeez Earbuds (Left and Right)
- Charging Cable for Smartwatch
- Charging Case for Earbuds
- User Manual (this document)

## 3. SETUP

---

### 3.1. Inspiria Smartwatch Setup

#### 1. Charge the Smartwatch:

Before first use, fully charge the Inspiria Smartwatch. Connect the provided charging cable to the charging port on the back of the watch and to a USB power adapter (not included). The watch display will indicate charging status.



*Image: Side view of the Inspiria Smartwatch, highlighting the charging contacts and the crown button. This view helps locate the charging area.*

**2. Power On:**

Press and hold the side button (crown) for a few seconds until the EKO logo appears on the screen.

**3. Install Companion App:**

Scan the QR code displayed on the watch screen or refer to the packaging to download the official EKO companion application on your smartphone (compatible with iOS and Android devices).

**4. Pair with Smartphone:**

Enable Bluetooth on your smartphone. Open the EKO companion app and follow the on-screen instructions to search for and connect to your Inspiria Smartwatch. Confirm the pairing request on both your phone and the smartwatch.

**5. Initial Configuration:**

Complete the initial setup within the app, including personal information, notification preferences, and desired watch faces.



*Image: The EKO Inspiria Smartwatch with a white silicone band, showing a vibrant space-themed watch face. This illustrates the watch's display capabilities after setup.*

### 3.2. TWS Jeez Earbuds Setup

**1. Charge the Earbuds and Case:**

Place the TWS Jeez Earbuds into their charging case. Connect the charging case to a USB power source using the provided cable. Ensure both the earbuds and the case are fully charged before first use.

**2. Power On and Pairing Mode:**

Open the charging case. The earbuds will automatically power on and enter pairing mode (indicated by flashing LED lights on the earbuds).

**3. Pair with Smartphone:**

Enable Bluetooth on your smartphone. Go to your phone's Bluetooth settings and select "EKO Jeez" (or similar name) from the list of available devices to pair.

**4. Confirmation:**

Once paired, the LED indicators on the earbuds will stop flashing, and your phone will confirm the connection.

## 4. OPERATING INSTRUCTIONS

### 4.1. Inspiria Smartwatch Operation

- **Navigation:**

Swipe left/right, up/down on the touchscreen to navigate through menus, notifications, and widgets. Press the

side button (crown) to return to the home screen or access the app list.



*Image: The EKO Inspiria Smartwatch featuring a gold mesh band, with its screen displaying a grid of colorful application icons. This demonstrates the user interface for app selection.*

- **Voice Call Function:**

With the smartwatch paired to your phone, you can make and receive calls directly from your wrist. Access the dialer or contacts through the watch interface. Ensure your phone is within Bluetooth range.

- **Notifications:**

Receive notifications for calls, messages, and app alerts directly on your smartwatch. Swipe down from the top of the screen to view recent notifications.

- **Health Monitoring:**

The smartwatch tracks various health metrics. Access these features through the watch menu or the companion app. Data includes steps, heart rate, and sleep patterns. *Note: This device is not a medical device and data should not be used for medical diagnosis.*

- **Customization:**

Change watch faces, adjust brightness, and configure other settings via the watch or the companion app.

## 4.2. TWS Jeez Earbuds Operation

- **Wearing the Earbuds:**

Insert the earbuds gently into your ears, ensuring a comfortable and secure fit. Adjust as needed for optimal sound quality.

- **Music Playback:**

Use the touch controls on the earbuds to play/pause music, skip tracks (single tap, double tap, or long press, depending on model configuration). Refer to the companion app or quick start guide for specific touch control gestures.

- **Call Management:**

Answer incoming calls with a single tap on either earbud. End calls with another tap. Reject calls by long-pressing an earbud.

- **Voice Assistant:**

Activate your smartphone's voice assistant (Siri, Google Assistant) by a specific touch gesture (e.g., triple tap or long press) on an earbud.

## 5. MAINTENANCE

---

### 5.1. Cleaning

- **Smartwatch:**

Wipe the screen and body with a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water. Avoid harsh chemicals or abrasive materials.

- **Earbuds and Case:**

Gently clean the earbuds and charging contacts with a dry cotton swab. Use a soft, dry cloth for the charging case. Do not immerse in water.

### 5.2. Battery Care

- Avoid fully discharging the battery frequently. Charge your devices regularly.
- Do not expose devices to extreme temperatures (hot or cold) as this can degrade battery life.
- Use only the provided charging cables or certified replacements.

## 6. TROUBLESHOOTING

---

### 6.1. Smartwatch Issues

- **Device not powering on:**

Ensure the smartwatch is fully charged. Connect it to the charger and wait a few minutes before attempting to power on again.

- **Cannot pair with phone:**

Make sure Bluetooth is enabled on your phone and the smartwatch. Restart both devices. Ensure the companion app is installed and running. Forget previous pairings on your phone's Bluetooth settings and try again.

- **Notifications not appearing:**

Check notification settings in the EKO companion app and your phone's system settings to ensure permissions are granted for the app to send notifications.

### 6.2. Earbuds Issues

- **No sound from earbuds:**

Ensure earbuds are charged and properly paired. Check your phone's volume settings. Try re-pairing the earbuds.

- **Only one earbud working:**

Place both earbuds back into the charging case, close the lid, wait a few seconds, then open again. This often resets their connection. Ensure both earbuds are charged.

- **Cannot pair with phone:**

Ensure earbuds are in pairing mode. Turn off and on your phone's Bluetooth. Forget "EKO Jeez" from your phone's Bluetooth list and try pairing again.

## 7. SPECIFICATIONS

Feature	Detail
Brand	EKO
Smartwatch Model	Inspiria
Earbuds Model	Jeez (TWS)
Operating System (Smartwatch)	Android
Connectivity	Bluetooth
Special Features (Smartwatch)	Voice Call
Compatible Devices	Smartphone, Tablet, Laptop
Display Type (Smartwatch)	LCD or OLED
Smartwatch Shape	Rectangular
GPS	No GPS
Compatible Phone OS	iOS and Android devices

## 8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official EKO website. Specific warranty terms may vary by region and retailer.

*Note: Information regarding spare parts availability and software updates is not explicitly provided by the manufacturer.*

