

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Powerplus](#) /

› [Powerplus POWXG90504 Electric High-Pressure Cleaner User Manual](#)

Powerplus POWXG90504

Powerplus POWXG90504 Electric High-Pressure Cleaner User Manual

Model: POWXG90504 | Brand: Powerplus

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Powerplus POWXG90504 Electric High-Pressure Cleaner. Please read these instructions carefully before using the appliance and keep them for future reference.

2. GENERAL SAFETY INSTRUCTIONS

- Always wear appropriate personal protective equipment (PPE) such as safety glasses, hearing protection, and protective footwear.
- Ensure the power supply matches the specifications on the product label.
- Never direct the water jet at people, animals, electrical equipment, or the appliance itself.
- Keep children and pets away from the working area.
- Do not use the appliance if the power cord, high-pressure hose, or other critical parts are damaged.
- Disconnect the appliance from the power supply before cleaning, maintenance, or when not in use.
- Use only original Powerplus accessories and spare parts.

3. PACKAGE CONTENTS

Verify that all items are present and undamaged upon unpacking:

- Powerplus POWXG90504 High-Pressure Cleaner unit
- High-pressure gun with adjustable nozzle
- Turbo nozzle
- Patio cleaner attachment

- Cleaning brush
- 8-meter high-pressure hose
- 5-meter power cable
- Integrated 0.9-liter soap reservoir
- User Manual

4. ASSEMBLY

Follow these steps to assemble your high-pressure cleaner:

1. **Attach the Wheels:** Securely attach the wheels to the base of the unit.
2. **Install the Handle:** Slide the handle into its designated slots until it clicks into place.
3. **Connect the High-Pressure Hose:** Connect one end of the 8-meter high-pressure hose to the outlet on the high-pressure cleaner unit and the other end to the high-pressure gun. Ensure connections are tight.
4. **Attach the Nozzle:** Select the desired nozzle (adjustable or turbo) and attach it to the high-pressure gun. For specific cleaning tasks, attach the patio cleaner or brush.

5. SETUP AND CONNECTION

Before operation, ensure proper setup:

1. **Water Supply:** Connect the high-pressure cleaner to a suitable water supply using a garden hose. Ensure the water supply is clean and free of debris. The maximum water temperature should not exceed 50°C.
2. **Power Supply:** Plug the 5-meter power cable into a grounded electrical outlet.
3. **Detergent (Optional):** If using detergent, fill the integrated 0.9-liter soap reservoir with appropriate high-pressure cleaner detergent.

6. OPERATING INSTRUCTIONS


Your Powerplus POWXG90504 is designed for effective cleaning of various surfaces. It features a 2200W motor and a maximum pressure of 170 bar.

6.1 Starting the Appliance

1. Turn on the water supply.
2. Press the trigger on the high-pressure gun to release any air from the system until a steady stream of water emerges.
3. Turn the main power switch on the unit to the 'ON' position. The motor will activate only when the trigger on the spray gun is pressed (Start/Stop function).

6.2 Using Different Nozzles and Attachments

- **Adjustable Nozzle:** Rotate the nozzle head to adjust the spray pattern from a concentrated jet to a wide fan spray for different cleaning needs.
- **Turbo Nozzle:** Provides a powerful, rotating jet for removing stubborn dirt and grime. Ideal for hard surfaces like concrete.
- **Patio Cleaner:** Use for efficient and splash-free cleaning of large flat surfaces like patios and driveways.
- **Cleaning Brush:** Suitable for gentle cleaning of sensitive surfaces, such as vehicles.



Große Auswahl an Sprühmustern

POWERPLUS

Image: Powerplus POWXG90504 High-Pressure Cleaner with various nozzles and attachments.

6.3 Applying Detergent

1. Ensure the soap reservoir is filled with appropriate detergent.
2. Attach the detergent nozzle or adjust the multi-function nozzle to the detergent setting.
3. Spray the detergent onto the surface, allowing it to soak for a few minutes (refer to detergent instructions).
4. Rinse the surface with clean water using a high-pressure jet.



Energie- und Wassersparsystem

POWERPLUS

Image: Illustrates the 2200W motor and energy-saving start/stop function of the Powerplus POWXG90504.

7. MAINTENANCE AND STORAGE

7.1 Cleaning

- After each use, flush the system with clean water to remove any detergent residue.
- Clean the nozzles and attachments to prevent blockages.
- Wipe the exterior of the unit with a damp cloth.

7.2 Storage

- Drain all water from the pump and hose to prevent freezing damage in cold weather.
- Store the high-pressure cleaner in a dry, frost-free location.
- Use the integrated cable tie to neatly store the power cable and wrap the 8-meter high-pressure hose around the designated reel.
- The unit is equipped with a handle and wheels for easy transport and storage.



Einfach zu transportieren und zu lagern

POWERPLUS

Image: The Powerplus POWXG90504 features a handle and wheels for convenient transport and storage.

8. TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

- **No Pressure:** Check water supply, ensure hose is not kinked, and verify nozzle is not blocked.
- **Motor Not Starting:** Check power connection, ensure the main switch is ON, and the trigger on the gun is pressed.
- **Pulsating Pressure:** Air in the system (bleed by pressing trigger without power), insufficient water supply, or blocked inlet filter.
- **Water Leakage:** Check all connections for tightness. Replace O-rings if damaged.

For persistent issues, contact Powerplus customer support.

9. SPECIFICATIONS

Feature	Specification
Model Number	POWXG90504
Power Source	Electric with cord
Motor Power	2200 W
Max Pressure	170 bar
Max Water Temperature	50 °C
Max Flow Rate	420 Liters Per Hour
High-Pressure Hose Length	8 meters
Power Cable Length	5 meters
Soap Reservoir Capacity	0.9 liters
Product Dimensions	38.3 x 32 x 83 cm
Item Weight	8.9 kg



Geeignet für schwere Arbeiten

POWERPLUS

Image: Highlighting the maximum pressure of 170 bar and maximum water temperature of 50°C for the Powerplus POWXG90504.



Mehr Bewegungsfreiheit

POWERPLUS

Image: Illustrating the 8-meter high-pressure hose and 5-meter power cable for extended reach.

10. WARRANTY AND SUPPORT

This Powerplus product comes with a standard manufacturer's warranty. For detailed warranty terms and conditions, please refer to the warranty card included in your package or visit the official Powerplus website. For technical support, spare parts, or service inquiries, please contact your retailer or Powerplus customer service.