

[Manuals.plus](#) /

› [BLACK+DECKER](#) /

› BLACK+DECKER 5-Setting Dual Shower Head (Model BD0029) Instruction Manual

BLACK+DECKER BD0029

BLACK+DECKER 5-Setting Dual Shower Head (Model BD0029) Instruction Manual

Your comprehensive guide to installation, operation, and maintenance.

1. INTRODUCTION

Thank you for choosing the BLACK+DECKER 5-Setting Dual Shower Head. This system provides the flexibility of a handheld shower and a rainfall shower head, offering multiple spray settings for a customized experience. This manual contains important information regarding the safe installation, operation, and maintenance of your new shower head. Please read it thoroughly before installation and retain it for future reference.

2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- Ensure all connections are tightened properly to prevent leaks. Overtightening plastic components can cause damage.
- Do not use harsh abrasive cleaners on the shower head surfaces, as this may damage the finish.
- Always turn off the water supply before attempting any installation or maintenance.
- If you are unsure about any installation steps, consult a qualified plumber.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Dual Shower Head Unit (Rainfall and Handheld)
- 60-inch Stainless Steel Hose
- Shower Mount/Diverter
- Plumber's Tape
- Washers

Spa-like Shower



Calm like gentle rain



Relaxing & Soft on skin



Dual System, unique modes



Figure 1: Product dimensions and key components. The image displays the overall length of 9 inches, with each shower head being 4 inches in diameter and 1 inch thick.

4. SETUP AND INSTALLATION

The BLACK+DECKER Dual Shower Head is designed for quick and tool-free installation. Follow these steps:

1. **Prepare the Shower Area:** Turn off the main water supply to your shower. Remove your existing shower head by unscrewing it counter-clockwise from the shower arm. Clean any debris from the shower arm threads.
2. **Apply Plumber's Tape:** Wrap the included plumber's tape clockwise around the threads of your shower arm 3-5 times. This helps prevent leaks.
3. **Install the Shower Mount:** Screw the new shower mount/diverter onto the shower arm clockwise until hand-tight. Do not overtighten. Ensure the diverter lever is accessible.
4. **Attach Rainfall Shower Head:** Screw the larger rainfall shower head onto the top outlet of the shower mount clockwise until hand-tight.
5. **Connect Handheld Hose:** Attach one end of the 60-inch stainless steel hose to the bottom outlet of the shower mount.

Ensure a washer is properly seated inside the hose connection. Screw clockwise until hand-tight.

6. **Attach Handheld Shower Head:** Attach the other end of the stainless steel hose to the handheld shower head. Ensure a washer is properly seated. Screw clockwise until hand-tight.
7. **Secure Handheld Shower:** Place the handheld shower head into its holder on the side of the shower mount.
8. **Test for Leaks:** Turn on the main water supply and check all connections for leaks. If leaks occur, tighten the connections slightly more, ensuring not to overtighten, or reapply plumber's tape.



Figure 2: The shower head system is designed for quick and easy installation, requiring no special tools. Plumber's tape is included to ensure a secure, leak-free connection.

5. OPERATING INSTRUCTIONS

Your dual shower head system offers versatile functionality:

5.1 Switching Between Shower Modes

The diverter lever on the shower mount allows you to select between the rainfall shower head, the handheld shower head, or both simultaneously:

- Move the lever to the left for the handheld shower only.
- Move the lever to the right for the rainfall shower head only.
- Position the lever in the middle to activate both shower heads.



Figure 3: The diverter allows selection of handheld, rainfall, or combined shower modes.

5.2 Adjusting Spray Settings

Both the rainfall and handheld shower heads feature 5 distinct spray settings:

- **Power Mist:** A fine, invigorating mist.
- **Rain Spray:** A gentle, full-coverage rain-like flow.
- **Power Rain:** A stronger, more concentrated rain spray.
- **Power Massage:** A pulsating stream for muscle relaxation.
- **Rain + Massage:** A combination of rain and pulsating massage.

To change the spray setting, rotate the dial on the face of each shower head until you reach your desired setting.




Figure 4: The 5-setting dial on each shower head allows for personalized spray patterns.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your shower head.

6.1 Cleaning Anti-Clog Nozzles

The shower heads are equipped with anti-clog nozzles designed to resist mineral buildup. If you notice reduced water flow or irregular spray patterns, mineral deposits may be present:

- Gently rub the rubber nozzles with your finger or a soft brush to dislodge any mineral deposits.
- For stubborn buildup, you can soak the shower head in a solution of white vinegar and water (1:1 ratio) for a few hours, then scrub and rinse thoroughly. Ensure the shower head is detached from the hose/mount before soaking.

6.2 General Cleaning

Clean the exterior surfaces with a soft cloth and mild soap and water. Rinse thoroughly and dry with a soft cloth. Avoid using abrasive cleaners, scouring pads, or chemicals containing ammonia or bleach, as these can damage the finish.

7. TROUBLESHOOTING

If you encounter issues with your shower head, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Low Water Pressure	Mineral buildup in nozzles; water restrictor; low household water pressure.	Clean anti-clog nozzles (Section 6.1). Ensure both shower heads are not running simultaneously if water pressure is inherently low. Check household water pressure.
Leaks at Connections	Loose connections; insufficient plumber's tape; missing or damaged washers.	Ensure all connections are hand-tight. Reapply plumber's tape. Check that washers are properly seated and undamaged. Avoid overtightening plastic components.
Irregular Spray Pattern	Clogged nozzles.	Clean anti-clog nozzles (Section 6.1).
Handheld Shower Head Does Not Stay in Holder	Improper seating; holder wear.	Ensure the handheld shower head is fully and correctly seated in the holder. If the issue persists, contact customer support.

8. SPECIFICATIONS

- **Brand:** BLACK+DECKER
- **Model:** BD0029
- **Style:** 5-Mode Dual
- **Shape:** Round
- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Finish Type:** Black
- **Installation Type:** Wall Mounted
- **Product Dimensions:** 11.2"L x 7"W
- **Number of Settings:** 5
- **Hose Length:** 60 Inches
- **Item Weight:** 2.3 pounds
- **UPC:** 840147846594

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact BLACK+DECKER customer service. Keep your purchase receipt as proof of purchase.

For further assistance, please visit the official BLACK+DECKER website or contact their customer support line.