

P47 Model 100

P47 Headset 5.0 EDR Bluetooth Wireless Headset User Manual

Model: P47 Model 100

INTRODUCTION

Thank you for choosing the P47 Headset. This manual provides detailed instructions for setting up, operating, and maintaining your new wireless headset. Designed for comfort and versatility, the P47 Headset offers a seamless audio experience for various activities including calling, gaming, and music listening.

The P47 Headset features a portable folding design, skin-friendly high-protein leather earmuffs for comfortable wear, and an adjustable head beam. It supports Bluetooth 5.0 EDR connectivity, making it compatible with a wide range of devices including Apple and Android phones, tablets, and computers.

PACKAGE CONTENTS

Please verify that all items are present in your package:

- 1 x P47 Wireless Headset
- 1 x USB Charging Cable



Image: The P47 Wireless Headset, shown in white, alongside its packaging box and the included USB charging cable.

SETUP

1. Charging the Headset

Before first use, fully charge the headset. Connect the supplied USB charging cable to the charging port on the headset and the other end to a USB power source (e.g., computer USB port, USB wall adapter).

- The indicator light will typically turn red during charging and turn off or change color when fully charged.
- Charging time is approximately 2-3 hours.

2. Powering On/Off

- **To Power On:** Press and hold the Power button (usually marked with a power icon) for a few seconds until the indicator light flashes.
- **To Power Off:** Press and hold the Power button again for a few seconds until the indicator light turns off.

3. Bluetooth Pairing

To connect your P47 Headset to a device:

1. Ensure the headset is powered off.
2. Press and hold the Power button for approximately 5-7 seconds until the indicator light flashes red and blue alternately. This indicates pairing mode.
3. On your device (phone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "P47" or "P47 Headset" from the list of found devices.
5. Once connected, the indicator light on the headset will typically flash blue slowly or turn solid blue.
6. If prompted for a password, enter "0000".



Image: A side view of the P47 Wireless Headset in white, illustrating its over-ear design and ear cup.

OPERATING INSTRUCTIONS

Controls Overview

The P47 Headset features intuitive controls located on the ear cup. Refer to the diagram below for button functions (if available on your model):



Image: The P47 Wireless Headset in white, with its control panel visible on the side of the ear cup, showing buttons for volume, track control, and power.

- **Power Button (On/Off/Pairing):** Long press to power on/off. Long press in off state to enter pairing mode.
- **Volume Up (+):** Short press to increase volume.
- **Volume Down (-):** Short press to decrease volume.
- **Next Track (>>|):** Long press Volume Up (+) to skip to the next track.
- **Previous Track (|<<):** Long press Volume Down (-) to go to the previous track.
- **Play/Pause/Call Button (M or Phone Icon):**
 - Short press to play/pause music.
 - Short press to answer/end a call.
 - Long press to reject an incoming call.
 - Double press to redial the last number.

Adjusting the Headset

The P47 Headset features an adjustable head beam and foldable ear cups for a comfortable and portable experience.

- **Head Beam Adjustment:** Gently extend or retract the headband on both sides to fit your head comfortably.
- **Folding Design:** The ear cups can be folded inwards for compact storage and portability.



Image: The P47 Wireless Headset in black, shown in its folded configuration, highlighting its portable design.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your P47 Headset.

- **Cleaning:** Use a soft, dry cloth to wipe the headset. Do not use abrasive cleaners, alcohol, or solvents.
- **Storage:** When not in use, store the headset in a cool, dry place, away from direct sunlight and extreme temperatures. The folding design allows for compact storage.

- **Avoid Moisture:** Do not expose the headset to water or excessive moisture. It is not waterproof.
- **Handle with Care:** Avoid dropping the headset or subjecting it to strong impacts.
- **Charging:** Always use the provided USB charging cable or a certified equivalent. Do not overcharge the battery.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Headset does not power on.	Battery is low or depleted.	Charge the headset fully using the supplied USB cable.
Cannot pair with device.	Headset not in pairing mode; Bluetooth off on device; device too far.	Ensure headset is in pairing mode (flashing red/blue). Turn on Bluetooth on your device. Move headset closer to device (within 10 meters).
No sound or low volume.	Volume too low on headset or device; headset not connected properly.	Increase volume on both headset and connected device. Repair the headset with your device.
Sound distortion or intermittent connection.	Interference; device too far; low battery.	Move away from sources of interference (Wi-Fi routers, other Bluetooth devices). Ensure headset is within range. Charge the headset.

SPECIFICATIONS

Feature	Detail
Model Name	P47
Item Model Number	100
Brand	Generic
Connectivity Technology	Bluetooth
Bluetooth Version	5.0
Wireless Communication Technology	Bluetooth
Ear Placement	Over Ear
Form Factor	Over Ear
Noise Control	Sound Isolation
Impedance	10 Ohm
Material	Plastic
Item Weight	4.6 ounces
Package Dimensions	6.5 x 4.25 x 2.5 inches
Included Components	1*Headset, 1*Usb charging

Feature	Detail
Recommended Uses	Calling, Cycling, Exercising, Gaming, Music
Compatible Devices	All Bluetooth-enabled devices

WARRANTY INFORMATION

This product is manufactured by Generic. For specific warranty details, please refer to the documentation provided at the time of purchase or contact the seller directly. Typically, electronic products come with a limited manufacturer's warranty covering defects in materials and workmanship under normal use.

Please retain your proof of purchase for any warranty claims.

SUPPORT

If you encounter any issues not covered in the troubleshooting section or require further assistance, please contact your retailer or the manufacturer's customer support. For the Generic P47 Headset, support is typically provided by the seller through the platform where the purchase was made.

You may also refer to the product page on the retailer's website for frequently asked questions or additional resources.

For online support, visit: [Amazon Product Page](#)