truke F40+

truke Buds Elite True Wireless Earbuds User Manual

Model: F40+

Introduction

Welcome to the user manual for your truke Buds Elite True Wireless Earbuds. This guide provides detailed instructions on how to set up, operate, maintain, and troubleshoot your earbuds, ensuring you get the most out of their advanced features.



Image: truke Buds Elite earbuds resting inside their open charging case, showcasing the sleek black design.



Image: A visual summary of the truke Buds Elite's key features, including extended playtime, powerful drivers, noise cancellation, low latency, and water resistance.

The truke Buds Elite are designed to deliver immersive sound with 10mm dynamic drivers, crystal-clear calls thanks to Dual-MIC ENC, and an ultra-low latency gaming mode. With up to 70 hours of total playtime and IPX5 water resistance, they are built for durability and convenience.

Setup Guide

1. Initial Charging

Before first use, it is recommended to fully charge both the earbuds and the charging case. This ensures optimal battery performance.

- Connect the charging case to a power source using the provided USB Type-C cable.
- The indicator light on the case will illuminate to show charging status.
- A full charge provides up to 70 hours of total playtime with the charging case.

- For quick power, a 10-minute charge can provide up to 10 hours of playback.



Image: The truke Buds Elite earbuds in their charging case, illustrating the extended 70-hour total playtime and the benefit of rapid charging.

2. Pairing with a Device

Follow these steps to pair your truke Buds Elite with your Bluetooth-enabled device:

1. Open the lid of the charging case. The earbuds will automatically power on and enter pairing mode, indicated by a flashing light on the earbuds.
2. On your smartphone, tablet, or laptop, navigate to the Bluetooth settings.
3. Ensure Bluetooth is enabled.
4. Search for "truke Buds Elite" in the list of available devices and select it to connect.
5. Once connected, a voice prompt will confirm successful pairing.
6. For future use, the earbuds will automatically connect to the last paired device when removed from the case, provided Bluetooth is enabled on the device.

The earbuds utilize Bluetooth 5.4 technology for a stable and efficient wireless connection.

Operating Instructions

Touch Controls

The truke Buds Elite feature responsive touch controls on each earbud. Refer to the table below for common functions:

Function	Action
Play/Pause Music	Single tap on either earbud
Next Track	Double tap on the Right earbud
Previous Track	Double tap on the Left earbud
Volume Up	Long press (3 seconds) on the Right earbud
Volume Down	Long press (3 seconds) on the Left earbud
Answer/End Call	Single tap on either earbud
Reject Call	Long press on either earbud
Activate Voice Assistant	Triple tap on either earbud
Toggle Gaming Mode	Triple tap on the Right earbud



Image: A detailed view of the truke Buds Elite earbud, highlighting the touch control area and illustrating the long press actions for volume adjustment.

Gaming Mode

Activate the dedicated gaming mode for an ultra-responsive audio experience with a low latency of 40ms, ideal for competitive gaming.

- To activate Gaming Mode: Triple tap the Right earbud.
- To deactivate Gaming Mode: Triple tap the Right earbud again.



Image: truke Buds Elite earbuds floating above a smartphone displaying a racing game, emphasizing the 40ms ultra-low latency gaming mode for synchronized audio.

Environmental Noise Cancellation (ENC)

The Dual-MIC PureVoice ENC technology in your truke Buds Elite effectively reduces ambient noise, ensuring your voice is clear during calls, even in busy environments.



Image: A man wearing truke Buds Elite earbuds while on a call, with a visual representation of environmental noise cancellation ensuring clear voice transmission.

Maintenance

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents, as these can damage the product.
- Gently remove any earwax or debris from the ear tips and speaker mesh using a small, soft brush or cotton swab.

Storage

- Always store the earbuds in their charging case when not in use. This protects them from damage and keeps them charged.
- Avoid storing the earbuds in extreme temperatures (above 45°C or below 0°C) or in highly humid environments.

Water Resistance (IPX5)

The truke Buds Elite are rated IPX5 water and sweat resistant. This means they are protected against low-pressure water jets from any direction. They are suitable for workouts, light rain, and daily activities where they might be exposed to sweat or splashes.

- Do not submerge the earbuds in water.
- Do not expose them to high-pressure water jets or steam.
- Ensure the earbuds are completely dry before placing them back into the charging case to prevent damage to the charging contacts.



Image: A person engaged in outdoor exercise, demonstrating the IPX5 water and sweat resistance of the earbuds, making them suitable for active lifestyles.

Troubleshooting

If you encounter any issues with your truke Buds Elite, refer to the following common problems and their solutions:

Problem	Possible Solution
Earbuds not pairing or connecting	• Ensure both earbuds are sufficiently charged. • Place earbuds back in the case, close the lid, wait 5 seconds, then open it again to re-enter pairing mode. • Turn off and then turn on Bluetooth on your device. • On your device, "forget" or "unpair" "truke Buds Elite" from your Bluetooth settings, then try pairing again from scratch. • Ensure no other Bluetooth devices are interfering with the connection.
No sound from one earbud	• Ensure both earbuds are charged. • Place both earbuds back in the charging case, close the lid, wait a few seconds, then open it again. This often re-syncs them. • Clean the charging contacts on both the earbuds and inside the case. • If the issue persists, try resetting the earbuds (refer to the truke support website for specific reset procedures if a simple re-pairing doesn't work).

Problem	Possible Solution
Low volume or poor sound quality	• Adjust the volume on both your connected device and using the earbud touch controls. • Ensure the ear tips are clean and properly seated in your ears to create a good seal, which is crucial for sound quality. • Check for any obstructions in the speaker mesh of the earbuds. • Try different sized ear tips for a better fit.
Charging case not charging	• Ensure the charging cable is securely connected to both the case and the power source. • Try a different USB Type-C cable and a different power adapter (e.g., a wall charger). • Check the charging port on the case for any debris or damage.

Technical Specifications

Detailed specifications for the truke Buds Elite True Wireless Earbuds:

Feature	Detail
Model Name	Buds Elite
Model Number	F40+
Connectivity Technology	Wireless
Wireless Communication	Bluetooth 5.4
Audio Driver Type	10mm Dynamic Driver
Total Playtime	Up to 70 Hours (with charging case)
Single Charge Playtime	Up to 10 Hours
Fast Charging	10 minutes charge for 10 hours playback
Microphone	Dual Mic with PureVoice ENC
Low Latency Gaming Mode	40ms
Control Method	Touch
Water Resistance Rating	IPX5 (Water and Sweat Resistant)
Item Weight	38 Grams
Product Dimensions	5.8 x 2.6 x 4.7 cm
Included Components	Wireless Charging Case
Compatible Devices	Cellphones, Desktops, Gaming Consoles, Laptops, Tablets

Warranty and Support

Your truke Buds Elite come with a 1-year service warranty, providing assurance and support for your product.

- **Warranty Period:** 1 Year from the date of purchase.
- **Service Points:** truke offers support through over 400 service points.
- **Claim Process:** Please retain your original purchase receipt as proof of purchase for any warranty claims.
- **Contact Support:** For detailed warranty terms and conditions, or to locate the nearest service center, please visit the official truke website or contact their customer support directly.




Image: A graphic highlighting the extensive service network and 1-year service warranty provided for truke Buds Elite.

Important Safety Information

- Always use certified charging cables and adapters to prevent damage and ensure safety.
- Avoid exposing the earbuds and charging case to extreme temperatures (hot or cold), direct sunlight, or high humidity for prolonged periods.
- Do not attempt to disassemble, repair, or modify the product yourself. This will void the warranty and may cause damage or

injury.

- Keep the product and its accessories out of reach of children and pets to prevent accidental ingestion or injury.
- Avoid using the earbuds at excessively high volumes for extended periods to prevent hearing damage.

© 2025 truke. All rights reserved.

For more information and support, please visit the official truke Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question