

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Motorola](#) /

› [Motorola Edge+ \(2022\) Smartphone User Manual](#)

## Motorola XT2201-3

# Motorola Edge+ (2022) User Manual

Model: XT2201-3

## INTRODUCTION

---

This manual provides essential information for the safe and efficient operation of your Motorola Edge+ (2022) smartphone. Please read this manual thoroughly before using your device to ensure proper handling and to maximize its features.



**Figure 1:** Motorola Edge+ (2022) smartphone, showcasing its front display with time and date, and its rear camera module and Motorola logo. The device is in Cosmos Blue.

## SAFETY INFORMATION

Always follow basic safety precautions to reduce the risk of injury, electric shock, fire, or damage to the device. Keep the device away from extreme temperatures, direct sunlight, and liquids. Do not attempt to disassemble or repair the device yourself.

- **Battery Safety:** The device contains a non-removable 4800mAh battery. Do not expose the battery to high temperatures or dispose of it in fire.
- **Charging:** Use only approved chargers and cables. Unapproved accessories may damage the device or cause safety hazards.
- **Hearing Protection:** Avoid prolonged listening at high volume levels to prevent hearing damage.
- **Driving Safety:** Do not use your phone while driving. Always prioritize safe driving practices.

# SETUP

---

## 1. Unboxing and Initial Inspection

Carefully remove all components from the packaging. Verify that all items listed in the "What's in the Box" section are present. Inspect the device for any physical damage before proceeding.

- **Included Items:** USB Cable.

## 2. Inserting the SIM Card

The Motorola Edge+ (2022) supports a single SIM card. Locate the SIM tray on the side of the device. Use the SIM ejector tool (if provided, otherwise a small paperclip) to open the tray. Place your Nano-SIM card into the tray with the gold contacts facing down, then gently push the tray back into the slot until it clicks into place.

## 3. Initial Power On and Setup Wizard

Press and hold the Power button (located on the right side of the device) until the Motorola logo appears. Follow the on-screen instructions to complete the initial setup, which includes selecting your language, connecting to Wi-Fi, signing in to your Google account, and setting up security features.

# OPERATING YOUR DEVICE

---

## 1. Navigating the Android Interface

Your Motorola Edge+ (2022) runs on Android 12.0 (upgradable to Android 13, planned upgrade to Android 14). Familiarize yourself with gestures for navigation: swipe up for app drawer, swipe down for notifications and quick settings, and use the navigation bar or gestures for Home, Back, and Recent Apps.

## 2. Camera Features

The device features a versatile camera system:

- **Rear Camera:** 50MP (wide) + 50MP (ultrawide) + 2MP (depth). Supports 4K Video Recording.
- **Front Camera:** 60MP (wide).

Open the Camera app to access various modes like Photo, Video, Portrait, Night Vision, and Pro mode. Tap to focus, pinch to zoom, and use the shutter button to capture images or start/stop video recording.

## 3. Connectivity

The device supports various connectivity options:

- **Wi-Fi:** Connect to wireless networks for internet access.
- **Bluetooth:** Pair with Bluetooth-enabled devices like headphones or speakers.
- **5G Cellular:** Utilize high-speed 5G networks for mobile data.
- **Built-In GPS:** For location services and navigation.

Access these settings via the Quick Settings panel (swipe down from the top of the screen) or through the main Settings app.

# MAINTENANCE

---

## 1. Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. Go to *Settings > System > System updates*

## 2. Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of the phone. Avoid using harsh chemicals or abrasive materials. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner designed for electronics.

## 3. Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Charge your device using the provided USB cable and a compatible charger. Optimal charging occurs between 20% and 80% battery level.

## TROUBLESHOOTING

### 1. Device Not Powering On

Ensure the battery is charged. Connect the device to a charger and wait a few minutes before attempting to power it on again. If the issue persists, perform a forced restart by holding the Power button for approximately 10-15 seconds.

### 2. Apps Crashing or Freezing

Try force-closing the problematic app (*Settings > Apps > See all apps > [App Name] > Force stop*). Clear the app's cache (*Storage & cache > Clear cache*). If the issue continues, consider uninstalling and reinstalling the app.

### 3. Connectivity Issues (Wi-Fi/Bluetooth/Cellular)

Toggle the respective connectivity option off and on. Restart your device. For Wi-Fi, try forgetting the network and reconnecting. For cellular, ensure your SIM card is properly inserted and your mobile data is enabled.

## SPECIFICATIONS

Feature	Detail
Model Name	Motorola Edge Plus 2022
Model Number	XT2201-3
Display	6.7" FHD+, 2400x1080px, OLED 10-bit, DCI-P3, 144Hz, HDR10+
Processor	Qualcomm SM8450 Snapdragon 8 Gen 1 (4nm) Octa-core
RAM	8GB
Storage	512GB
Rear Camera	50MP (wide) + 50MP (ultrawide) + 2MP (depth)
Front Camera	60MP (wide)
Battery	4800mAh
Operating System	Android 12 (upgradable to Android 13, planned upgrade to Android 14)
Connectivity	5G, Wi-Fi, Bluetooth, Built-In GPS
Dimensions	6 x 4 x 2 inches

Item Weight	14.9 ounces
Color	Cosmos Blue

## WARRANTY AND SUPPORT

---

This product is sold as a renewed item. According to the product description, it is "professionally inspected and tested to work and look like new" by Amazon-qualified suppliers. If not satisfied with the purchase, renewed products are eligible for replacement or refund under the Amazon Renewed Guarantee.

Please note that this is a "Discontinued US Model" and is "no longer covered by Manufacturer's Warranty." However, the item is still covered under the Return policy. Terms and conditions apply.

For support regarding your renewed device, please refer to the Amazon Renewed Guarantee details or contact the seller, YY Wireless, directly through Amazon's platform.

**Amazon Renewed Guarantee:** [Visit the Amazon Renewed Store](#)

**Seller Contact:** [YY Wireless Seller Information](#)