

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Vente-unique](#) /
- › [Vente-unique LUDIMA Nightstand Instruction Manual](#)

### Vente-unique LUDIMA

# Vente-unique LUDIMA Nightstand Instruction Manual

Model: LUDIMA | Brand: Vente-unique

## PRODUCT OVERVIEW

The Vente-unique LUDIMA Nightstand is a stylish and modern furniture piece designed to complement any bedroom decor. It features a single door with a push-to-open mechanism, offering convenient storage. The design incorporates linear reliefs on the front, adding a touch of originality while maintaining simplicity. This nightstand is constructed from MDF and melamine, ensuring durability and ease of maintenance.



Image 1: Front view of the Vente-unique LUDIMA Nightstand.

## SAFETY INFORMATION

---

- Always follow assembly instructions carefully.
- Do not exceed the maximum weight capacity of 10 kg for the top surface and 7 kg for the internal compartment.
- Keep small parts away from children during assembly to prevent choking hazards.
- Ensure the nightstand is placed on a flat, stable surface to prevent tipping.

## SETUP AND ASSEMBLY

---

The Vente-unique LUDIMA Nightstand requires assembly. Please ensure all parts are present before beginning.

### Package Contents

Verify that your package contains the following components:

- Top panel
- Bottom panel

- Side panels (2)
- Back panel
- Door panel
- Legs (2)
- Hardware pack (screws, dowels, hinges, push-to-open mechanism)

## Tools Required (Not Included)

- Phillips head screwdriver
- Hammer (optional, for dowels)

## Assembly Steps

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Identify each part using the provided diagram (if available, otherwise refer to the list above).
2. **Assemble the Main Frame:** Attach the side panels to the bottom panel using the provided screws and dowels. Ensure the pre-drilled holes align correctly.
3. **Attach the Top Panel:** Secure the top panel to the assembled side and bottom panels.
4. **Install the Back Panel:** Slide or screw the back panel into place.
5. **Attach the Legs:** Securely fasten the two legs to the underside of the nightstand using the designated hardware.
6. **Install the Door:** Attach the hinges to the door panel and then to the main frame. Adjust the hinges as needed for proper alignment.
7. **Install Push-to-Open Mechanism:** Mount the push-to-open mechanism inside the cabinet, ensuring it aligns with the door for smooth operation.




Image 2: Interior view of the nightstand, demonstrating the storage space and door hinges.

## OPERATING INSTRUCTIONS

---

### Using the Door

The LUDIMA Nightstand features a convenient push-to-open door mechanism.

- **To Open:** Gently press the center of the door. The door will spring open slightly, allowing you to pull it fully open.
- **To Close:** Push the door firmly until it clicks into place and remains closed.

### Weight Capacity

Observe the following weight limits to ensure the longevity and safety of your nightstand:

- **Top Surface:** Maximum 10 kg (22 lbs).
- **Internal Compartment:** Maximum 7 kg (15.4 lbs).

Distribute weight evenly to prevent stress on the structure.

## MAINTENANCE AND CARE

To keep your Vente-unique LUDIMA Nightstand in excellent condition, follow these simple care guidelines:

- Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the melamine finish.
- Spills:** Immediately wipe up any spills to prevent staining or damage to the material.
- Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration over time.
- Heat:** Do not place hot items directly on the surface. Use coasters or protective pads.
- Inspection:** Periodically check all screws and fittings to ensure they remain tight. Tighten if necessary.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Nightstand is wobbly.	Loose screws or uneven floor.	Check and tighten all assembly screws. Ensure the nightstand is on a level surface; use furniture pads if needed.
Door does not close properly.	Hinges are misaligned or push-to-open mechanism is not correctly installed/adjusted.	Adjust the door hinges. Ensure the push-to-open mechanism is securely mounted and aligned with the door.
Door does not open when pressed.	Push-to-open mechanism is faulty or misaligned.	Check the push-to-open mechanism for obstructions or damage. Realign or replace if necessary.
Scratches on surface.	Sharp objects or abrasive cleaning.	Use furniture polish or repair kits for minor scratches. Prevent future scratches by using coasters and avoiding abrasive materials.

## SPECIFICATIONS

Feature	Detail
Model	LUDIMA
Brand	Vente-unique
Color	Beige
Material	MDF, Melamine, Engineered Wood
Overall Dimensions (L x D x H)	50 cm x 36.8 cm x 46.1 cm (19.7 in x 14.5 in x 18.1 in)
Internal Compartment Dimensions (L x D x H)	49.3 cm x 31.7 cm x 33.2 cm (19.4 in x 12.5 in x 13.1 in)
Product Weight	11.9 kg (26.2 lbs)
Maximum Top Surface Load	10 kg (22 lbs)

Feature	Detail
Maximum Internal Compartment Load	7 kg (15.4 lbs)
Door Mechanism	Push-to-open
Assembly Required	Yes

## WARRANTY INFORMATION

---

Specific warranty details for the Vente-unique LUDIMA Nightstand are not provided in the product information. Please refer to your purchase documentation or contact the retailer directly for warranty terms and conditions.

## CUSTOMER SUPPORT

---

For further assistance, missing parts, or inquiries regarding your Vente-unique LUDIMA Nightstand, please contact your point of purchase or the Vente-unique customer service department.

You may find contact information on the Vente-unique website or your order confirmation.

© 2025 Vente-unique. All rights reserved.