

AVIOT TE-A1

AVIOT

AVIOT TE-A1 Hi-Res True Wireless Earbuds User Manual

Model: TE-A1

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your AVIOT TE-A1 Hi-Res True Wireless Earbuds. Please read this manual thoroughly before using the product and retain it for future reference.

Key Features:

- **High-Resolution Audio:** Supports LDAC for superior wireless audio quality.
- **Adaptive Noise Canceling:** Automatically adjusts to your environment.
- **3D Spatial Audio:** Immersive sound for movies, games, and music.
- **Comfortable Fit:** Unique nozzle design and medical-grade silicone ear tips.
- **IPX4 Water Resistance:** Resistant to sweat and splashes.
- **Extended Playback:** Up to 70 hours total battery life with charging case.
- **Wireless Charging & Multi-Point Support:** Convenient charging and seamless device switching.
- **Low Latency Mode:** Optimized for gaming and video content.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- AVIOT TE-A1 True Wireless Earbuds (Left and Right)
- Charging Case

- USB Type-C Charging Cable
- Ear Tips (Multiple Sizes: SS, S, M, L)
- User Manual (This document)




Image: AVIOT TE-A1 package contents, showing the earbuds, charging case, various ear tip sizes, and a USB Type-C charging cable.

3. SETUP

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case.

1. Place the earbuds into the charging case, ensuring they are correctly seated.
2. Connect the USB Type-C cable to the charging case and a power source, or place the charging case on a compatible wireless charging pad.
3. The indicator lights on the case will show the charging status. Once fully charged, the lights will indicate completion or turn off.

A full charge provides up to 70 hours of total playback time with the charging case.



Image: The AVIOT TE-A1 charging case being charged wirelessly on a charging pad, demonstrating cable-free convenience.

3.2 Pairing with a Device

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, PC), enable Bluetooth and search for available devices.
3. Select "AVIOT TE-A1" from the list of found devices to connect.
4. Once connected, a confirmation sound will play, and the indicator lights on the earbuds will change.

The TE-A1 supports **Multi-Point Connectivity**, allowing connection to two devices simultaneously for seamless audio switching.

3.3 Optimal Fit

Selecting the correct ear tip size is crucial for sound quality and noise cancellation.

1. Experiment with the included medical-grade silicone ear tips (SS, S, M, L) to find the size that provides a secure and comfortable seal in your ear canal.
2. Gently insert each earbud into your ear and twist slightly until it feels snug and stable.




Image: A selection of medical-grade silicone ear tips, highlighting the different sizes available to ensure a comfortable and secure fit for the AVIOT TE-A1 earbuds.

4. OPERATING INSTRUCTIONS

4.1 Touch Controls

The AVIOT TE-A1 earbuds feature high-sensitivity touch sensors for control. Specific functions can be customized via the dedicated AVIOT SOUND ME app.

- **Single Tap:** Play/Pause, Answer/End Call
- **Double Tap:** Next Track, Reject Call
- **Triple Tap:** Previous Track
- **Long Press:** Activate Voice Assistant, Toggle Noise Canceling/Ambient Mode

4.2 Audio Modes

- **Adaptive Noise Canceling:** Reduces ambient noise for an immersive listening experience. Activate via touch control or app.
- **Ambient Sound Mode:** Allows you to hear your surroundings while listening to audio. Activate

via touch control or app.

- **3D Spatial Audio:** Enhances audio with a three-dimensional soundstage. Enable through the AVIOT SOUND ME app.
- **Low Latency Mode (Gaming Mode):** Minimizes audio-visual delay, ideal for gaming and video. Enable through the AVIOT SOUND ME app.

4.3 AVIOT SOUND ME App

Download the dedicated AVIOT SOUND ME app for advanced customization and features:

- **Preset Tuning Options:** Adjust sound profiles (e.g., Bass Boost, Movie, ASMR, Live).
- **Custom Equalizer:** Fine-tune audio to your preference.
- **Touch Control Customization:** Reassign touch functions.
- **Firmware Updates:** Keep your earbuds up-to-date.
- **Earbud Detection Feature:** Locate misplaced earbuds.




Image: The AVIOT SOUND ME app interface displaying various preset tuning options such as Bypass, Custom1, Custom2, Bass Boost, Mid Boost, Treble Boost, ASMR, Movie, and Live.

5. MAINTENANCE

5.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Ensure charging contacts on both earbuds and case are free of debris.

5.2 Water Resistance

The AVIOT TE-A1 earbuds are rated **IPX4**, meaning they are resistant to splashing water from any direction. This makes them suitable for workouts and light rain.

- Do not submerge the earbuds in water.
- The charging case is not water-resistant.
- If earbuds get wet, wipe them dry completely before placing them back in the charging case.

6. TROUBLESHOOTING

6.1 Pairing Issues

- **Earbuds not connecting:** Ensure earbuds are charged and within range of your device. Turn Bluetooth off and on again on your device.
- **Only one earbud playing:** Place both earbuds back in the case, close it, wait a few seconds, then open it again. This often re-syncs them.
- **Cannot find "AVIOT TE-A1" in Bluetooth list:** Ensure earbuds are in pairing mode (indicator lights flashing). If previously paired, try forgetting the device on your phone and re-pairing.

6.2 Sound Quality Issues

- **Low volume or poor bass:** Check ear tip fit. A proper seal is essential for optimal sound. Try different ear tip sizes.
- **Intermittent audio:** Ensure no obstructions between earbuds and device. Move closer to your device. Avoid environments with strong Wi-Fi or other wireless interference.
- **Distorted sound:** Reduce volume on your device or through the app. Ensure earbuds are fully charged.

6.3 Charging Issues

- **Earbuds not charging in case:** Ensure earbuds are correctly seated and charging contacts are clean.
- **Case not charging:** Try a different USB-C cable or power adapter. Ensure wireless charging pad is compatible and correctly aligned.

7. SPECIFICATIONS

Feature	Specification
Model Name	TE-A1
Connectivity Technology	Wireless
Wireless Communication	Bluetooth 5.3
Audio Driver Type	Dynamic Driver
Noise Control	Adaptive Noise Cancellation
Control Method	Touch
Battery Life (Earbuds)	Up to 10 hours
Battery Life (with Case)	Up to 70 hours

Water Resistance Level	IPX4 (Earbuds only)
Item Weight	145 Grams (Total) / 5.1 ounces
Manufacturer	AVIOT

8. WARRANTY AND SUPPORT

Warranty information for your AVIOT TE-A1 earbuds is typically provided with the product packaging or can be found on the official AVIOT website. Please refer to these resources for details regarding warranty coverage and terms.

For further assistance, technical support, or inquiries, please visit the official AVIOT support channels or their brand store:

[Visit the AVIOT Store on Amazon](#)