Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

QCY QCYT31-01

QCY T31 Melobuds Neo User Manual

Model: QCYT31-01

Introduction

The QCY MeloBuds Neo (T31) are advanced wireless earbuds designed to deliver a unique audio experience. Featuring a transparent charging case with an integrated LED digital display, these earbuds combine modern design with practical functionality. They offer impressive sound quality through 10mm drivers, customizable audio with 9 equalization settings, and extended battery life. Equipped with 4 integrated microphones and wind noise reduction technology, the MeloBuds Neo ensure clear calls. Multi-point connectivity allows seamless switching between two devices.

Package Contents

- QCY T31 Melobuds Neo Earbuds
- Charging Case
- Ear Cushions (various sizes)
- Charging Cable
- User Manual

Setup

1. Initial Charging

Before first use, fully charge the QCY T31 Melobuds Neo and their charging case. Place the earbuds into the charging case. Connect the charging cable to the case and a power source. The LED digital display on the case will indicate the charging status. A full charge provides up to 24 hours of total playback with the case, and up to 7 hours for the earbuds alone.



Image: QCY T31 Melobuds Neo earbuds inside their transparent charging case, displaying the digital LED battery indicator. This image illustrates the product's design and the battery display feature.

2. Pairing with a Device

1. Ensure the earbuds are in the charging case and the lid is open.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available Bluetooth devices. Select "QCY T31 Melobuds Neo" from the list.
4. Once connected, a confirmation sound will play, and the earbuds will be ready for use.

3. Multi-Point Connection

The QCY T31 Melobuds Neo support multi-point connection, allowing you to connect to two devices simultaneously. After pairing with the first device, disable Bluetooth on that device. Pair the earbuds with the second device. Once paired, re-enable Bluetooth on the first device. The earbuds will automatically connect to both, allowing seamless switching between audio sources.

Operating Instructions

Touch Controls

The QCY T31 Melobuds Neo feature intuitive touch controls on each earbud. Specific functions can be customized via the QCY application.

Action	Function

Action	Function
Single Tap	Play/Pause, Answer Call
Double Tap (Left/Right)	Next Track / Previous Track (customizable)
Triple Tap	Activate Voice Assistant
Long Press (1.5s)	Reject Call
Long Press (2s)	Toggle Noise Control (if applicable)

Sound Customization

Utilize the official QCY application to access 9 studio-level equalization settings. This allows for personalized audio profiles to match your listening preferences.

Call Management

The 4 integrated microphones with wind noise reduction technology ensure clear voice pickup during calls, even in noisy environments.

Maintenance

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear cushions and clean them separately with mild soap and water if necessary, ensuring they are completely dry before reattaching.
- Do not use abrasive cleaners or solvents.

Storage

When not in use, store the earbuds in their charging case to protect them and ensure they remain charged. Store in a cool, dry place away from direct sunlight and extreme temperatures.

Water Resistance

The QCY T31 Melobuds Neo are water-resistant. This means they can withstand splashes and sweat, making them suitable for workouts. However, they are not designed for swimming or submersion in water. Avoid exposing them to high-pressure water or prolonged contact with water.

Troubleshooting

Earbuds Not Pairing

- Ensure both earbuds are charged.
- Turn off and on Bluetooth on your device.
- Forget the device from your Bluetooth list and try pairing again.
- Reset the earbuds (refer to the QCY app or manufacturer's website for specific reset instructions).

No Sound or Low Volume

- Check the volume level on both your device and the earbuds.
- Ensure the earbuds are properly seated in your ears.
- Clean any debris from the earbud nozzles.

- Reconnect the earbuds to your device.

Charging Issues

- Ensure the charging cable is securely connected to both the case and the power source.
- Verify the power source is active.
- Clean the charging contacts on both the earbuds and the case.
- Try a different charging cable or power adapter.

Specifications

Feature	Detail
Model Name	QCYT31-01
Connectivity Technology	Wireless (Bluetooth)
Noise Control	Sound Isolation
Driver Size	10mm
Microphones	4 integrated with wind noise reduction
Battery Life (Earbuds)	Up to 7 hours continuous playback
Total Playback Time (with Case)	Up to 24 hours
Charging Case Display	LED Digital Display
Equalization Settings	9 studio-level presets via QCY app
Water Resistance Level	Water Resistant (splashes and sweat)
Material	Plastic
Impedance	140 Ohm
Battery Composition	Lithium-ion

Warranty and Support

Warranty Information

The QCY T31 Melobuds Neo come with a 1-year manufacturer's warranty. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For further assistance, technical support, or warranty inquiries, please visit the official QCY website or contact their customer service department. Refer to the product packaging or the QCY website for the most up-to-date contact information.
You can also visit the QCY Store on Amazon for more product information and support resources.

© 2024 QCY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DVVVG9SF

More documents and user manuals: **https://manuals.plus/**