Ingersoll I14504

Ingersoll Ollie Automatic Black Dial Analog Watch - Model I14504 User Manual

Introduction

Thank you for choosing the Ingersoll Ollie Automatic Black Dial Analog Watch, Model I14504. This manual provides essential information for the proper setup, operation, maintenance, and care of your timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.



Image: Close-up of the Ingersoll Ollie watch dial, highlighting the automatic skeleton movement.

Setup

Initial Winding

Your Ingersoll Ollie watch is equipped with an automatic mechanical movement. It does not require a battery. Before wearing for the first time, or if the watch has stopped due to lack of movement, it needs to be manually wound. To do this, rotate the crown (located on the side of the watch case) clockwise approximately 20-30 times while it is in its normal, pushed-in position. This will build up an initial power reserve.

Setting the Time

1. Gently pull the crown outwards to the first position.
2. Rotate the crown either clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its normal, pushed-in position to engage the movement and start the

watch.



Image: Side view of the watch, illustrating the crown for winding and time adjustment.

Operating Your Watch

Automatic Movement Functionality

The automatic movement in your Ingersoll Ollie watch is powered by the natural motion of your wrist. As you wear the watch, an oscillating weight inside the movement rotates, winding the mainspring and storing energy. If the watch is worn daily for at least 8-10 hours, it should maintain its power reserve. If the watch is not worn for an extended period (typically 36-40 hours), it will stop and require manual winding and time setting as described in the 'Setup' section.

Wearing the Watch

Ensure the watch is worn comfortably on your wrist, not too tight or too loose, to allow for proper automatic winding. The black leather strap features a buckle clasp for secure fastening.



Image: Detail of the watch's black leather strap and buckle clasp.

Maintenance and Care

Cleaning

To maintain the appearance of your watch, regularly clean the dial and case with a soft, dry cotton cloth. Avoid using harsh chemicals or abrasive materials, which can damage the finish or glass.

Water Resistance

Your Ingersoll Ollie watch has a water resistance rating of 50 meters (5 ATM). This means it is suitable for everyday use and can withstand splashes, rain, and brief immersion in water. However, it is **not** suitable for swimming, showering, diving, or any water sports. Always ensure the crown is fully pushed in before any contact with water.

Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong

magnetic fields. A watch box or pouch is recommended to protect it from dust and scratches.

Troubleshooting

Watch Not Running

- **Insufficient Power Reserve:** As an automatic watch, it relies on wrist movement. If the watch has stopped, manually wind it by rotating the crown clockwise 20-30 times.
- **Lack of Wear:** If the watch is not worn for an extended period, it will stop. Wear it regularly or manually wind it.

Time Inaccuracy

- **Magnetic Fields:** Exposure to strong magnetic fields (e.g., from speakers, refrigerators, or certain electronic devices) can affect the watch's accuracy. If you suspect this, consult a professional watchmaker for demagnetization.
- **Impact:** A severe impact can affect the delicate internal components.
- **Service Interval:** Mechanical watches benefit from periodic servicing (typically every 3-5 years) to maintain accuracy and performance.

Specifications

Feature	Detail
Model Name	Ollie
Model Number	I14504
Case Diameter	45 mm
Case Thickness	13.7 mm
Strap Width	23 mm
Case Material	Stainless Steel
Strap Material	Leather
Glass Material	Mineral Glass
Movement Type	Automatic
Display Type	Analog
Water Resistance Depth	50 Metres (5 ATM)
Case Shape	Square
Dial Colour	Black
Face Style	Skeleton
Item Weight	200 Grams

Product Dimensions (LxWxH)	21 x 4.5 x 1.4 Centimeters



Image: Rear view of the watch, displaying the automatic movement through the transparent case back.

Warranty

Your Ingersoll Ollie Automatic Watch, Model I14504, comes with a**Lifetime Warranty** from the manufacturer. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for any warranty claims. For specific terms and conditions, please refer to the official Ingersoll warranty documentation or contact customer support.

Support

For further assistance, service, or warranty inquiries, please contact the manufacturer or authorized importer:

- **Manufacturer:** Ingersoll (Zeon Far East Limited, Kwai Chung, N.T, Hong Kong)
- **Importer/Packer:** Designer World Brands LLP, Pinnacle Business Park, First Floor, Next to Ahura Centre, Mahakali Caves Road, Andheri East, Mumbai - 400096

Please have your watch model number (I14504) and purchase details ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question