

[manuals.plus](#) /

› [Zeegma](#) /

› [Zeegma ZONDER Pro Aqua Wet and Dry Vacuum Cleaner Instruction Manual](#)

Zeegma ZONDER Pro Aqua

Zeegma ZONDER Pro Aqua Wet and Dry Vacuum Cleaner Instruction Manual

Model: ZONDER Pro Aqua

INTRODUCTION

The Zeegma ZONDER Pro Aqua is a versatile 1400W wet and dry vacuum cleaner designed for comprehensive cleaning tasks. It combines dry vacuuming, wet vacuuming, and extraction functions, making it suitable for various surfaces including floors, carpets, upholstery, and vehicle interiors. This manual provides essential information for the safe and efficient use, maintenance, and troubleshooting of your appliance.

1. SETUP AND ASSEMBLY

Before first use, ensure all components are present and correctly assembled.

- 1. Unpacking:** Carefully remove all parts from the packaging.
- 2. Wheel Installation:** Attach the four swivel wheels to the base of the vacuum cleaner for mobility.
- 3. Hose Connection:** Connect the flexible suction hose to the designated inlet port on the main unit. Ensure a secure fit.
- 4. Accessory Attachment:** Select the appropriate nozzle for your cleaning task and attach it to the end of the suction hose or extension tube. The kit includes nozzles for upholstery, floors, and crevices.
- 5. Filter Installation:** For dry vacuuming, ensure the HEPA filter is securely in place. For wet vacuuming, the foam filter should be used to protect the motor from moisture.
- 6. Water Tank Preparation (for wet cleaning):** Fill the 4-liter clean water tank with water and an appropriate cleaning solution, if desired. The 20-liter metallic tank is for dirty water collection.



Image 1: The Zeegma ZONDER Pro Aqua wet and dry vacuum cleaner with its included accessories, such as the floor nozzle, crevice tool, and spray/extraction nozzles.

Zonder Pro Aqua



- ALCANCE DE TRABAJO 13 M
- COMPLETO JUEGO DE ACCESORIOS

Image 2: A detailed view of the various nozzles and attachments provided with the Zeegma ZONDER Pro Aqua, including specialized tools for different cleaning applications.

2. OPERATING INSTRUCTIONS

2.1. Dry Vacuuming

1. Ensure the HEPA filter is installed and the foam filter is removed.
2. Connect the desired dry vacuuming nozzle (e.g., floor brush, crevice tool).
3. Plug the power cord into a suitable electrical outlet.
4. Turn on the vacuum cleaner using the power switch.
5. Vacuum the desired surface.

Zonder Pro Aqua



- 4 RUEDAS GIRATORIAS
- ASA PRÁCTICA

Image 3: A user demonstrating dry vacuuming on a carpet using the Zeegma ZONDER Pro Aqua, highlighting its capability for general floor cleaning.

2.2. Wet Vacuuming and Extraction

This function is ideal for deep cleaning carpets, rugs, and upholstery.

1. Ensure the foam filter is installed and the HEPA filter is removed.
2. Fill the 4-liter clean water tank with water and a suitable cleaning solution.
3. Attach the spray/extraction nozzle.
4. Plug in the vacuum cleaner and turn it on.
5. Press the spray button on the handle to dispense cleaning solution onto the surface.
6. Move the nozzle slowly over the wet area to extract the dirty water. The transparent nozzle allows real-time monitoring of the cleaning process.
7. Repeat as necessary until the surface is clean.



- MÉTODO DE EXTRACCIÓN
- ELIMINA ÁCAROS, MICROBIOS Y ALÉRGENOS

Image 4: A man using the Zeegma ZONDER Pro Aqua to clean a carpet, demonstrating the extraction method for deep cleaning.

Zonder Pro Aqua



- FUNCIÓN DE SOPLADO**
- RECOLECCIÓN DE SUCIEDAD HÚMEDA**
- ASPIRACIÓN DE AGUA DE SUPERFICIES**

Image 5: An illustration highlighting the extraction method's effectiveness in removing mites, microbes, and allergens from surfaces.

2.3. Blowing Function

The blowing function can be used to remove dirt from hard-to-reach areas or to accelerate the drying of surfaces after wet cleaning.

1. Connect the hose to the exhaust port of the vacuum cleaner.
2. Turn on the vacuum cleaner.
3. Direct the airflow to the desired area.

Zonder Pro Aqua



POSIBILIDAD DE LIMPIEZA EN SECO

Image 6: A visual representation of the blowing function and the process of wet dirt collection, demonstrating the versatility of the appliance.

3. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your Zeegma ZONDER Pro Aqua.

- 1. Emptying the Dirty Water Tank:** After wet vacuuming, always empty the 20-liter metallic dirty water tank. Use the drain plug for easy emptying.
- 2. Cleaning the Metallic Tank:** After wet use, it is crucial to thoroughly dry the metallic tank to prevent rust and corrosion.
- 3. Filter Cleaning:**
 - HEPA Filter:** For dry use, regularly tap out dust or rinse with water if heavily soiled. Ensure it is completely dry before reinstallation.
 - Foam Filter:** For wet use, rinse the foam filter with water after each use and allow it to air dry completely.
- 4. Nozzle and Hose Cleaning:** Rinse all nozzles and the suction hose with clean water after wet use to prevent blockages and odors.

5. **Motor Protection:** The design includes features to protect the turbine and motor from moisture. Ensure filters are correctly installed for the chosen operation mode.



DEPÓSITO DE ACERO INOXIDABLE

Image 7: A user removing the filter from the Zeegma ZONDER Pro Aqua, illustrating a key step in routine maintenance.

Zonder Pro Aqua



■ PROTECCIÓN DE LA TURBINA Y EL MOTOR CONTRA LA HUMEDAD

Image 8: A user demonstrating how the vacuum cleaner's design protects the turbine and motor from moisture, emphasizing proper handling during wet operations.

4. TROUBLESHOOTING

If you encounter issues with your vacuum cleaner, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|----------------------------|--|--|
| No suction or weak suction | <ul style="list-style-type: none">Hose or nozzle blockageFull dirty water tankIncorrectly installed filterDamaged hose/seal | <ul style="list-style-type: none">Check and clear any blockages in the hose or nozzle.Empty the dirty water tank.Ensure the correct filter (HEPA for dry, foam for wet) is properly seated.Inspect hose and seals for damage; replace if necessary. |

| Problem | Possible Cause | Solution |
|--|--|---|
| Water not spraying (during extraction) | <ul style="list-style-type: none"> Empty clean water tank Clogged spray nozzle Pump malfunction | <ul style="list-style-type: none"> Refill the clean water tank. Clean the spray nozzle to remove any blockages. If the issue persists, contact customer support. |
| Vacuum cleaner does not turn on | <ul style="list-style-type: none"> No power supply Power switch fault | <ul style="list-style-type: none"> Check power cord connection and wall outlet. Ensure the power switch is fully engaged. |
| Unusual noise during operation | <ul style="list-style-type: none"> Foreign object in fan/motor Motor issue | <ul style="list-style-type: none"> Turn off and unplug the unit. Inspect for any foreign objects. If noise persists, discontinue use and contact customer support. |

5. SPECIFICATIONS

- Brand:** Zeegma
- Model Number:** ZE-ZONDER PRO AQUA SILVER
- Color:** Silver
- Product Dimensions:** 51 x 37 x 41 cm
- Weight:** 7.3 kg
- Power:** 1400 W
- Clean Water Tank Capacity:** 4 Liters
- Dirty Water Tank Capacity:** 20 Liters (Metallic)
- Noise Level:** 87 Decibels
- Special Features:** Wet and Dry Vacuuming, Anti-allergenic HEPA Filter, Blowing Function, Extraction Cleaning, Powerful 1400W Motor
- Filter Type:** HEPA Filter, Foam Filter
- Hose Length:** 350 cm
- Form Factor:** Canister




Image 9: A diagram illustrating the physical dimensions of the Zeegma ZONDER Pro Aqua vacuum cleaner (51 cm height, 37 cm depth, 41 cm width).

6. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the documentation included with your purchase or contact Zeegma customer service directly. Keep your proof of purchase for warranty claims.