

IBELL YO2800

IBELL YO2800 High Pressure Washer Instruction Manual

Model: YO2800

INTRODUCTION

Thank you for choosing the IBELL YO2800 High Pressure Washer. This manual provides essential information for the safe and efficient operation, assembly, and maintenance of your new pressure washer. Please read these instructions carefully before use and retain them for future reference.

IMPORTANT SAFETY INFORMATION

Always observe basic safety precautions to reduce the risk of fire, electric shock, and personal injury. This pressure washer generates high-pressure water streams, which can cause serious injury if not handled properly.

- **Electrical Safety:** Do not use the pressure washer near electrical outlets or power lines. Ensure all electrical connections are dry and protected from water.
- **Personal Protective Equipment:** Always wear appropriate eye protection, such as safety goggles, and protective clothing when operating the pressure washer.
- **Stable Surface:** Operate the pressure washer on a stable, level surface to prevent tipping.
- **Children and Pets:** Keep children and pets away from the operating area.
- **Water Source:** Ensure the water supply is clean and free of debris to prevent damage to the pump.
- **Pressure Release:** Always release residual pressure in the system before disconnecting hoses or accessories.

PACKAGE CONTENTS

Verify that all items are present in the package:

- IBELL YO2800 High Pressure Washer Unit
- 3-meter Inlet Pipe
- 8-meter Outlet Hose
- Spray Gun
- Spray Gun Extension Rod
- Inlet Filter
- Inlet Connector

- Tap Connector
- Bucket Water Filter
- Foam Spray Bottle



ACCESSORIES



3M INLET HOSE



8M OUTLET HOSE



INLET CONNECTOR



BUCKET FILTER



INLET FILTER



TAP CONNECTOR



FOAM BOTTLE



SPRAY GUN & NOZZLE

Figure 1: Included accessories for the IBELL YO2800 High Pressure Washer. This image displays the main unit alongside various components such as the 3M inlet hose, 8M outlet hose, inlet connector, bucket filter, inlet filter, tap connector, foam bottle, and spray gun with nozzle.

ASSEMBLY AND SETUP

Follow these steps to assemble your IBELL YO2800 High Pressure Washer:

1. **Connect Inlet Filter:** Screw the transparent inlet filter onto the main unit's water inlet.
2. **Attach Inlet Connector:** Attach the orange inlet connector to the inlet filter.
3. **Connect Inlet Pipe:** Connect the 3-meter inlet pipe to the inlet connector. If drawing water from a bucket, attach the bucket filter to the other end of the inlet pipe. If connecting to a tap, use the tap connector.
4. **Connect Outlet Hose:** Push and screw the 8-meter outlet hose into the high-pressure outlet on the main unit.

5. **Connect Spray Gun:** Attach the high-pressure outlet hose to the spray gun. Ensure it is securely tightened.
6. **Attach Extension Rod:** Connect the spray gun extension rod to the spray gun.
7. **Attach Nozzle:** Attach the desired nozzle to the spray gun extension rod.
8. **Purge Air:** Before turning on the machine, turn on the water supply and press the spray gun trigger to release any air from the system until a steady stream of water emerges.

HOW TO INSTALL



1. Attach inlet pipe to tap connector

Connect bucket filter if needed



2. Attach inlet pipe to inlet connector



3. Screw inlet filter onto main unit



4. Attach inlet connector to inlet filter



5. Push and screw the outlet hose pipe with the outlet connector



6. Turn ON machine without connecting hose pipe to gun to release air.



7. Attach outlet hose pipe to spray gun.



8. Connect spray gun extension rod to spray gun.



9. Attach nozzle to spraygun extension rod.



Connect : Water inlet quick connection link method



Wrong : There is a gap in the middle

Figure 2: Step-by-step visual guide for installing the IBELL YO2800 High Pressure Washer. This image illustrates connecting the inlet pipe to the tap connector or bucket filter, attaching the inlet connector and filter to the main unit, connecting the outlet hose, and assembling the spray gun with its extension rod and nozzle. It also shows a correct and incorrect water inlet quick connection method.

OPERATION

Once assembled and connected to a water source and power, your pressure washer is ready for use.

Starting the Unit

1. Ensure the water supply is fully open and all air has been purged from the system.

2. Plug the power cord into a suitable electrical outlet.
3. Turn on the power switch on the pressure washer unit. The motor will start.
4. Point the spray gun at the surface to be cleaned and press the trigger. The unit will deliver high-pressure water.


Adjustable Nozzle and Foam Bottle

The IBELL YO2800 features an adjustable nozzle and a foam spray bottle for versatile cleaning.

- **Adjustable Nozzle:** Rotate the nozzle head to change the spray pattern from a concentrated jet for tough stains to a wider fan spray for general cleaning.
- **Foam Spray Bottle:** Fill the foam bottle with appropriate cleaning detergent. Attach it to the spray gun for applying foam during cleaning tasks.



Figure 3: Illustration of the adjustable nozzle on the IBELL YO2800 High Pressure Washer, showing different spray patterns (low speed, medium speed, high speed) and the foam application method.



Experience the ,might of
2800 W and 240 Bar

Figure 4: A person demonstrating the use of the IBELL YO2800 High Pressure Washer for car cleaning, highlighting its powerful spray.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your pressure washer.

- **Clean Filters:** Regularly check and clean the inlet filter and bucket water filter to prevent debris from entering the pump.
- **Drain Water:** After each use, disconnect the water supply and run the machine for a few seconds to drain any remaining water from the pump and hoses. This prevents freezing damage in cold weather.
- **Store Properly:** Store the pressure washer in a dry, frost-free environment. Coil hoses neatly and store accessories in a safe place.
- **Check for Leaks:** Periodically inspect hoses, connections, and the spray gun for any signs of wear or leaks. Replace damaged parts immediately.

TROUBLESHOOTING

If you encounter issues with your pressure washer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No water pressure	Clogged inlet filter; Air in the pump; Insufficient water supply; Kinked hose	Clean inlet filter; Purge air from the system; Ensure adequate water flow; Straighten hose
Motor not starting	No power supply; Faulty power switch; Thermal overload activated	Check power connection; Inspect power switch; Allow motor to cool down
Water leaking from connections	Loose connections; Worn O-rings or seals; Damaged hose	Tighten all connections; Replace worn O-rings/seals; Replace damaged hose
Pulsating pressure	Air in the pump; Clogged nozzle; Insufficient water supply	Purge air; Clean nozzle; Ensure adequate water flow

SPECIFICATIONS

Key technical specifications for the IBELL YO2800 High Pressure Washer:

- **Model:** YO2800
- **Power Source:** Corded Electric
- **Motor Type:** Induction Motor
- **Power:** 2800W
- **Maximum Pressure:** 240 Bar
- **Maximum Flow Rate:** 12 Liters Per Minute
- **Hose Length:** 8 Meters (Outlet), 3 Meters (Inlet)
- **Item Weight:** 5 Kilograms
- **Product Dimensions:** 30L x 30W x 30H Centimeters
- **Tank Volume (Foam Bottle):** 350 Milliliters
- **Country of Origin:** China



IBELL YOVER YO2800
HIGH
PRESSURE
WASHER

POWER 2800 W	FLOW RATE 12 L / min	MAX PRESSURE 240 Bar	WEIGHT 5.0 kg	HOSE PIPE 8 M
Adjustable spray nozzle	Dual water intake method	Advanced total stop system	Powerfull induction motor	


Figure 5: Overview of the IBELL YO2800 High Pressure Washer, highlighting its key specifications such as 2800W power, 12 L/min flow rate, 240 Bar max pressure, 5.0 kg weight, and 8M hose pipe. It also mentions features like adjustable spray nozzle, dual water intake, advanced total stop system, and powerful induction motor.

DIMENSION



Figure 6: Dimensional view of the IBELL YO2800 High Pressure Washer, showing its approximate length, width, and height.


2800 Watts Motor & 240 Bar Pressure Water Flowing : 12 L / Min



HIGH SPEED



POWERFUL



LOWER NOISE




TSS

Figure 7: Internal view illustrating the 2800 Watts motor and 240 Bar pressure system of the IBELL YO2800, with a water flow rate of 12 L/Min. Key features like high speed, powerful operation, lower noise, and Total Stop System (TSS) are highlighted.

WARRANTY AND SUPPORT

The IBELL YO2800 High Pressure Washer comes with a comprehensive warranty and dedicated customer support.

- **Warranty:** 1 Year (6 Months Standard + 6 Months Additional warranty on Registration). Registration should be completed within 30 days from the date of purchase.
- **Customer Service:** For any queries, technical assistance, or warranty claims, please contact IBELL customer support.



**Keep Your Trust
in Aftercare Purchase.**

Customer service support

 **+91 98956 00055**

To avail the full warranty, product registration must be completed within 30 days from the date of purchase.

Figure 8: IBELL customer service support information, including a contact number for aftercare assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question