Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Samsung Galaxy Tab S10 FE+

Samsung Galaxy Tab S10 FE+ 13.1” WiFi Android Tablet User Manual

Model: Galaxy Tab S10 FE+ (SM-X620NZSNXAR)

Introduction

Welcome to the comprehensive user manual for your Samsung Galaxy Tab S10 FE+ 13.1” WiFi Android Tablet. This guide provides essential information on setting up, operating, maintaining, and troubleshooting your device to ensure optimal performance and user experience. Please read through this manual carefully to familiarize yourself with all the features and functionalities of your new tablet.

What's in the Box

Upon unboxing your Samsung Galaxy Tab S10 FE+, you should find the following items:

- Tablet
- S-Pen
- Data Cable
- Ejection Pin
- Quick Start Guide




Figure 1: Box Contents. This image displays the Samsung Galaxy Tab S10 FE+ tablet, S-Pen, data cable, ejection pin, and quick start guide, as typically found inside the product packaging.

Setup

Follow these steps to set up your new Samsung Galaxy Tab S10 FE+:

1. **Charge the Tablet:** Connect the included USB-C cable to your tablet and a compatible power adapter (sold separately). Allow the tablet to charge fully before initial use.
2. **Power On:** Press and hold the Power button located on the side of the tablet until the Samsung logo appears.
3. **Initial Setup Wizard:** Follow the on-screen instructions to select your language, connect to a Wi-Fi network, sign in with your Google account, and set up security features like a PIN or fingerprint.
4. **S Pen Setup:** The S Pen is included and ready for use. It magnetically attaches to the back of the tablet for charging and storage.



Figure 2: Samsung Galaxy Tab S10 FE+. A silver Samsung Galaxy Tab S10 FE+ tablet is shown, highlighting its sleek design and large display.

Setup Video Guide

Video 1: Tab S10 FE+ Product Overview. This video provides a brief overview of the Samsung Galaxy Tab S10 FE+, showcasing its key features and design. It is an official product overview from the seller.

Operating Your Galaxy Tab S10 FE+

Your Galaxy Tab S10 FE+ is designed for intuitive and powerful performance. Here are some key operational highlights:

- **Expansive 13.1” Screen:** Enjoy your favorite content with stunning detail on the large display. Dual speakers enhance the audio experience.



Figure 3: Large Display. The tablet screen shows a vibrant image of hot air balloons, illustrating the expansive 13.1-inch display and its visual quality.

- **Circle to Search with Google:** Easily search for anything on your screen by simply circling it with your S Pen.




Figure 4: Circle to Search. An S Pen is used to circle an image of a blue jay on the tablet screen, initiating a Google search, demonstrating the Circle to Search feature.

- **Handwriting Assist & Math Solver:** Tidy up handwritten notes and solve math problems directly on your screen using the S Pen.
- **Durable and Water-Resistant:** The IP68-rated design ensures durability against water exposure (up to 5 feet for 30 minutes).




Figure 5: Water Resistance. The tablet is shown with water splashing on its screen, emphasizing its IP68 water-resistant design.

- **Powerful Performance:** The Exynos 1580 processor provides smooth experiences for gaming, multitasking, and other demanding tasks.




Figure 6: Gaming Performance. A person is shown holding the tablet horizontally, playing a colorful video game, demonstrating its capability for entertainment and gaming.

- **S Pen Precision:** Write, draw, and sketch with a natural, pen-on-paper feel.




Figure 7: S Pen Usage. A hand is shown using the S Pen to draw on the tablet screen, illustrating the precision and natural feel of the S Pen for creative tasks.

- **Long-Lasting & Fast-Charging Battery:** Enjoy up to 21 hours of video playback and quickly recharge with Super Fast Charging (45W charger sold separately).
- **AI on Your Keyboard:** Utilize AI features via a quick access hot key on compatible tablet keyboards.




Figure 8: AI Keyboard. The tablet is shown attached to a keyboard case, with a magnified view of a key featuring an AI icon, indicating the integration of AI features.

- **Ample Storage:** Up to 256GB internal storage, expandable by up to 1TB with a microSD card.

360° View

Video 2: Tab S10 FE+ 360 Spin Silver. This video provides a 360-degree view of the Samsung Galaxy Tab S10 FE+ in silver, showcasing its design from all angles. It is an official product video from the seller.

Maintenance

To ensure the longevity and optimal performance of your Samsung Galaxy Tab S10 FE+, consider the following maintenance tips:

- **Screen Care:** Use a soft, lint-free cloth to clean the screen. Avoid harsh chemicals or abrasive materials.
- **Software Updates:** Regularly check for and install software updates to benefit from the latest features, security patches, and performance improvements. Navigate to **Settings > Software update** to check for updates.
- **Battery Health:** To prolong battery life, avoid extreme temperatures and do not leave the tablet fully charged or fully discharged for extended periods. Use only Samsung-approved chargers and cables.

- **Water Resistance:** While your tablet is IP68 water-resistant, it is not waterproof. Avoid intentional submersion and ensure all ports are dry before charging. Rinse residue/dry after wet exposure.
- **Storage Management:** Periodically clear unnecessary files and apps to free up storage space and maintain smooth operation.

Troubleshooting

If you encounter issues with your Samsung Galaxy Tab S10 FE+, try these common troubleshooting steps:

- **Tablet Not Responding:** Press and hold the Power button for about 10 seconds to force a restart.
- **Wi-Fi/Bluetooth Connectivity Issues:** Toggle Wi-Fi or Bluetooth off and on from the Quick Settings panel. If the issue persists, restart your tablet and/or your router.
- **Apps Crashing:** Clear the cache and data for the problematic app (**Settings > Apps > [App Name] > Storage > Clear cache/Clear data**). If the issue continues, uninstall and reinstall the app.
- **Slow Performance:** Close unused apps, clear cache, and ensure sufficient storage space. A factory reset (**Settings > General management > Reset > Factory data reset**) can resolve persistent performance issues, but back up your data first.
- **S Pen Not Working:** Ensure the S Pen is properly attached to the tablet's magnetic charging area to confirm it's charged. If issues persist, restart the tablet.

Specifications

Brand	Samsung
Model Name	Galaxy Tab S10 FE+
Model Number	SM-X620NZSNXAR
Memory Storage Capacity	128 GB
RAM Memory Installed	8 GB
Screen Size	13.1 Inches
Display Resolution Maximum	2880 x 1800 Pixels
Display Refresh Rate	90 Hz
Operating System	Android
Processor	Samsung Exynos 1580 (S5E8855)
Connectivity Technology	Bluetooth, USB, Wi-Fi
Item Weight	1.49 Pounds
Battery Average Life	21 Hours
Special Features	Fast Charging, Stylus Support (S Pen included)

Warranty and Support

Your Samsung Galaxy Tab S10 FE+ comes with a **2 Year Manufacturer Warranty**. For detailed terms and conditions, please refer to the warranty card included in your product packaging or visit the official Samsung support website.
For further assistance, technical support, or service inquiries, please contact Samsung Customer Service through their official website or designated support channels. Have your model number (SM-X620NZSNXAR) and serial number ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Where is the external storage (microSD card) slot located on my Samsung Galaxy Tab S10 FE+?

The Samsung Galaxy Tab S10 FE+ features a microSD card slot that allows you to expand your storage by up to 1TB. To locate and use the slot, follow these steps: Location: The slot...

Read full answer

Open the live page

https://manuals.plus/asin/B0DVZWJL91

More documents and user manuals: **https://manuals.plus/**