

[Manuals.plus](#) /

› [Dapper Supply](#) /

› Dapper Supply 18-inch Pressure Washer Surface Cleaner (Model DP-SPW1115) Instruction Manual

Dapper Supply DP-SPW1115

Dapper Supply 18-inch Pressure Washer Surface Cleaner Instruction Manual

Model: DP-SPW1115

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Dapper Supply 18-inch Pressure Washer Surface Cleaner. Designed for cleaning large flat surfaces such as driveways, patios, sidewalks, porches, and decks, this unit features a durable stainless steel construction, dual high-pressure rotating nozzles, and a splash-free skirt. Please read this manual thoroughly before operation.

SAFETY INFORMATION

Always wear appropriate personal protective equipment, including eye protection, during operation. Ensure all connections are secure to prevent leaks. Do not operate the surface cleaner without a pressure washer connected and water flowing. Keep children and pets away from the operating area. Refer to your pressure washer's manual for additional safety guidelines.

PACKAGE CONTENTS

- 18-inch Surface Cleaner Unit
- Handle Assembly
- Pressure Washer Gun
- 3/8" QC Inlet
- Two Hose Adapters
- Teflon Tape

SETUP AND ASSEMBLY

Follow these steps to assemble your Dapper Supply 18-inch Pressure Washer Surface Cleaner:

1. **Attach the Handle to the Base:** Secure the handle assembly to the surface cleaner base using the provided pins. Ensure the pins are fully inserted and locked.



Image: Securely attach the handle to the base of the surface cleaner using the provided locking pins.

2. **Connect the High-Pressure Hose:** Connect the high-pressure hose from the surface cleaner base to the handle assembly. Use Teflon tape on threaded connections to ensure a leak-free seal.



Image: Detail of the high-pressure hose connection point on the surface cleaner base.

3. **Attach the Pressure Washer Gun:** Connect your pressure washer gun to the handle assembly. The unit includes a 3/8" QC inlet and two hose adapters for compatibility.



Image: The pressure washer gun connected to the handle, showing the 3/8" QC inlet and adapters.

4. **Secure the Trigger:** The pressure washer gun features a trigger lock for continuous operation. Engage the lock to prevent accidental trigger pulls or to maintain pressure without constant squeezing.



Image: Close-up of the pressure washer gun showing the trigger and safety locking mechanism.

Setup Video Guide:

Your browser does not support the video tag.

Video: Step-by-step installation guide for the Dapper Pressure Washer Surface Cleaner.

OPERATING INSTRUCTIONS

To achieve optimal cleaning results and ensure safe operation, follow these guidelines:

1. **Connect to Pressure Washer:** Ensure your surface cleaner is properly connected to a pressure washer with a minimum of 2500 PSI for optimal performance. The maximum allowable pressure is 4350 PSI.
2. **Start Pressure Washer:** Turn on your pressure washer according to its manufacturer's instructions.
3. **Begin Cleaning:** Squeeze the trigger on the pressure washer gun to start the water flow. Walk slowly behind the unit, guiding it over the surface to be cleaned. The dual high-pressure rotating nozzles will clean a wide path.



Image: The Dapper Supply surface cleaner actively cleaning a large paved area, demonstrating its wide coverage.

4. **Maintain Consistent Speed:** Move at a consistent, slow pace to allow the rotating nozzles to thoroughly clean the surface without streaking.
5. **Splash-Free Operation:** The circular brush and splash-free skirt are designed to contain water spray and debris, ensuring a cleaner and safer workspace.



Image: The underside of the surface cleaner showing the dual rotating nozzles and the flexible bristle skirt.

6. **Maneuverability:** The four 360° caster wheels allow for smooth gliding and easy maneuverability over various flat surfaces.



Image: A detailed view of one of the 360-degree rotating caster wheels, highlighting smooth movement.

Operation Video Guide:

Your browser does not support the video tag.

Video: Demonstration of the Dapper Pressure Washer Surface Cleaner in action, showing its cleaning effectiveness.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your surface cleaner:

- **After Each Use:** Flush the unit with clean water to remove any debris or chemical residues.
- **Inspect Nozzles:** Periodically check the rotating nozzles for clogs or damage. Clean any blockages using a nozzle cleaning tool (not included) or a thin wire.
- **Check Connections:** Ensure all hose connections remain tight and free of leaks. Replace Teflon tape as needed.

- **Lubrication:** The internal bearings are designed for durability. If you notice any resistance in rotation, consult a qualified technician.
- **Storage:** Store the surface cleaner in a dry, protected area to prevent corrosion and damage.

TROUBLESHOOTING

If you encounter issues with your surface cleaner, refer to the following common solutions:

Problem	Possible Cause	Solution
No water flow or low pressure	Clogged nozzles Insufficient water supply to pressure washer Loose hose connections Pressure washer malfunction	Clean nozzles with a thin wire or nozzle cleaning tool. Ensure adequate water supply to your pressure washer. Tighten all hose connections; reapply Teflon tape if necessary. Refer to your pressure washer's manual for troubleshooting.
Uneven cleaning or streaking	Moving too fast Partially clogged nozzle	Slow down your pace during cleaning. Inspect and clean both rotating nozzles.
Water leaking from connections	Loose connections Worn O-rings or seals Insufficient Teflon tape	Tighten all connections. Inspect and replace O-rings or seals if damaged. Reapply Teflon tape to threaded connections.

If problems persist, contact Dapper Supply customer support.

SPECIFICATIONS

Feature	Detail
Brand	Dapper Supply
Model Number	DP-SPW1115
Cleaning Disc Size	18 inches
Max PSI	4350 PSI
Recommended Min PSI	2500 PSI
Connector Type	3/8" Quick Connect (QC)
Material	Stainless Steel
Wheels	Four 360° Caster Wheels
UPC	850064526219

WARRANTY AND SUPPORT

Your Dapper Supply 18-inch Pressure Washer Surface Cleaner is backed by a**1-Year Warranty**, ensuring reliable performance and customer satisfaction. For any inquiries or support needs, please contact Dapper Supply customer service. Additional support resources may include:

- U.S.-Based Expert Support
- Nationwide Technician Network
- Replacement Parts Availability



Images: Visual representations of available support services.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DW1M6QBJ>

More documents and user manuals: <https://manuals.plus/>