

[manuals.plus](#) /› [Yaheetech](#) /› [Yaheetech 12x12 Pop-up Canopy Tent Instruction Manual](#)

## Yaheetech 615263

# Yaheetech 12x12 Pop-up Canopy Tent Instruction Manual

Model: 615263

## 1. INTRODUCTION AND OVERVIEW

Thank you for choosing the Yaheetech 12x12 Pop-up Canopy Tent. This manual provides essential information for the safe and efficient setup, operation, and maintenance of your canopy. Designed for outdoor use, this heavy-duty, waterproof canopy offers 144 sq. ft. of shade and features integrated wheels for effortless mobility.

Key features include a one-push-to-lock system for easy setup, UPF 50+ polyester fabric for sun protection, and enhanced stability with guy lines, sandbags, and ground anchors.

## 2. SAFETY INFORMATION

**Important:** Always secure the tent with guy lines, sandbags, and ground anchors when using in windy conditions. Failure to do so may result in damage to the canopy or personal injury. Do not use the canopy in severe weather conditions such as heavy rain, strong winds, or thunderstorms. Always ensure all locking mechanisms are fully engaged before use.

## 3. PACKAGE CONTENTS

Before assembly, please verify that all components listed below are present:

- 1 x Canopy Frame (pre-assembled)
- 1 x Canopy Top Fabric
- 1 x Portable Carry Bag with Wheels
- 4 x Sandbags (empty, for filling)
- 8 x Ground Stakes
- 4 x Guy Lines

# EASY SETUP



## STEP 01

Open the frame and adjust the wheels to the footpads

## STEP 02

Push the central knob and adjust the height

## STEP 03

Secure with ground stakes, guy lines, and sandbags

*Detailed view of all items included in the Yaheetech 12x12 Pop-up Canopy Tent package.*

## 4. SETUP INSTRUCTIONS

For optimal setup, two people are recommended, though single-person setup is possible. Ensure you are on a flat, clear surface.

### 4.1. Expand the Frame

1. Place the folded frame in the desired setup location.
2. With a partner (or alone, by walking around), gently pull the legs outwards to partially expand the frame.

### 4.2. Attach the Canopy Fabric

3. Drape the canopy top fabric over the partially expanded frame. Ensure the Yaheetech logo is facing outwards on the desired side.
4. Secure the Velcro straps located at each corner of the canopy fabric to the corresponding frame legs.

### 4.3. Extend the Frame and Legs

5. From underneath the canopy, push the central locking system upwards until it clicks into position. This will fully expand the frame and lock the top.
6. Press the leg height adjustment buttons on each leg and lift the outer leg sections until they lock into your desired height. There are multiple height settings.



*Visual guide for the three main steps of canopy setup.*

### 4.4. Secure the Canopy

7. Fill the four provided sandbags with sand or other heavy material and attach them to the base of each leg for added stability.
8. Use the ground stakes to anchor the footpads of the legs to the ground.
9. Attach the guy lines to the canopy corners and stake them into the ground at an angle, away from the canopy, to provide additional wind resistance. Adjust tension as needed.

*Video demonstrating the full setup process of a Yaheetech pop-up tent, including frame expansion, fabric attachment, and securing.*

*Video showcasing the easy setup of a Yaheetech pop-up canopy.*

## 5. OPERATING INSTRUCTIONS

The Yaheetech canopy is designed for ease of use and versatility.

### 5.1. Mobility

Two of the tent legs feature integrated wheels. To move the canopy without fully dismantling it, lift the opposite side of the tent and roll it to your desired location. The wheels can also be folded to act as footpads for stationary use.



*Demonstration of the wheeled design for easy transport and conversion to stable footpads.*

### 5.2. Weather Considerations

The canopy fabric is waterproof and features UPF 50+ UV protection. A vented top allows for better air circulation and helps prevent wind uplift. Always ensure the canopy is properly secured with all provided accessories (sandbags, stakes, guy lines) to withstand light wind conditions. Avoid use in severe weather.



*Visual representation of the canopy's water and UV resistant properties.*

## 6. STORAGE AND TRANSPORT

After use, the canopy can be easily collapsed and stored in its portable carry bag.

### 6.1. Collapsing the Canopy

1. Lower all legs to their shortest height by pressing the adjustment buttons.
2. Press the central locking system lever to release the canopy top, allowing the frame to collapse inwards.
3. Gently push the frame from opposite sides until it is fully collapsed.

### 6.2. Packing into Carry Bag

4. Once fully collapsed, slip the carry bag over the canopy frame.
5. Zip up the bag and secure any external straps to keep the frame compact.
6. Utilize the exposed wheels on the carry bag to easily roll the canopy to your vehicle or storage area.



### GREAT FOR OUTDOOR GATHERINGS



*Close-up of the durable carry bag with wheels, handle, and zippers.*

*Video demonstrating the takedown process of a Yaheetech pop-up tent, including collapsing and packing.*

*Video review of a Yaheetech 10x10 Pop-up Canopy Tent, showing setup and takedown. Note: This video features a 10x10 model, but the general process is similar.*

## 7. MAINTENANCE

Regular maintenance will extend the life of your canopy.

- **Cleaning:** Clean the canopy fabric with mild soap and water. Do not use harsh chemicals or abrasive cleaners. Allow the fabric to dry completely before storing to prevent mildew.
- **Frame Care:** Inspect the frame for any damage or loose parts before and after each use. Clean any dirt or debris from the frame.
- **Storage:** Store the canopy in its carry bag in a cool, dry place away from direct sunlight when not in use.

## 8. TROUBLESHOOTING

If you encounter issues with your canopy, refer to the following common problems and solutions:

- **Canopy not standing stable:** Ensure all legs are fully extended and locked. Verify that sandbags are filled and attached, and ground stakes and guy lines are properly installed and tensioned.

- **Water pooling on top:** The canopy is designed with a vented top to help prevent pooling. Ensure the canopy is fully extended and taut. In heavy rain, water may still accumulate; consider lowering one side slightly to allow drainage, or temporarily collapse the canopy.
- **Difficulty collapsing the frame:** Ensure all leg height adjustment buttons are pressed and the central locking system is disengaged. Do not force the frame; check for any obstructions.

## 9. SPECIFICATIONS

---

<b>Brand</b>	Yaheetech
<b>Model Number</b>	615263
<b>Size</b>	12x12 FT (144 sq. ft. coverage)
<b>Product Dimensions</b>	144"L x 144"W x 114"H
<b>Material</b>	Alloy Steel Frame, 600x300D Oxford Fabric Canopy
<b>Color</b>	White
<b>Item Weight</b>	46.5 pounds
<b>Water Resistance Level</b>	Waterproof
<b>Ultraviolet Light Protection</b>	Yes (UPF 50+)
<b>Assembly Required</b>	Yes

## 10. WARRANTY AND SUPPORT

---

For any questions, concerns, or warranty information regarding your Yaheetech 12x12 Pop-up Canopy Tent, please contact Yaheetech customer support. Refer to your purchase documentation for specific warranty terms and contact details.

You can also visit the [Yaheetech Store on Amazon](#) for additional product information and support.