

[Manuals.plus](#) /

> [COMHOMA](#) /

> COMHOMA Electric Height Adjustable Desk 120 x 60 cm with Drawers, Monitor Stand, and 3-Height Memory Control

COMHOMA EU-DTS118-WT-NEW

COMHOMA Electric Height Adjustable Desk

Model: EU-DTS118-WT-NEW | Brand: COMHOMA

1. INTRODUCTION

Thank you for choosing the COMHOMA Electric Height Adjustable Desk. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new desk. Please read these instructions carefully before use and retain them for future reference.

This desk is designed to offer a flexible and ergonomic workspace, allowing you to switch between sitting and standing positions with ease. It features a spacious desktop, integrated monitor stand, convenient drawer, and a smart control panel with memory presets.

2. SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Ensure all components are securely fastened before use.
- Keep children and pets away from the desk during height adjustment.
- Do not place hands or other objects near moving parts during operation.
- Do not overload the desk. The maximum recommended load capacity is 80 kg (176 lbs).
- Avoid spilling liquids on the control panel or electrical components.
- If any unusual noise or movement occurs, stop operation immediately and consult the troubleshooting section.
- Only use the provided power adapter and cable.

3. PACKAGE CONTENTS

Please check that all parts are present and undamaged before beginning assembly. Assembly tools are not included.

- Desktop sections

- Desk frame (legs, crossbar)
- Electric lifting mechanism and motor
- Control panel with power cable
- Drawer
- Monitor stand
- Headphone hooks (set of 2)
- Cable management tray
- Assembly hardware (screws, bolts, etc.)
- User Manual

4. SETUP AND ASSEMBLY

Assembly of this product is required. Follow the detailed instructions provided in the separate assembly guide for step-by-step installation. Ensure you have adequate space and the necessary tools (e.g., screwdriver, wrench) before starting.

4.1 Key Components and Dimensions

Familiarize yourself with the desk's dimensions and key features before assembly.

MultiFunction Control Panel

Ultra-clear digital display screen for easier operation



Image: Product dimensions and workspace organizers. The desk measures approximately 55 inches (140 cm) in width, with a monitor stand of 51 inches (130 cm) and a depth of 15.75 inches (40 cm). The main desktop depth is 24 inches (60 cm). The drawer is 22 inches (56 cm) wide and 9.84 inches (25 cm) deep. The desk height adjusts from 28.14 inches (71.5 cm) to 45.86 inches (116.5 cm).

4.2 Installing Accessories

After assembling the main desk structure, attach the drawer, monitor stand, headphone hooks, and cable management tray as per the assembly guide.

Ergonomic Monitor Stand

Optimal Pairing for Healthy Office





Image: Spacious desk drawer and mousepad. The integrated drawer provides convenient storage for desktop essentials, helping to keep your workspace tidy.

Product Size & Workspace Organizers



Image: Tablet, Laptop, and Book Stand. The adjustable stand can securely hold various devices or books, enhancing multitasking capabilities and freeing up desktop space.



Image: Cable Management System. Utilize the cable holes and management tray to keep your power cords and peripheral cables neatly organized and out of sight.

5. OPERATING INSTRUCTIONS

5.1 Control Panel Overview

The desk is operated via an intuitive control panel located on the front edge of the desktop.



Image: Multifunction Control Panel. Features include a clear digital display, up/down arrows for manual height adjustment, three programmable memory preset buttons, and an 'S' button for locking and settings.

5.2 Height Adjustment

Use the **Up** (▲) and **Down** (▼) arrow buttons on the control panel to manually adjust the desk height. The digital display will show the current height in centimeters.



Spacious Desk Drawer & Mousepad

An embedded drawer to organize your desktop essentials

Image: Wide Height Range. The desk can be adjusted from a minimum height of 28.14 inches (72 cm) to a maximum height of 45.86 inches (116 cm), accommodating both sitting and standing work preferences.


5.3 Memory Presets

The control panel allows you to save up to three preferred height positions:


1. Adjust the desk to your desired height using the Up/Down buttons.
2. Press the **S** button. The display will flash.
3. Press one of the numbered memory buttons (**1**, **2**, or **3**) within 3 seconds. The current height is now saved to that preset.
4. To recall a saved height, simply press the corresponding numbered memory button. The desk will automatically adjust to the stored position.

5.4 Ergonomic Monitor Stand


The integrated monitor stand helps maintain an ergonomic posture by elevating your screen to eye level, reducing strain on your neck and eyes.



Tablet Stand



Laptop Stand



Book Stand

Image: Ergonomic Monitor Stand. Achieve optimal eye-level alignment to prevent neck and eye fatigue, promoting a healthier working posture.

5.5 Quiet Operation

The electric lifting mechanism operates quietly, ensuring minimal disturbance in your workspace.

Conception Ultra-silencieuse

Restez concentré et ne dérangez pas les autres

10dB Feuilles qui tombent
45dB Notre produit
 60dB Voix normale
 90dB Bruit de moteur



Image: Ultra-Quiet Operation. The desk operates at approximately 45dB, allowing you to adjust its height without disturbing others or losing focus.

6. MAINTENANCE

Regular maintenance helps prolong the life of your desk:

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Retighten if necessary.
- **Cable Management:** Ensure cables are not pinched or tangled, especially during height adjustments.
- **Load Capacity:** Do not exceed the maximum load capacity of 80 kg (176 lbs) to prevent damage to the motor and frame.

7. TROUBLESHOOTING

If you encounter any issues with your desk, please refer to the following table:

Problem	Possible Cause	Solution
Desk does not move	Power cable disconnected; Motor overload; Control panel error.	Check power connection; Reduce load on desk; Unplug and replug power after 10 minutes.
Uneven height adjustment	Uneven load; Obstruction.	Distribute weight evenly; Remove any obstructions under or around the desk.
Desk stops mid-adjustment	Overload protection activated; Overheating.	Reduce load; Allow motor to cool down for 20 minutes before resuming operation.
Error code on display	Specific system error.	Refer to the detailed error code list in the full assembly manual or contact customer support.

If the problem persists after attempting these solutions, please contact COMHOMA customer support.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	COMHOMA
Model Number	EU-DTS118-WT-NEW
Product Dimensions (L x W x H)	120 x 60 x 116 cm (47.2 x 23.6 x 45.7 inches)
Item Weight	28 Kilograms (61.7 lbs)

Feature	Detail
Minimum Height	72 Centimeters (28.3 inches)
Maximum Height	116 Centimeters (45.7 inches)
Recommended Max Load	80 Kilograms (176 lbs)
Color	White
Material Type	Wood, Metal (Alloy Steel Frame)
Top Material Type	Wood
Finish Type	Lacquered
Desk Design	Standing Desk (T-shape)
Special Features	Ergonomic, Height Adjustable, Integrated USB Socket, Monitor Stand, Electric
Number of Drawers	1
Included Components	Headphone Hook, Cable Management Tray
Assembly Required	Yes (Assembly tools not included)
Recommended Uses	Gaming, Drafting, Work, Writing

9. WARRANTY AND SUPPORT

9.1 Warranty Information

COMHOMA products are manufactured to high-quality standards. For specific warranty details regarding your electric height adjustable desk, please refer to the warranty card included in your package or visit the official COMHOMA website. The warranty typically covers manufacturing defects and malfunctions under normal use.

9.2 Customer Support

If you have any questions, require assistance with assembly, or experience issues not covered in the troubleshooting guide, please contact COMHOMA customer support. Have your model number (EU-DTS118-WT-NEW) and purchase date ready when contacting support.

Contact information can typically be found on the COMHOMA website or on the product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DW49ZYHN>

More documents and user manuals: <https://manuals.plus/>