Maxximum MAXGIM15SS

Maxximum MAXGIM15SS Premium Indoor Gourmet Cube Ice Machine User Manual

Model: MAXGIM15SS | Brand: Maxximum

1. Important Safety Information

Read all instructions before using this appliance to prevent the risk of fire, electric shock, or injury. Keep this manual for future reference.

- **Electrical Safety:** Ensure the appliance is connected to a properly grounded 115V, 60Hz electrical outlet with a NEMA5-15P plug. Do not use extension cords or ungrounded adapters.
- **Water Connection:** This appliance requires a water supply. Ensure all water connections are secure to prevent leaks.
- **Refrigerant:** This unit contains R290-A refrigerant. Servicing should only be performed by authorized personnel. Do not puncture the refrigerant tubing.
- **Placement:** Place the ice machine on a stable, level surface. Ensure adequate ventilation around the unit. Do not block air vents.
- **Children:** Keep children away from the appliance. Do not allow them to operate or play with the ice machine.
- **Cleaning:** Disconnect power before cleaning or performing any maintenance.

2. Product Overview

The Maxximum MAXGIM15SS is a premium indoor gourmet cube ice machine designed for convenience and efficiency. It features a stainless steel exterior and an easy-to-use electronic control system.



Figure 2.1: Front view of the ice machine with the door open, revealing the ice bin, control panel, and ice scoop.



Figure 2.2: Close-up of the electronic control panel and the ice scoop positioned within the ice storage bin.

Key Features:

- **Daily Ice Production:** Up to 50 lbs. of gourmet cube ice per day.
- **Storage Capacity:** Integrated insulated ice storage bin holds up to 26 lbs. of ice.
- **Control System:** Easy-to-use electronic controls for operation and settings.
- **Auto Shut-Off:** Automatically stops ice production when the ice bin is full.
- **Included Accessories:** Comes with an ice scoop and a hanging hook for convenient storage.
- **Refrigerant:** Utilizes R290-A refrigerant.

3. Setup and Installation

Proper installation is crucial for the optimal performance and longevity of your ice machine.

3.1 Unpacking

1. Carefully remove all packaging materials, including tape and protective films.
2. Inspect the unit for any shipping damage. Contact your retailer immediately if damage is found.
3. Locate the ice scoop and user manual inside the ice bin.

3.2 Placement

- Place the ice machine on a firm, level surface capable of supporting its weight (approximately 114 lbs.).
- Ensure there is at least 6 inches of clearance around the back and sides of the unit for proper air circulation.
- Avoid direct sunlight or heat sources. The ambient temperature should be between 50°F (10°C) and 90°F (32°C).
- This unit is designed for indoor use only.

3.3 Electrical Connection

- Connect the power cord (72 inches long) to a dedicated, grounded 115V, 60Hz electrical outlet. The plug type is NEMA5-15P.
- Do not use multi-outlet adapters or extension cords.

3.4 Water Connection

This ice machine requires a continuous water supply. Consult a qualified plumber for proper water line installation if you are unsure.

- Connect the water inlet hose (not included, typically 1/4 inch) to a cold water supply with a shut-off valve.
- Connect the other end of the water inlet hose to the water inlet valve on the back of the ice machine.
- Ensure all connections are tight to prevent leaks.
- Install a drain line (not included) from the ice machine to a suitable floor drain or standpipe. Ensure proper slope for drainage.

3.5 Initial Cleaning

Before first use, clean the interior of the ice machine.

1. Prepare a solution of mild detergent and warm water.
2. Wipe down the interior surfaces, including the ice bin and water reservoir.
3. Rinse thoroughly with clean water.
4. Allow the unit to air dry completely before plugging it in.

4. Operating Instructions

Familiarize yourself with the control panel for efficient operation.



Figure 4.1: Detailed view of the electronic control panel.

4.1 Control Panel Functions

- **POWER Button:** Press to turn the ice machine ON or OFF.
- **ICE CUBE SIZE Buttons (Up/Down Arrows):** Adjust the size of the ice cubes. Refer to the display for current setting.
- **LIGHT Button:** Toggles the interior light ON or OFF.
- **ALARM Indicator:** Illuminates to indicate a fault or when the ice bin is full.
- **RUN Indicator:** Illuminates when the machine is actively producing ice.

4.2 Starting Ice Production

1. Ensure the unit is properly installed and connected to power and water.
2. Press the **POWER** button to turn on the ice machine. The RUN indicator should illuminate.
3. The machine will automatically begin the ice-making cycle. The first batch of ice may take longer to produce.
4. Adjust the ice cube size using the**ICE CUBE SIZE** buttons if desired.

4.3 Auto Shut-Off

The ice machine is equipped with an auto shut-off feature. When the ice bin is full, the machine will automatically stop ice production to prevent overflow. Production will resume once ice is removed from the bin.

4.4 Using the Ice Scoop

Use the provided ice scoop to retrieve ice from the storage bin. The scoop can be hung on the designated hook inside the unit for sanitary storage.

5. Maintenance and Cleaning

Regular maintenance ensures optimal performance and extends the life of your ice machine.

5.1 Daily Cleaning

- Wipe down the exterior with a soft, damp cloth.
- Empty and wipe the interior of the ice bin with a clean cloth.

5.2 Weekly Cleaning

- Disconnect the power supply.
- Remove all ice from the storage bin.
- Clean the interior surfaces, including the water reservoir and ice-making components, with a solution of mild detergent and warm water.
- Rinse thoroughly with clean water.
- Clean the ice scoop with warm, soapy water and rinse well.

5.3 Monthly Cleaning (Condenser)

- Disconnect the power supply.
- Locate the condenser coils (usually at the back or bottom of the unit).
- Use a soft brush or vacuum cleaner with a brush attachment to gently remove dust and debris from the condenser coils. Clean coils improve efficiency.

5.4 Descaling

Depending on water hardness, descaling may be required periodically to remove mineral buildup. Consult a qualified technician or refer to specific descaling instructions if provided with a descaling kit.

6. Troubleshooting Guide

Before contacting customer support, review the following common issues and solutions.

Problem	Possible Cause	Solution
Ice machine does not turn on.	No power supply.	Check if the power cord is securely plugged in. Verify the outlet has power.
No ice production.	No water supply.	Ensure the water supply valve is open and water pressure is adequate. Check for kinks in the water line.
	Ice bin is full.	Remove ice from the bin. Production will resume automatically.
	Ambient temperature too high.	Move the unit to a cooler location or ensure proper ventilation.
Ice cubes are too small or soft.	Water temperature too high.	Ensure cold water supply.
	Air vents blocked.	Clear any obstructions from the air vents.
Unusual noise.	Unit not level.	Adjust leveling feet to ensure the unit is stable and level.
Water leak.	Loose water connections.	Check and tighten all water inlet and drain connections.

7. Specifications

Detailed technical specifications for the Maxximum MAXGIM15SS ice machine.

Specification	Detail
Brand	Maxximum
Model Name	MAXGIM15SS
Product Dimensions (D x W x H)	33" x 23" x 42"
Daily Ice Production	50 lbs.
Storage Capacity	26 lbs.
Wattage	480 watts

Specification	Detail
Voltage	115 Volts
Item Weight	114 Pounds
Material Type	Stainless Steel
Refrigerant Type	R290-A
Plug Type	NEMA5-15P
Cord Length	72 inches
Included Components	User Manual, Ice Scoop
UPC / GTIN	845035034800
ASIN	B0DW4YGYSH

8. Warranty Information

This Maxximum MAXGIM15SS ice machine is covered by a**1 Year Manufacturer Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For specific terms, conditions, and to make a warranty claim, please refer to the warranty card included with your product or contact Maxximum customer support.

9. Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact Maxximum customer support. Have your model number (MAXGIM15SS) and purchase information ready when you call.

For the most up-to-date contact information, please visit the official Maxximum website or refer to your product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question