

## KSR KSW-8022

# KSR KSW-8022 Professional Bluetooth Speaker User Manual

Model: KSW-8022 | Brand: KSR

## 1. INTRODUCTION

Thank you for choosing the KSR KSW-8022 Professional Bluetooth Speaker. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.

The KSW-8022 is a versatile portable speaker featuring 50W RMS power, dual 6.5-inch speakers, Bluetooth connectivity, FM radio, USB/Micro SD playback, AUX input, and KSR-LINK technology for wireless stereo pairing. It also includes dynamic LED lighting to enhance your audio experience.



Image 1.1: Front view of the KSR KSW-8022 Bluetooth Speaker with illuminated LED rings.

## 2. SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following precautions:

- Do not expose the speaker to water, moisture, or extreme temperatures.
- Avoid placing the speaker near heat sources or in direct sunlight.
- Do not attempt to disassemble, repair, or modify the unit yourself. Contact qualified service personnel.

- Use only the specified charging accessories.
- Keep the speaker away from children and pets.
- Ensure proper ventilation around the speaker during use.

### 3. PACKAGE CONTENTS

---

Please check that all items are present in the package:

- 1 x KSR KSW-8022 Bluetooth Speaker
- 1 x User Manual
- 1 x Power Cable (specific type may vary by region)

### 4. PRODUCT OVERVIEW

---

#### 4.1 Key Features

- **50W RMS Power Output:** Delivers clear and powerful audio.
- **Dual 6.5-inch Speakers:** Provides balanced sound reproduction.
- **KSR-LINK Technology:** Allows wireless pairing of two KSW-8022 speakers for stereo sound.
- **Multiple Playback Options:** Bluetooth, FM Radio, USB, Micro SD, AUX input.
- **Dynamic LED Lighting:** Integrated lights synchronize with music for visual effects.
- **Rechargeable Battery:** For portable use.



Image 4.1: Key features of the KSW-8022 speaker, including power, battery life, and KSR-LINK.

#### 4.2 Control Panel and Connections

Familiarize yourself with the control panel and connection ports:



Image 4.2: Top view of the control panel.

- **POWER:** On/Off switch.
- **ALIMENTACIÓN/CARGA:** Power input for charging.
- **AUX:** 3.5mm auxiliary input.
- **USB:** USB port for media playback.
- **MICRO SD:** Micro SD card slot for media playback.
- **MIC 1 / MIC 2:** 6.3mm microphone inputs.

- **EQ:** Equalizer settings.
- **REPETIR:** Repeat playback mode.
- **LED:** Control for LED lighting effects.
- **GRABAR:** Recording function (if available).
- **MIC PRIO:** Microphone priority function.
- **MODO:** Mode selection (Bluetooth, FM, USB, SD, AUX).
- **KSR-LINK:** Button to activate KSR-LINK (TWS) pairing.
- **VOL/MÚSICA MENÚ:** Volume control and menu navigation.



## 5. SETUP

---

### 5.1 Initial Charging

Before first use, fully charge the speaker. Connect the power cable to the ALIMENTACIÓN/CARGA port on the speaker and plug it into a suitable power outlet. The charging indicator will illuminate. Once fully charged, the indicator may change color or turn off. Disconnect the power cable when charging is complete.

### 5.2 Powering On/Off

To power on the speaker, toggle the **POWER** switch to the 'ON' position. To power off, toggle the switch to the 'OFF' position.

## 6. OPERATING MODES

---

### 6.1 Bluetooth Pairing

1. Power on the speaker. The display will show 'BLUE' and a pairing indicator will flash, indicating it's in Bluetooth mode and ready to pair. If not, press the **MODO** button until 'BLUE' is displayed.
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select 'KSW-8022' from the list of devices.
4. Once paired, the speaker will emit a confirmation sound, and the 'BLUE' indicator will stop flashing.

### 6.2 KSR-LINK (True Wireless Stereo) Function

To pair two KSW-8022 speakers for a stereo experience:

1. Ensure both KSW-8022 speakers are powered on and in Bluetooth mode.
2. On one of the speakers (this will be the primary speaker), press and hold the **KSR-LINK** button. The speaker will emit a sound indicating it's searching for another speaker.
3. The two speakers will automatically connect. A confirmation sound will indicate successful pairing.
4. Now, connect your mobile device to the primary speaker via Bluetooth as described in Section 6.1. Audio will play through both speakers in stereo.



#### ENTRADAS

- 1 Entrada AUX de 3,5 mm
- 2 Entradas 6,3 mm para micrófono
- 1 Entrada USB
- 1 Entrada Micro SD



Image 6.1: Illustration of various input options and the KSR-LINK feature for connecting two speakers.

### 6.3 FM Radio

1. Press the **MODO** button repeatedly until 'FM' is displayed.
2. Press and hold the Play/Pause button (often integrated with VOL/MÚSICA MENÚ or a dedicated button) to automatically scan and save available FM stations.
3. Use the Previous/Next track buttons (often integrated with VOL/MÚSICA MENÚ) to navigate through saved stations.

### 6.4 USB/Micro SD Playback

1. Insert a USB flash drive or Micro SD card (with supported audio files) into the respective port.
2. The speaker will automatically switch to USB or Micro SD mode and begin playback. If not, press the **MODO** button to select the correct source.
3. Use the playback controls (Play/Pause, Previous/Next track) to manage your music.

### 6.5 AUX Input

1. Connect an external audio device (e.g., smartphone, MP3 player) to the **AUX** port using a 3.5mm audio cable.
2. Press the **MODO** button until 'AUX' is displayed.
3. Control playback from your connected device.

### 6.6 Microphone Usage

1. Connect a microphone to either the **MIC 1** or **MIC 2** 6.3mm input.
2. Adjust the microphone volume using the dedicated control (if available) or the main volume.
3. The **MIC PRIO** button can be used to prioritize microphone audio over music playback.

### 6.7 LED Light Control

Press the **LED** button to cycle through different lighting modes or to turn the LED lights off.

## 7. MAINTENANCE

### 7.1 Cleaning

Wipe the speaker's exterior with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents. Ensure no liquids enter the speaker's openings.

### 7.2 Storage

When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to charge the battery periodically (e.g., every 3 months) to maintain its lifespan.

## 8. TROUBLESHOOTING

If you encounter issues with your KSW-8022 speaker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Battery is depleted; Power switch is off.	Charge the speaker; Ensure the power switch is in the 'ON' position.
No sound	Volume is too low; Incorrect input mode selected; Device not connected properly.	Increase volume; Press <b>MODO</b> to select correct input; Reconnect device.
Bluetooth not pairing	Speaker not in pairing mode; Device Bluetooth is off; Speaker already paired to another device.	Ensure speaker is in Bluetooth mode and flashing; Enable Bluetooth on your device; Disconnect from other devices.
KSR-LINK not connecting	Speakers are too far apart; One speaker not in Bluetooth mode.	Ensure speakers are within range; Verify both speakers are in Bluetooth mode before initiating KSR-LINK.
USB/Micro SD not playing	Unsupported file format; Card/drive not inserted correctly; Corrupted files.	Ensure files are supported (e.g., MP3); Reinsert card/drive; Try different media.

## 9. SPECIFICATIONS

Feature	Detail
Model Name	KSW-8022
Brand	KSR
Speaker Type	Tower
Mounting Type	Floor
Speaker Output Power	50 Watts RMS
Frequency Response	50 GHz
Connectivity Technology	Bluetooth

Feature	Detail
Audio Output Mode	Surround
Product Dimensions	29D x 30W x 65H centimeters
Components Included	1 Speaker, 1 User Manual
Batteries Required	No (Internal rechargeable battery)



Image 9.1: Physical dimensions of the KSW-8022 speaker.

## 10. WARRANTY AND SUPPORT

## 10.1 Warranty Information

This product is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase or contact KSR customer service for specific warranty terms and conditions. Keep your proof of purchase for warranty claims.

## 10.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact KSR customer support. Contact details can typically be found on the manufacturer's official website or on the product packaging.

