SHPAVVER Rs8993

SHPAVVER Electric Rotary Shaver

Model: Rs8993

User Instruction Manual

Introduction

The SHPAVVER Electric Rotary Shaver Model Rs8993 is designed to provide a comfortable and efficient shaving experience. This cordless, waterproof shaver features a 4D flexible floating head, dual steel precision blades, and a pop-up trimmer for versatile grooming. It is suitable for both wet and dry use, ensuring convenience and adaptability to your shaving routine.



Image: The SHPAVVER Electric Rotary Shaver Model Rs8993, showcasing its sleek design and accompanying retail packaging.

What's Included

Upon unboxing your SHPAVVER Electric Rotary Shaver, you should find the following components:

- SHPAVVER Electric Rotary Shaver unit
- Protective cap for shaver head
- USB charging cable
- Cleaning brush
- User manual (this document)

Setup

1. **Initial Charge:** Before first use, fully charge the shaver. Connect the USB charging cable to the shaver's charging port

and plug the other end into a compatible USB power source (e.g., computer, wall adapter). The LED display will indicate charging status.

2. **Attach Shaver Head:** Ensure the rotary shaver head is securely attached to the main unit. It should click into place.

Operating Instructions

The SHPAVVER Electric Rotary Shaver is designed for ease of use and versatility.

Shaving Technique (Wet or Dry)

The shaver can be used for both wet and dry shaving. For dry shaving, ensure your face is clean and dry. For wet shaving, you may use shaving foam or gel for a smoother experience.

1. **Power On:** Press the power button to turn on the shaver. The LED display will show the remaining battery minutes.
2. **Shaving Motion:** Gently move the shaver in small, circular motions over your face and neck. The 4D flexible floating head adapts to the contours of your face for a close and comfortable shave.
3. **Pressure:** Apply light pressure. Excessive pressure is not necessary and may cause skin irritation.
4. **Rinsing During Use (Wet Shaving):** If using with foam or gel, you can rinse the shaver head under running water during your shave to clear accumulated hair and product.



Image: Close-up of the shaver's 4D Flexible Floating Head, designed to adapt to facial contours for a close shave.



Image: Demonstrates the shaver's versatility for both wet shaving with foam and dry shaving.

Using the Pop-up Trimmer

The integrated pop-up trimmer is ideal for precise grooming of sideburns, mustaches, and beards.

1. **Activate Trimmer:** Locate the pop-up trimmer switch on the back of the shaver and slide it upwards to engage the trimmer.
2. **Trimming:** Hold the shaver at a right angle to your skin and gently trim desired areas.
3. **Retract Trimmer:** Once finished, slide the switch downwards to retract the trimmer.



Image: A detailed view of the pop-up trimmer, highlighting its 25mm blade width and one-click ejection mechanism for easy use on mustaches and sideburns.

Maintenance

Regular cleaning ensures optimal performance and extends the life of your shaver.

Cleaning the Shaver Head

The SHPAVVER Electric Rotary Shaver is fully washable for easy cleaning.

1. **Power Off:** Turn off the shaver before cleaning.
2. **Open Shaver Head:** Press the release button to open the shaver head. The spring-loaded mechanism will allow it to pop open.
3. **Rinse:** Rinse the opened shaver head thoroughly under warm running water. You can also use the included cleaning brush to remove any stubborn hair clippings.

4. **Dry:** Shake off excess water and allow the shaver head to air dry completely before closing it or attaching the protective cap.
5. **Close Shaver Head:** Gently push the shaver head back into place until it clicks shut.



Image: The shaver head being rinsed under running water, demonstrating its washable design for easy cleaning.

Troubleshooting

If you encounter any issues with your SHPAVVER Electric Rotary Shaver, please refer to the following common solutions:

- **Shaver not turning on:** Ensure the shaver is fully charged. If the battery is low, connect it to the charger.
- **Reduced shaving performance:** Clean the shaver head thoroughly as described in the Maintenance section. Accumulated hair or debris can affect blade efficiency.
- **Skin irritation:** Ensure you are using light pressure. For wet shaving, try using a quality shaving foam or gel. Allow your skin to adapt to the new shaver if you are switching from a different type.

- **Unusual noise:** Check if the shaver head is properly closed and secured. Clean the head to ensure no foreign objects are interfering with the blades.

If the problem persists after attempting these solutions, please contact SHPAVVER customer support.

Specifications

Feature	Detail
Product Dimensions	3.8 x 2.5 x 6.8 inches; 10.55 ounces
Item Model Number	Rs8993
Manufacturer	SHPAVVER
ASIN	B0DW7M7HLV
UPC	662987949378
Waterproof	Yes (Wet/Dry use)
Charging	USB Fast Charging
Blades	Precision Blades, Dual Steel, Double Ring Mesh
Head Type	4D Flexible Floating Head
Trimmer	Pop-up Trimmer (25mm blade width)

Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the documentation included with your purchase or visit the official SHPAVVER website. Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I charge the SHPAVVER Rs8993 Electric Rotary Shaver?

To charge your SHPAVVER Rs8993 Electric Rotary Shaver, follow these steps:Connect the Cable: Plug the included USB charging cable into the charging port located on the shaver unit.Power Source: Connect the other end of...

Read full answer

Why won't my SHPAVVER Rs8993 electric shaver charge?

If your SHPAVVER Rs8993 shaver is not charging, please try the following troubleshooting steps based on the product manual:Check the Power Source: Ensure the USB charging cable is securely connected to the shaver's charging...

Read full answer