

[Manuals.plus](#) /

› [SHPAVVER](#) /

› SHPAVVER GK-1800 12-in-1 Cordless Waterproof Beard Trimmer and Grooming Kit User Manual

SHPAVVER GK-1800

SHPAVVER GK-1800 12-in-1 Cordless Waterproof Beard Trimmer and Grooming Kit User Manual

Model: GK-1800 | Brand: SHPAVVER

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your SHPAVVER GK-1800 12-in-1 Cordless Waterproof Beard Trimmer and Grooming Kit. Please read all instructions carefully before first use and retain this manual for future reference.



Image: The SHPAVVER GK-1800 grooming kit, showcasing the main trimmer unit and various interchangeable heads and guide combs.

Safety Information

- To reduce the risks of burns, electric shock, fire, or injury, always unplug the appliance from the power outlet immediately after use.
- Keep the plug and electrical cord away from heated surfaces.
- Make sure that the plug and cord are free from moisture.
- Do not plug or unplug the appliance with wet hands.
- Please do not use the appliance with a broken cord. Please contact the seller to purchase a new cord.

- Please charge it, use it, and keep it stored at 60-80°F.
- Remember to unplug the appliance when cleaning it.
- Only use the attachments provided with this appliance.
- Keep this product out of the reach of children.
- Persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge may result in hazardous use. Ensure they are supervised or given instructions for safe use.
- The external safety lock design prevents accidental activation, which is safer when traveling or storing with children at home, avoiding the risk of accidental touch.

PACKAGE CONTENTS

Your SHPAVVER GK-1800 Grooming Kit includes the following items:

- Main Trimmer Unit (with On/Off switch and Safety Lock)
- Full-Size Trimmer Head
- Precision Trimmer Head
- Design Trimmer Head
- Nose Trimmer Head
- Micro Shaver Head
- Body Trimmer Head
- Guide Combs: 3mm, 6mm, 9mm, 12mm (for full-size trimmer)
- Adjustable Sideburn Comb
- USB Charging Cable
- Cleaning Brush
- Stand Base
- User Manual (this document)

ALL IN 1



Elite Men GROOMING KIT




Image: All components of the SHPAVVER GK-1800 grooming kit, including the main unit, various heads, combs, and charging cable.

SETUP

1. Charging the Trimmer

1. Ensure the trimmer is switched OFF.
2. Connect the USB charging cable to the charging port at the bottom of the trimmer.
3. Plug the USB end into a compatible USB power adapter (not included) or computer USB port.
4. The LED display will show the charging progress and remaining battery percentage.
5. A full charge takes approximately 1.5 hours and provides up to 90 minutes of cordless use.



Image: The main trimmer unit displaying battery percentage on its LED screen while being charged via USB.

2. Attaching/Detaching Trimmer Heads

1. To remove a head, gently pull it upwards from the main unit.
2. To attach a head, align the head with the main unit and press down until it clicks securely into place.



Image: Visual guide on how to easily install and remove different trimmer heads from the main unit.

3. Attaching Guide Combs

1. Select the desired guide comb (3mm, 6mm, 9mm, or 12mm) for your preferred hair length.
2. Slide the comb onto the full-size trimmer head until it locks into position.
3. To remove, gently push the comb upwards from the back.

OPERATING INSTRUCTIONS

General Use

1. Ensure the desired trimmer head and guide comb (if applicable) are securely attached.
2. To turn on the trimmer, slide the safety lock (if engaged) and then press the power button. The LED display will illuminate.
3. To activate Turbo Speed, press the power button again.
4. Move the trimmer against the direction of hair growth for optimal results.
5. To turn off, press the power button. Engage the safety lock for storage or travel.

Specific Trimmer Head Functions

- **Full-Size Trimmer:** Ideal for beard, mustache, and sideburn trimming. Use with guide combs for desired length.
- **Precision Trimmer:** For detailed styling, sharp lines, and intricate designs.
- **Micro Shaver:** For a smooth, close shave on smaller areas. Gently press against the skin and move in circular motions.
- **Nose & Ear Trimmer:** Carefully insert the trimmer into the nostril or ear canal. Do not insert deeper than 6mm.
- **Body Trimmer:** Use for trimming body hair. Can be used with or without the guard for different lengths.

Your browser does not support the video tag.

Video: Official SHPAVVER product video demonstrating the various functions and ease of use of the beard trimmer and grooming kit.

MAINTENANCE

Cleaning

1. Turn off the trimmer and unplug it from the charger.
2. Remove the trimmer head.
3. Gently brush off any remaining hair from the blades and inside the unit using the provided cleaning brush.
4. Since the trimmer is IPX6 waterproof, you can rinse the trimmer head and main unit under running water for thorough cleaning. Ensure it is completely dry before reattaching heads or storing.
5. Do not use harsh chemicals or abrasive cleaners.



Low noise



Waterproof



Easy to install



Image: The SHPAVVER trimmer being cleaned under running water, demonstrating its IPX6 waterproof design.

Storage

Store the trimmer and all accessories in the provided stand base in a cool, dry place, away from direct sunlight and out of reach of children. Ensure the safety lock is engaged when storing.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Trimmer does not turn on.	Low battery or safety lock engaged.	Charge the trimmer fully. Disengage the safety lock.
Poor trimming performance.	Blades are dull or clogged with hair.	Clean the blades thoroughly. Ensure blades are properly attached.

Problem	Possible Cause	Solution
Trimmer pulls hair.	Blades are dull, dirty, or moving too fast/slow.	Clean and lubricate blades. Ensure sufficient battery charge. Try using Turbo Speed for thicker hair.

SPECIFICATIONS

- **Model Number:** GK-1800
- **Product Dimensions:** 3 x 3 x 3 inches
- **Item Weight:** 1.17 Pounds
- **Battery Type:** 1 Nonstandard Battery (included), Rechargeable Lithium-ion
- **Charging Time:** 90 minutes
- **Run Time:** Up to 90 minutes
- **Waterproof Rating:** IPX6
- **Included Components:** Beard Trimmer, Cleaning Brush, Guide Combs, Hair Clipper, Nose and Ear Trimmer

WARRANTY AND SUPPORT

For warranty information, technical support, or customer service inquiries, please refer to the product packaging or visit the official SHPAVER website. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

