

[Manuals.plus](#) /

› [Bestier](#) /

› Bestier H200571G Cross-Legged Office Chair User Manual

Bestier H200571G

Bestier H200571G Cross-Legged Office Chair User Manual

Model: H200571G | Brand: Bestier

1. INTRODUCTION

Thank you for choosing the Bestier H200571G Cross-Legged Office Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. Please read these instructions thoroughly before use and retain them for future reference.

Important Safety Information

- Ensure all components are securely fastened before use.
- Do not exceed the maximum weight capacity of 136.08 kg (300 lbs).
- Avoid standing on the chair or using it as a step stool.
- Keep hands and feet clear of moving parts during adjustment.
- Use the chair on a level surface to prevent tipping.
- Regularly inspect the chair for loose parts or damage. Discontinue use if any damage is found.

2. PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact Bestier customer service.

- Backrest (1)
- Seat Cushion (1)
- Footrest (1)
- Gas Lift Cylinder (1)
- Base with Wheels (1)
- Footrest Support Frame (1)
- Hardware Pack (Screws, Allen Wrench) (1)
- Instruction Manual (1)



Figure 2.1: Exploded view of chair components. This image displays all individual parts included in the package, such as the backrest, seat, footrest, gas lift, base, and hardware.

3. ASSEMBLY INSTRUCTIONS

Assembly typically takes 20-30 minutes. Follow these steps carefully.

1. **Attach Wheels to Base:** Insert the five wheels into the openings on the chair base until they click securely into place.
2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the assembled base.
3. **Assemble Footrest Support:** Attach the footrest support frame to the footrest cushion using the provided screws and Allen wrench.
4. **Attach Backrest to Seat:** Secure the backrest to the seat cushion using the designated screws. Ensure the bentwood support is facing the correct direction.
5. **Connect Seat Assembly to Gas Lift:** Carefully place the assembled seat onto the gas lift cylinder, ensuring it is centered and stable.

6. **Attach Footrest Assembly:** Connect the footrest assembly to the main chair structure as indicated in the diagram, securing it with screws.



Figure 3.1: Initial assembly steps, showing the attachment of the gas lift to the wheeled base.

MOVES WITH YOUR BODY'S NATURAL POSTURE

Reinforced Support Base

2-Level

Adjustable Backrest

(0-6.3")

Adjustable Height System

360°

Swivel Design



Figure 3.2: Intermediate assembly, illustrating how the seat and backrest components are joined.



360° SWIVEL CASTERS

Glides on Hardwood/Carpet /Tile Effortlessly

SUPER-THICK PADDING

Butter-Soft PU Leather
Spill-Proof Surface
Scratch-Resistant Finish



Figure 3.3: Final assembly step, showing the attachment of the footrest to the main chair body.

4. OPERATING INSTRUCTIONS

This chair is designed for ergonomic comfort and versatility. Familiarize yourself with its adjustable features.

4.1. Height Adjustment

To adjust the chair's height (0-6.3 inches range), locate the lever beneath the seat on the right side. While seated, pull the lever up to lower the chair. To raise the chair, stand up and pull the lever up. Release the lever at your desired height.

4.2. Backrest Adjustment

The backrest offers two height positions for customized lumbar support. To adjust, loosen the knob located on the backrest support, slide the backrest to the desired height, and then tighten the knob securely.

4.3. 360° Swivel Function

Both the main seat and the footrest feature a 360-degree swivel design, allowing for easy movement and multi-positional seating. Simply rotate the desired section to adjust your position.



Figure 4.1: The Bestier chair in an office environment, showcasing its design and potential for various seating positions.



Figure 4.2: Visual representation of the chair's adjustable height system, 2-level backrest, and 360-degree swivel design.

5. MAINTENANCE

Proper care will extend the life and appearance of your Bestier chair.

5.1. Cleaning

- For general cleaning, wipe the faux leather surfaces with a soft, damp cloth.
- For spills, immediately blot the area with a clean, dry cloth. The spill-proof surface helps prevent stains.
- Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the faux leather and finish.
- Clean the metal and engineered wood components with a dry or slightly damp cloth.

5.2. General Care

- Periodically check all screws and bolts to ensure they are tight. Retighten as necessary.
- Avoid exposing the chair to direct sunlight or extreme temperatures for prolonged periods.
- Ensure the wheels are free of debris to maintain smooth rolling.



Figure 5.1: Detail view of the super-thick padding and 360-degree swivel casters, highlighting the materials and mobility features.

6. TROUBLESHOOTING

Refer to this section for solutions to common issues.

Problem	Possible Cause	Solution
Chair does not adjust height.	Gas lift cylinder not properly installed or damaged.	Ensure the gas lift is fully inserted into the base and seat mechanism. If still unresponsive, contact customer service.
Chair feels unstable or wobbly.	Loose screws or uneven floor surface.	Check and tighten all assembly screws. Ensure the chair is on a flat, level surface.
Wheels do not roll smoothly.	Debris caught in casters or damaged wheels.	Inspect wheels for hair or debris and remove. If wheels are damaged, contact customer service for replacements.
Backrest slides down after adjustment.	Adjustment knob not tightened sufficiently.	Ensure the backrest adjustment knob is tightened firmly after setting the desired height.

7. SPECIFICATIONS

Feature	Detail
Brand	Bestier
Model Name	Meditation Chair
Model Number	H200571G
Colour	White
Material	Engineered Wood, Faux Leather, Metal, Sponge (Fill Material)
Product Dimensions (D x W x H)	86.4D x 71.1W x 109.2H centimetres (34D x 28W x 43H inches)
Item Weight	14.97 kg (33 lbs)
Maximum Weight Recommendation	136.08 kg (300 lbs)
Special Features	Adjustable Backrest (2 positions), Adjustable Height (0-6.3 inches), Foot Rest, Rolling (360° Swivel Casters), Scratch Resistant Finish
Seat Material Type	Faux Leather
Back Style	Solid Back (Bentwood)
Recommended Uses	Cross Legged, Meditation, Office

Product Size



UNIT: INCH

Figure 7.1: Detailed product size diagram, showing various dimensions of the chair and footrest in inches.

8. WARRANTY AND SUPPORT

Bestier is committed to providing high-quality products and excellent customer service. For any questions, missing parts, or assistance with assembly or operation, please contact our professional after-sales service team. Refer to your purchase documentation for specific warranty details and contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DW85SMZH>

More documents and user manuals: **<https://manuals.plus/>**