

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Wyklaus](#) /

› [Wyklaus Electric Razors for Women - User Manual](#)

Wyklaus FK-8608

Wyklaus Electric Razors for Women - User Manual

Model: FK-8608

INTRODUCTION

The Wyklaus 5-in-1 Electric Shaver for Women is a versatile hair removal tool designed for various body areas, including legs, bikini, face, and lips. It features a 7D floating shaving head for a smooth, painless experience and is suitable for both wet and dry shaving. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.

PRODUCT OVERVIEW AND COMPONENTS

Your Wyklaus Electric Shaver comes with multiple attachments to cater to all your hair removal and facial care needs.



Figure 1: Main unit of the Wyklus 5-in-1 Electric Shaver with the 7D floating shaving head attached.

Included Components:

- Main Shaver Unit with 7D Floating Shaving Head
- Hair Trimmer Head
- Nose Hair Trimmer Head
- Cleansing Brush Head
- Hair Trimmer Combs (3mm, 5mm, 7mm)
- USB Charging Cable
- Cleaning Brush

5-IN-1

WOMEN'S ELECTRIC SHAVER



Nose
Hair Trimmer



Facial
Massage Brush



Hair
Trimmer



Facial
Cleaning Brush

Figure 2: The complete set of attachments, including the hair trimmer, nose hair trimmer, cleansing brush, and various comb sizes.

SETUP

Charging the Device:

Before first use, fully charge the electric shaver. The device features an LED intelligent display that shows the battery percentage.

1. Connect the USB charging cable to the charging port on the shaver.
2. Plug the other end of the USB cable into a compatible USB power source (e.g., USB charger, power bank, car charger, laptop).
3. The LED display will indicate the charging status. A full charge takes approximately 1.5 hours and provides up to 90 minutes of working time.
4. Unplug the device once fully charged.



Figure 3: The shaver can be conveniently charged via various USB power sources, including USB chargers, power banks, car chargers, and laptops.

Attaching/Detaching Heads:

To change the shaver head, gently twist and pull the current head off the main unit. Align the desired head with the main unit and push it down until it clicks securely into place.

OPERATING INSTRUCTIONS

General Operation:

1. Ensure the device is charged.
2. Long press the power button for 3 seconds to turn the shaver ON or OFF.
3. The LED display will show the battery level and a water washing reminder when needed.
4. To activate the travel lock, long press the switch button for 3 seconds. This prevents accidental power consumption.

Shaving (Wet & Dry):

The Wyklaus shaver is IPX6 waterproof, allowing for both wet and dry shaving.

- **Dry Shaving:** For quick touch-ups, use the shaver on dry skin. The 7D floating head is designed to follow body contours for a close, painless shave without nicks or irritation.
- **Wet Shaving:** For a refreshing experience, use the shaver in the shower or bath with foam or gel.



Figure 4: The shaver is suitable for both wet shaving in the shower or bath and dry shaving for convenience.

Using Different Heads:

- **7D Floating Shaving Head:** Ideal for large areas like legs, arms, and bikini line. Move the shaver in circular motions or against the direction of hair growth for optimal results.
- **Hair Trimmer Head:** Use for trimming longer hair before shaving or for precise trimming in sensitive areas. Attach the appropriate comb (3/5/7mm) for desired hair length.
- **Nose Hair Trimmer Head:** Carefully insert the trimmer into the nostril or ear canal to trim unwanted hair.
- **Cleansing Brush Head:** Attach for facial cleansing. Apply your preferred cleanser to your face or the brush head and gently move in circular motions.




Figure 5: The versatile design allows for use on arms, legs, bikini area, and face with specialized attachments.

MAINTENANCE

Cleaning the Shaver:

Regular cleaning ensures optimal performance and hygiene. The shaver is IPX6 waterproof, making cleaning easy.

1. Turn off the shaver and detach the head.
2. Rinse the detached head and the main unit (if necessary) under running water to remove hair and debris.

3. Use the provided cleaning brush to remove any stubborn hair particles from the blades and internal components.
4. Allow all parts to air dry completely before reattaching the head or storing the device.



Figure 6: The package includes a small brush for detailed cleaning of the shaver heads.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Low battery; Travel lock activated.	Charge the device fully. Long press the power button for 3 seconds to deactivate travel lock.
Poor shaving performance.	Blades are dull or clogged with hair; Head not properly attached.	Clean the shaving head thoroughly. Ensure the head is securely attached. Consider replacing the head if blades are dull.
Skin irritation after shaving.	Improper technique; Sensitive skin.	Ensure you are shaving gently and not applying excessive pressure. Try wet shaving with shaving cream/gel. Apply a soothing lotion after shaving.

SPECIFICATIONS

Model Name: FK-8608

Power Source: Battery Powered

Special Features: Dry Shave, Anti-Scratch, Cordless, Ergonomic Design, Battery Indicator

Recommended Uses: Legs, Bikini, Face, Lips, Arms, Ankles

Waterproof Rating: IPX6 (Whole body washable)

Battery Capacity: 600mAh

Charging Time: Approximately 1.5 hours

Working Time: Approximately 90 minutes

Product Dimensions: 2 x 2 x 2 inches

Item Weight: 15.2 ounces

Manufacturer: Wyklus

Country of Origin: China

IMPORTANT SAFETY INFORMATION

Please read all safety instructions before using the device. Keep this manual for future reference.

- Do not disassemble or attempt to repair the device yourself.
- Keep out of reach of children.
- Do not use if the device or charging cable is damaged.
- Avoid using on irritated, broken, or infected skin.
- Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

WARRANTY AND SUPPORT

For any questions, concerns, or warranty claims regarding your Wyklus Electric Shaver, please contact the manufacturer directly through the seller's contact information on the purchase platform or visit the official Wyklus store for support.

Wyklus Store: [Visit Wyklus Store on Amazon](#)