

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Samsonite](#) /
- › [Samsonite Intuo Spinner L Suitcase User Manual](#)

## Samsonite Intuo Spinner L

# Samsonite Intuo Spinner L Suitcase User Manual

Model: Intuo Spinner L (75 cm - 115 L)

## INTRODUCTION

---

Thank you for choosing the Samsonite Intuo Spinner L suitcase. This manual provides essential information for the proper use, care, and maintenance of your new luggage. Please read these instructions carefully before using your suitcase to ensure a pleasant travel experience and to maximize the lifespan of your product.



*Image: Front view of the Samsonite Intuo Spinner L suitcase, showcasing its hard shell and wave-like design.*

## PRODUCT OVERVIEW

---

The Samsonite Intuo Spinner L is a durable and spacious hard-shell suitcase designed for extended travel. It features four spinner wheels for effortless maneuverability, an adjustable telescopic handle, and an integrated TSA combination lock for security. The interior is thoughtfully designed with packing straps and compartments to keep your belongings organized.



*Image: Size comparison chart illustrating different suitcase sizes (S, M, L, XL) relative to human figures, indicating the 'L' size for 2-week trips.*

## SETUP AND INITIAL USE

### Setting the TSA Combination Lock

Your Samsonite Intuo suitcase is equipped with an integrated TSA-approved combination lock. The initial combination is set to 0-0-0.

1. Open the suitcase by sliding the TSA lock release button (if applicable) or by entering the default 0-0-0 combination and pressing the release button.
2. Locate the small reset button (often a small, recessed button) next to the dials. Use a pen or a pointed object to press and hold this button until you hear a click.
3. While holding the reset button, set your desired 3-digit combination by turning the dials. Choose a memorable combination.
4. Release the reset button. You should hear another click, indicating the new combination is set.
5. Test your new combination by scrambling the dials and then entering your new code to open the lock.

**Important:** Do not forget your combination. Samsonite cannot provide combination codes for security reasons.



*Image: Close-up view of the integrated TSA combination lock on the side of the suitcase, showing the three-digit dials and the release mechanism.*

## **OPERATING INSTRUCTIONS**

---

### **Using the Telescopic Handle**

The suitcase features a multi-stage telescopic handle for comfortable maneuvering. Press the button located on the top of the handle to extend or retract it to your desired height. Ensure the handle is fully retracted when checking in or storing the suitcase to prevent damage.



*Image: Top view of the suitcase handle, showing the ergonomic grip and an integrated pull-out ID tag for personal information.*

### **Maneuvering with Spinner Wheels**

Your Intuo Spinner L suitcase is equipped with four 360-degree spinner wheels, allowing for smooth and effortless movement in any direction. Push or pull the suitcase upright on all four wheels for optimal maneuverability, especially in crowded areas. For rougher surfaces, you may tilt the suitcase and pull it on two wheels.



*Image: Close-up of one of the durable spinner wheels, designed for smooth 360-degree rotation.*

### **Using the Expansion Feature**

The Intuo Spinner L suitcase features an expandable zipper to increase packing capacity. To expand, simply unzip the secondary zipper located around the perimeter of the suitcase. To return to its original size, ensure the suitcase is not overpacked and zip it back up.



*Image: Side view of the suitcase, highlighting the main zipper, the expansion zipper, the integrated TSA lock, and the side carry handle.*

### **Packing the Interior**

The interior of your suitcase is designed for efficient packing. Utilize the cross-straps to secure your clothing and prevent shifting during transit. The zippered divider panel helps separate items and provides additional pockets for smaller belongings.



*Image: The suitcase opened, revealing the spacious interior with a zippered divider on one side and elastic cross-straps on the other for secure packing.*



*Image: Close-up of the interior showing the adjustable packing straps and the patterned lining.*

## MAINTENANCE AND CARE

---

- **Cleaning the Exterior:** Wipe the hard shell with a soft cloth dampened with mild soap and water. Avoid abrasive cleaners or solvents.
- **Cleaning the Interior:** Vacuum the interior to remove dust and debris. Spot clean any stains with a gentle fabric cleaner.
- **Wheel Maintenance:** Periodically check the wheels for debris (hair, lint) and remove them to ensure smooth rolling. Lubrication is generally not required.

- **Zipper Care:** Keep zippers clean and free of obstructions. If a zipper becomes stiff, apply a small amount of zipper lubricant or wax.
- **Storage:** Store your suitcase in a cool, dry place, away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

---

### Lock Issues

- **Cannot open lock:** Ensure you are using the correct 3-digit combination. If you have forgotten it, unfortunately, Samsonite cannot assist in resetting it without the original code. You may need to contact a locksmith or a Samsonite service center for assistance.
- **Reset button stuck:** Ensure you are using a thin, pointed object to fully depress the reset button.

### Wheel Issues

- **Wheels not rolling smoothly:** Check for hair, lint, or other debris wrapped around the wheel axles. Carefully remove any obstructions.
- **Wobbly wheels:** This can sometimes occur with heavy loads or uneven surfaces. Ensure the suitcase is not overloaded beyond its capacity.

### Handle Issues

- **Handle stuck:** Ensure the release button is fully pressed. Check for any obstructions in the handle mechanism. Avoid forcing the handle.

## SPECIFICATIONS

---

Feature	Detail
Brand	Samsonite
Model	Intuo Spinner L
Size	75 cm - 115 L
Dimensions (L x W x H)	75L x 31W x 75H centimetres
Item Weight	1000 Grams (1 kg)
Material Type	Polypropylene (PP)
Shell Type	Hard
Wheel Type	Spinner (4 wheels)
Lock Type	TSA Combination Lock
Strap Type	Adjustable (Internal packing straps)
Color	Black
Pattern	Solid
ASIN (Current Product)	B0CX4YSG26

Feature	Detail
ASIN (Parent Product)	B0DW8N3SQL

## WARRANTY INFORMATION

---

Samsonite products are rigorously tested to ensure they meet stringent standards. If a problem occurs with this Samsonite product (the "Product") and the problem is caused by manufacturing defects in material and workmanship, Samsonite will, in its discretion, either repair or replace the Product in accordance with the warranty terms and conditions stated on their official website. This warranty does not cover damage caused by misuse, neglect, accidents, abrasion, extreme temperatures, solvents, acids, water, normal wear and tear, or transport damage (by airlines, for example).

For specific warranty details and to register your product, please visit the official Samsonite website or contact their customer service.

## CUSTOMER SUPPORT

---

For further assistance, inquiries, or to locate an authorized service center, please refer to the official Samsonite website or contact their customer service department. Contact details can typically be found in the "Contact Us" or "Support" section of their website.

**Samsonite Official Website:** [www.samsonite.com](http://www.samsonite.com)