Conyat Q16

Conyat Q16 Wireless Earbuds User Manual

Model: Q16

1. Introduction

Thank you for choosing the Conyat Q16 Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your new earbuds. Please read this manual carefully before use to ensure optimal performance and longevity of your device.

What's in the Box

- Headphones (Left/Right) x 2
- USB-C charging cable x 1
- Portable charging box x 1
- User manual x 1



Image: The Conyat Q16 Wireless Earbuds in their charging case, displaying the digital battery level. This image shows the sleek black design of the earbuds and the compact charging case.

---

2. Setup

2.1 Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C charging cable to the charging port on the case and a power source. The digital LED display on the case will show the charging status and battery levels.

2.2 Pairing with Your Device

The Conyat Q16 earbuds feature one-step pairing. Once taken out of the charging case, they will automatically enter pairing mode and reconnect to the last paired device. If pairing for the first time:

1. Ensure the earbuds are fully charged.

2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth.
4. Search for Bluetooth devices and select "Q16" from the list.
5. Once connected, a voice prompt will confirm successful pairing.




Image: A visual representation of the one-step pairing process, showing the earbuds in their case and a smartphone screen with 'Q16' listed under Bluetooth devices, indicating successful connection.

3. Operating Instructions

3.1 Touch Controls

The Conyat Q16 earbuds feature sensitive touch control panels on both the left and right earbuds for easy management of audio and calls. Refer to the table below for specific functions:

Action	Left Earbud (L)	Right Earbud (R)
Play/Pause	Double tap L/R	

Action	Left Earbud (L)	Right Earbud (R)
Volume Up		One tap R
Volume Down	One tap L	
Next Track		Long tap 2s R
Previous Track	Long tap 2s L	
Answer Call	One tap L/R	
Hang Up Call	Long tap 2s L/R	
Voice Assistant	Triple tap L/R	



Image: A diagram illustrating the various touch control functions on the Conyat Q16 earbuds, including play/pause, volume adjustment, track skipping, call management, and voice assistant activation.

3.2 Single Ear Mode / Binaural Mode

The earbuds can be used individually (single ear mode) or together (binaural mode). Simply take one

earbud out of the case to use it independently, or both for stereo sound.

---

4. Comfort and Fit

For optimal sound quality and comfort, select the ear tips that best fit your ear canal. The Conyat Q16 earbuds come with three different sizes (S, M, L) of soft ear tips.

1. Try each size to find the one that provides a secure yet comfortable seal.
2. A good seal is crucial for bass response and noise isolation.



Image: A visual guide showing the three different ear tip sizes (Small, Medium, Large) included with the Conyat Q16 earbuds, emphasizing comfortable fit.

---

5. Battery Life and Charging

The Conyat Q16 earbuds offer extended playback time:

- **Single Charge:** Up to 8 hours of playback.
- **With Charging Case:** Up to 48 hours of total playback.

5.1 Digital Power Display

The charging case features a dual digital LED power display, showing the battery level of the charging case and the individual charging status of each earbud.



Image: An illustration demonstrating the long battery life of the Conyat Q16 earbuds, highlighting 8 hours on a single charge and 48 hours total with the charging case, along with the digital display.

---

6. Maintenance

6.1 Cleaning

Regular cleaning helps maintain sound quality and hygiene:

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- Gently remove any earwax or debris from the ear tips and speaker mesh using a small, soft brush or cotton swab.
- Do not use abrasive cleaners, alcohol, or chemical solvents.

6.2 Water Resistance (IPX7)

The earbuds have an IPX7 waterproof rating, meaning they are resistant to splashes and sweat. They can withstand immersion in water up to 1 meter for 30 minutes. However, the charging case is not waterproof. Do not expose the charging case to liquids.



Image: A visual representation of the IPX7 waterproof rating, showing the earbuds being splashed with water, indicating their resistance to sweat and rain.

6.3 Storage

Store the earbuds in their charging case when not in use to protect them and keep them charged.

---

7. Troubleshooting

If you encounter issues with your Conyat Q16 earbuds, please refer to the following common solutions:

- **Earbuds not pairing:** Ensure both earbuds are out of the case and fully charged. Turn off and on your device's Bluetooth, then try pairing again.
- **Only one earbud working:** Place both earbuds back into the charging case, close the lid, wait a few seconds, then take them out again. This often resets their connection.
- **No sound:** Check the volume level on both your device and the earbuds. Ensure the earbuds are properly connected to your device.
- **Poor sound quality:** Ensure the ear tips provide a good seal in your ear. Clean any debris from the speaker mesh. Move closer to your connected device to avoid interference.
- **Earbuds not charging:** Ensure the charging cable is securely connected to both the case and the power source. Check if the charging contacts on the earbuds and inside the case are clean.

7.1 Factory Reset

If issues persist, a factory reset may resolve them. Consult the specific reset procedure in the included quick start guide or contact customer support for detailed instructions.

---

8. Specifications

Feature	Specification

Feature	Specification
Model Name	Q16
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.4
Bluetooth Range	15 Millimeters (approx. 49 feet)
Battery Life (Single Charge)	8 Hours
Total Playback Time (with Case)	48 Hours
Water Resistance Level	IPX7
Audio Driver Type	Dynamic Driver (13mm speakers)
Frequency Range	20 Hz - 20,000 Hz
Control Method	Touch
Microphone	Built-in ENC Noise Reduction Mic
Compatible Devices	Smartphones, Tablets, Laptops, Smart Speakers (iOS, Android)
Item Weight	3.52 ounces

9. Warranty and Support

Conyat products are designed and manufactured to the highest quality standards. For information regarding warranty coverage and terms, please refer to the warranty card included in your product packaging or visit the official Conyat website.

9.1 Customer Support

If you have any questions, require technical assistance, or experience any issues not covered in this manual, please contact Conyat customer support. Contact details can typically be found on the product packaging, the official Conyat website, or through your purchase platform.

© 2025 Conyat. All rights reserved.