

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Arwibon GT08

Arwibon GT08 60V 5A Battery Charger User Manual

Model: GT08

PRODUCT OVERVIEW

The Arwibon GT08 60V 5A Battery Charger is designed for charging electric scooter batteries. This manual provides essential information for safe and effective use, including setup, operation, maintenance, and troubleshooting.



This image displays the Arwibon GT08 60V 5A Battery Charger. The charger unit is black and rectangular, with a power input cable and a charging output cable. The power input cable has a standard two-prong plug, and the charging output cable has a specialized connector for electric scooters. Text on the charger unit provides model information, input/output specifications, and important safety warnings.

SAFETY INFORMATION

Please read and understand all safety instructions before using the charger. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Indoor Use Only:** This charger is designed for indoor use. Do not expose it to dampness, rain, or any liquids.
- **Battery Compatibility:** Only use this charger with compatible rechargeable batteries as specified by the electric scooter manufacturer. Do not attempt to charge non-rechargeable batteries, as this can lead to explosion or fire.
- **High Voltage Warning:** The charger contains high internal voltage. Do not open the charger casing under any circumstances. There are no user-serviceable parts inside.
- **Damaged Power Cord:** If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or

similarly qualified persons to avoid a hazard. Do not use the charger with a damaged cord.

- **Connection Sequence:** Always connect the charger to the battery first, then plug the charger into the power outlet. When disconnecting, unplug the charger from the power outlet first, then disconnect from the battery.
- **Power Off:** Ensure the power supply is switched off before connecting or disconnecting the charger.
- **Ventilation:** Ensure adequate ventilation around the charger during operation. Do not cover the charger.
- **Children and Pets:** Keep the charger out of reach of children and pets.

SETUP

1. **Unpack:** Carefully remove the charger from its packaging. Inspect the charger and cables for any signs of damage.
2. **Placement:** Place the charger on a stable, flat, and non-flammable surface in a well-ventilated area. Ensure it is away from direct sunlight, heat sources, and flammable materials.
3. **Power Source:** Ensure the power outlet matches the input voltage requirements of the charger (180 Volts).

OPERATING INSTRUCTIONS

1. **Connect to Battery:** With the charger unplugged from the wall outlet, connect the charging output cable of the GT08 charger to the charging port on your electric scooter's battery. Ensure a secure connection.
2. **Connect to Power:** Plug the charger's power cord into a suitable 180V AC wall outlet.
3. **Charging Indicator:** The charger typically has an indicator light. A red light usually indicates charging in progress, while a green light indicates charging is complete or standby. Refer to your scooter's manual for specific charging light behavior.
4. **Monitor Charging:** Do not leave the battery charging unattended for extended periods.
5. **Disconnect:** Once charging is complete (indicated by the light turning green, if applicable), first unplug the charger from the wall outlet. Then, disconnect the charging cable from the scooter's battery.

Note: Charging times vary depending on the battery capacity and its current charge level.

MAINTENANCE

- **Cleaning:** Disconnect the charger from all power sources and the battery before cleaning. Use a soft, dry cloth to wipe the exterior of the charger. Do not use liquid cleaners or solvents.
- **Storage:** Store the charger in a cool, dry place when not in use. Avoid extreme temperatures and humidity. Keep cables neatly coiled to prevent damage.
- **Inspection:** Periodically inspect the charger, power cord, and charging cable for any signs of wear, cuts, or damage. If any damage is found, discontinue use and seek professional assistance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Charger not working / No indicator light	No power from outlet Charger not properly plugged in Damaged power cord	Check the wall outlet with another device. Ensure both ends of the power cord are securely connected. Inspect the power cord for damage. If damaged, do not use.

Problem	Possible Cause	Solution
Battery not charging	Loose connection to battery Incompatible battery Battery fault	Ensure the charging cable is firmly connected to the scooter's battery port. Verify that your scooter's battery is compatible with a 60V 5A charger. Consult your scooter's manual or a professional for battery diagnosis.
Charger gets hot during use	Normal operation (some heat is expected) Poor ventilation Overload or internal fault	Ensure adequate airflow around the charger. If excessively hot or emitting smoke/smell, immediately unplug and discontinue use. Contact support.

SPECIFICATIONS

Model: GT08

Brand: Arwibon

Input Voltage: 180 Volts

Output Current: 5 Amperes

Output Voltage: 60 Volts

Product Dimensions: 9 x 4.7 x 2.4 inches (22.86 x 11.94 x 6.1 cm)

Item Weight: 1.12 pounds (0.51 kg)

Color: Black

Date First Available: February 6, 2025

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact Arwibon customer service directly. Specific warranty terms and support channels may vary.

Please note: This manual does not constitute a warranty.