

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [PGYTECH](#) /

> [PGYTECH OneGo Rope Strap Camera Bag \(Model P-CB-411\) Instruction Manual](#)

PGYTECH P-CB-411

PGYTECH OneGo Rope Strap Camera Bag

Model P-CB-411 User Instruction Manual

1. OVERVIEW

The PGYTECH OneGo Rope Strap Camera Bag (Model P-CB-411) is designed for urban photographers seeking a versatile and lightweight solution for carrying camera gear. This bag offers multiple carrying options, expandable storage, and protective features to keep your equipment secure.

Key features include an ultralight design at only 370g, multi-protective padding, a sleek aesthetic, and a 4-in-1 carrying system that allows for shoulder, crossbody, underarm, or hand-carry styles. Its smart storage details, including adjustable dividers and specialized pockets, ensure efficient organization, while splash-resistant nylon provides protection against the elements.




Figure 1: PGYTECH OneGo Rope Strap Camera Bag highlighting its versatile design.

2. SETUP

2.1 Unpacking

Carefully remove the camera bag from its packaging. Inspect the bag for any signs of damage. Ensure all components, including the shoulder strap and internal dividers, are present.

2.2 Strap Adjustment and Carrying Styles

The OneGo Rope Strap Camera Bag features a versatile rope strap system that allows for quick adjustments to suit various carrying preferences:

- **Shoulder Carry:** Adjust the strap to a comfortable length to wear over one shoulder.
- **Crossbody Carry:** Lengthen the strap to wear across your body for added security and weight distribution.
- **Underarm Carry:** Shorten the strap and tuck the bag snugly under your arm for a compact hold.
- **Hand-Carry:** The rope straps can be configured to form a convenient handle for hand-carrying.



Functional Everyday Style



Figure 2: Demonstrating the four versatile carrying styles of the bag.

2.3 Internal Configuration

The bag includes adjustable hook-and-loop dividers to customize the internal compartments. These dividers allow you to securely fit your camera body, lenses, and other accessories, preventing them from shifting during transport.

Secure Your Gear with All-round Protection



Figure 3: Internal view with adjustable dividers securing camera gear.

Your browser does not support the video tag.

Video 1: Official PGYTECH video demonstrating the features and versatility of the OneGo Rope Strap Camera Bag.

3. OPERATING THE BAG

3.1 Standard and Expanded Capacity

The bag offers flexible storage options:

- **Standard Mode:** Comfortably accommodates one mirrorless camera body and up to two small lenses.
- **Extended Mode:** For larger lenses, such as a 70-200mm, locate the hidden zipper at the bottom of the bag. Unzipping this expands the bag's depth, providing additional space without adding significant bulk.

Pack More With Expandable Capacity

A hidden zipper at the bottom unlocks additional space for maximum flexibility and functionality



Before Expansion

One compact mirrorless camera + two small lenses



After Expansion

One camera + one 70-200mm lens



Figure 4: Visual representation of the bag's expandable capacity.

3.2 Accessory Storage

Utilize the various internal pockets for organizing smaller items:

- **Zippered Pockets:** Ideal for securing small valuables like memory cards, batteries, or personal items.
- **Elastic Holders:** Keep cables, lens caps, or other small accessories neatly in place.
- **Integrated Hidden Pocket:** A discreet pocket is included to prevent loss of small, important items, such as a locator device.

Adjustable Shoulder Strap

Easily adjust the length for best fit or remove the strap.



Figure 5: Detailed view of the bag's smart storage features.

4. MAINTENANCE

4.1 Cleaning

To clean the bag, use a soft, damp cloth with mild soap. Gently wipe down the exterior and interior surfaces. Avoid harsh chemicals or abrasive materials, as these may damage the fabric or water-repellent coating. Allow the bag to air dry completely before storing or using.

4.2 Water Resistance

The bag is constructed with splash-resistant nylon and features water-repellent reinforced seams and high-quality YKK zippers. This design provides protection against light rain and splashes, making it suitable for outdoor adventures in varying weather conditions. However, it is not fully waterproof and should not be submerged in water.



Figure 6: The bag's splash-resistant material in action.

4.3 Storage

When not in use, store the bag in a cool, dry place away from direct sunlight to preserve its material integrity and color.

5. TROUBLESHOOTING

5.1 Limited Internal Space

If you find the internal space insufficient for your gear, ensure the bottom expansion zipper is fully unzipped. Reconfigure the adjustable dividers to optimize space for your specific camera and lenses. Consider removing non-essential items to maximize available room.

5.2 Strap Slippage

If the shoulder strap feels slippery or does not stay in place, try adjusting its length to achieve a more secure fit. Experiment with different carrying styles (e.g., crossbody) which often provide better stability and prevent

slippage, especially when wearing smooth fabrics.

6. SPECIFICATIONS

Feature	Detail
Model Number	P-CB-411
Item Weight	0.37 kg (0.82 lbs)
Package Dimensions	40.28 x 29.11 x 6.4 cm (15.86 x 11.46 x 2.52 inches)
Material	Splash-resistant Nylon, Polyurethane fabric
Zippers	YKK

The bag is designed to be ultralight, weighing approximately 370g (0.82 lbs), ensuring comfortable carry throughout the day.

LightWeight and Comfortable Carry



Figure 7: Highlighting the ultralight design of the bag.

7. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official PGYTECH website or contact their customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

You can visit the PGYTECH Store for more information: [PGYTECH Store](#)