

Manuals.plus /

› Calor /

› Calor Virtuo 30 Steam Iron User Manual, 2000W, FV2C42C0

Calor FV2C42C0

Calor Virtuo 30 Steam Iron User Manual

Model: FV2C42C0

INTRODUCTION

The Calor Virtuo 30 steam iron is designed for efficient and easy ironing. With 2000W power, a ceramic soleplate, and various steam functions, it provides effective garment care. This manual provides instructions for safe operation, maintenance, and troubleshooting to ensure optimal performance of your appliance.

IMPORTANT SAFETY INSTRUCTIONS

- Always ensure the voltage indicated on the iron matches your mains supply.
- Do not leave the iron unattended when it is switched on or connected to the mains.
- Keep the iron and its cord out of reach of children.
- Never immerse the iron, cord, or plug in water or any other liquid.
- Unplug the iron from the electrical outlet before filling with water, cleaning, or when not in use.
- Do not operate the iron with a damaged cord or plug, or if the iron has been dropped or damaged.
- Place the iron on a stable, heat-resistant surface when resting.
- Use the iron only for its intended household purpose.

PRODUCT OVERVIEW

Familiarize yourself with the main components of your Calor Virtuo 30 steam iron.





Image: The Calor Virtuo 30 steam iron, showcasing its design and key features.



Image: Close-up of the ceramic soleplate, designed for smooth gliding and durability.



Image: The precision tip of the iron, ideal for reaching difficult areas like collars and button plackets.

SETUP

Before First Use

1. Remove any labels or protective film from the soleplate.
2. Clean the soleplate with a soft, damp cloth.
3. It is recommended to iron an old piece of fabric for a few minutes to remove any manufacturing residues.

Filling the Water Tank

1. Ensure the iron is unplugged from the power outlet.
2. Open the water tank inlet cover.
3. Fill the water tank with tap water up to the 'MAX' level indicator. Do not overfill.
4. Close the water tank inlet cover securely.

OPERATING INSTRUCTIONS

Temperature Adjustment

Plug in the iron. Turn the temperature dial to the desired setting according to the fabric type. The indicator light will illuminate and turn off when the set temperature is reached. The iron heats up quickly, typically within 30 seconds.

Dry Ironing

For dry ironing, ensure the steam control is set to the 'no steam' position. Select the appropriate temperature for your fabric and wait for the indicator light to turn off before beginning.

Steam Ironing

For steam ironing, fill the water tank. Set the temperature dial to the steam zone (usually indicated by three dots or a steam symbol). Once the indicator light turns off, select the desired steam level using the steam control. The iron provides a continuous steam output of 27g/minute for effective wrinkle removal.



Image: The iron in operation, demonstrating its efficient steam output for quick wrinkle removal.

Powerful Pressing Function (Steam Boost)

To remove stubborn creases or iron thick fabrics, use the powerful pressing function. Press the steam boost button for an extra burst of steam (120g/minute). This function is most effective at higher temperatures.



Image: A user demonstrating the powerful pressing function to smooth out thick fabrics and stubborn wrinkles.

Vertical Steaming

The iron can be used for vertical steaming to refresh hanging garments, curtains, or delicate fabrics. Hold the iron vertically, press the steam boost button, and direct the steam towards the fabric. Ensure the iron is at a high temperature setting for optimal steam production.

Anti-Drip Protection

The integrated anti-drip system prevents water droplets from staining your garments, even when ironing at lower temperatures. If you notice dripping, ensure the iron has reached the correct temperature for steam ironing.



Image: Illustration of the anti-drip protection feature, ensuring no water stains on your clothes during ironing.

MAINTENANCE AND CARE

Cleaning the Soleplate

- Always unplug the iron and allow it to cool completely before cleaning.
- Wipe the soleplate with a damp cloth and a non-abrasive cleaner if necessary.
- Do not use abrasive pads, scourers, or chemical cleaners as they can damage the ceramic coating.

Descaling (Self-Clean Function)

To maintain steam performance and prevent limescale buildup, use the self-clean function regularly (e.g., once a month, depending on water hardness).

1. Fill the water tank to the MAX level.
2. Set the temperature to maximum and plug in the iron.

3. Once the indicator light turns off, unplug the iron.
4. Hold the iron horizontally over a sink.
5. Press and hold the self-clean button (if available, refer to specific model markings) or the steam boost button while shaking the iron gently. Hot water and steam will be expelled from the soleplate, carrying limescale particles.
6. Continue until the water tank is empty.
7. Reheat the iron and iron an old cloth to dry the soleplate.

Storage

After use, unplug the iron and allow it to cool completely. Empty any remaining water from the tank. Store the iron upright in a safe, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet fault; temperature dial set to minimum.	Check power connection; test outlet with another appliance; turn temperature dial to a higher setting.
No steam or insufficient steam.	Water tank empty; temperature too low for steam; steam control set to 'no steam'; limescale buildup.	Fill water tank; set temperature to steam zone; adjust steam control; perform descaling.
Water drips from the soleplate.	Temperature too low for steam; water tank overfilled.	Increase temperature to steam zone; do not overfill water tank.
White flakes or brown stains on clothes.	Limescale buildup; impurities in water.	Perform descaling; use distilled or demineralized water if tap water is very hard.

TECHNICAL SPECIFICATIONS

- **Model:** FV2C42C0
- **Power:** 2000 Watts
- **Continuous Steam Output:** 27 g/min
- **Steam Boost (Pressing Effect):** 120 g/min
- **Soleplate Material:** Ceramic
- **Water Tank Capacity:** 240 ml
- **Dimensions (L x W x H):** 31 x 14 x 18 cm
- **Weight:** 1.15 kg



Image: Diagram illustrating the physical dimensions of the Calor Virtuo 30 steam iron.

WARRANTY AND SUPPORT

Calor is committed to product durability. This appliance benefits from a 15-year reparability commitment at a fair price, supported by a network of 6200 repairers worldwide. This initiative aims to contribute to environmental protection and waste reduction.

For further assistance, troubleshooting not covered in this manual, or to locate a repair center, please visit the official Calor website or contact customer support.

You can find more information and support at: [Calor Official Store](#)