

Airpher HS827D

Airpher HS827D Cordless Vacuum Cleaner with Mop Function User Manual

Model: HS827D | Brand: Airpher

1. INTRODUCTION

Thank you for choosing the Airpher HS827D Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient use of your new appliance. The HS827D is a versatile cleaning tool featuring powerful 55000Pa suction, a convenient mop function, a lightweight design, and quiet operation, making daily cleaning tasks easier and more effective.

Please read this manual thoroughly before first use and keep it for future reference.



Airpher 常識を超えた一台で二役 水拭きコードレス掃除機

55000kpaの強力吸引力で、すべての汚れを簡単に吸引。
HEPAろ過システムでダニやほこりをしっかりろ過。
33分の長時間バッテリー、軽量で耐久性も抜群。
多機能アクセサリーで、掃除と床拭きを同時にこなせる。
プレミアム銅製モーター&アルミ合金パイプで、耐久性と長寿命を実現。

Figure 1.1: Airpher HS827D Cordless Vacuum Cleaner in action, demonstrating its powerful suction on different types of debris.

2. SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury, please observe the following safety precautions:

- Read all instructions before using the appliance.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not handle charger or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Exercise extra care when cleaning on stairs.
- Do not use without dust cup and/or filters in place.
- Prevent unintentional starting. Ensure the switch is in the off-position before connecting to battery pack, picking up or carrying the appliance.

3. PACKAGE CONTENTS

Carefully unpack your Airpher HS827D and check that all items are present and in good condition. If any items are missing or damaged, please contact customer support.

- Main Vacuum Unit
- Extension Pipe
- Floor Brush Head
- Multi-purpose Nozzle (Crevice Tool) x1
- HEPA Filter x1
- Wall Mount Bracket x1
- Floor Mop Pads x3
- Water Tank x1
- Charger x1
- Screw Pack x1
- Cleaning Brush x1
- Instruction Manual x1

完璧な伸縮性、自由自在に調整

最長**73cm**

必要な時に素早く調整でき、どんな角度や高さでも完璧に掃除できます。

アルミニウム合金製伸縮パイプ

プラスチック製とは異なり、アルミニウム合金製のは耐久性に優れ、長期間の使用にも耐える強度を誇ります。

静音設計 < 70db



Figure 3.1: Included accessories with the Airpher HS827D.

4. PRODUCT FEATURES

- **Powerful Suction:** Equipped with a premium copper motor, providing a strong 55000Pa suction power to effectively clean fine dust and larger debris.
- **Wet & Dry Cleaning:** Features a dedicated water tank (250ml capacity) and mop pads, allowing for simultaneous vacuuming and mopping. Easily switch between 'Mop Mode' and 'Suction Only Mode' with a single button.
- **Lightweight Design:** Weighing approximately 1.3kg, this vacuum is easy to maneuver and carry, making it suitable for cleaning high areas, car interiors, and tight spaces.
- **Long Runtime:** The 6600mAh large-capacity lithium battery provides approximately 33 minutes of continuous operation on a full charge, covering large areas without interruption.
- **Quiet Operation:** Designed for low noise, operating at less than 70dB, ensuring a peaceful cleaning experience even during early mornings or late nights.
- **High-Performance HEPA Filter:** Captures 99% of microscopic particles, ensuring clean air output. The filter is washable and reusable for environmental friendliness and cost-effectiveness.
- **Flexible Brush Head:** The brush head rotates 180° horizontally and 90° vertically, allowing easy cleaning under furniture and around corners. Its brushless design prevents hair tangling.
- **Adjustable Extension Pipe:** The aluminum alloy extension pipe can be adjusted up to 73cm, providing flexibility for various cleaning heights and angles.

驚異の**55000PA**吸引力! プレミアム銅製モーター搭載掃除機

55000pa強力吸引力で、すべてのゴミを瞬時に吸引。



静音設計	強力吸引力	でフル充電	高純度銅モーター
< 70db	55000Pa	≈4.5H	4 ~ 6年間

Figure 4.1: Premium Copper Motor and Suction Power.

高性能HEPAフィルター

99%の微細粒子をしっかりキャッチ。強力な吸引力と相まって、空気を清潔に保ちながら、快適な空間を提供します。




Figure 4.2: Integrated Suction and Mop Function.

フル充電で**33分** の連続稼働

ワイヤレスで自由に動かせ、
約**30畳**の広い空間もラクラクお掃除。
軽量で操作も簡単なので、
広い空間でも負担なく使用可能です。



Figure 4.3: Battery Capacity and Runtime.



Figure 4.4: High-Performance HEPA Filter and Cyclone System.

スペースも時間も節約!一台で吸引も拭去掃除も完了。

モップを別で用意する手間なし! コンパクト設計で収納もラクラク、スペースを無駄にしません。



Figure 4.5: Flexible Brush Head for Easy Cleaning.



Figure 4.6: Adjustable Extension Pipe and Versatile Cleaning.

5. SETUP

5.1 Assembly

1. Insert the extension pipe into the main vacuum unit until it clicks securely into place.
2. Attach the floor brush head to the other end of the extension pipe, ensuring it is firmly connected.
3. For handheld use, attach the multi-purpose nozzle directly to the main vacuum unit.
4. To use the mop function, fill the water tank with clean water (and floor cleaning solution if desired) and attach it to the floor brush head. Secure the mop pads to the bottom of the water tank.

5.2 Initial Charging

Before first use, fully charge the vacuum cleaner. Connect the charger to the charging port on the main unit and plug it into a power outlet. The charging indicator light will show the charging status. A full charge takes approximately 4.5 hours.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

Press the power button on the main unit to turn the vacuum cleaner on. Press it again to turn it off.

6.2 Using the Mop Function

1. Ensure the water tank is filled and mop pads are attached to the floor brush head.
2. Locate the ON/OFF switch on the side of the water tank.
3. Slide the switch to 'ON' to activate the mop function, allowing water to dispense onto the mop pads.
4. Slide the switch to 'OFF' to stop water dispensing, using the vacuum for dry suction only.

6.3 Using Different Nozzles

- **Floor Brush Head:** Ideal for general floor cleaning (hardwood, tile, carpet).
- **Multi-purpose Nozzle:** Use for narrow gaps, corners, car interiors, and upholstery. Attach directly to the main unit for handheld use or to the extension pipe for extended reach.

7. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

7.1 Emptying the Dust Cup

1. Press the dust cup release button to detach the dust cup from the main unit.
2. Open the dust cup lid and empty the collected debris into a trash bin.
3. Reattach the dust cup to the main unit, ensuring it clicks into place.

7.2 Cleaning the HEPA Filter

1. Remove the dust cup.
2. Twist and pull out the HEPA filter from the dust cup.
3. Rinse the HEPA filter under running water until clean. Do not use detergent.
4. Allow the filter to air dry completely for at least 24 hours before reinserting it. Ensure it is completely dry to prevent damage and maintain suction power.
5. Reassemble the filter and dust cup, then attach to the main unit.



Figure 7.1: Filter and Mop Cleaning Steps.

7.3 Cleaning Mop Pads and Water Tank

- Remove the used mop pads from the water tank. They are washable and reusable.
- Rinse the water tank and mop pads with clean water.
- Allow all components to air dry completely before reassembly or storage.

7.4 Cleaning the Brush Head

Periodically check the brush head for tangled hair or debris. Use the included cleaning brush or scissors to remove any obstructions. The brushless design minimizes tangling, but occasional checks are recommended.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is low or depleted.	Charge the vacuum cleaner fully.
Weak suction power.	Dust cup is full.	Empty the dust cup.
	HEPA filter is clogged or wet.	Clean and thoroughly dry the HEPA filter.
	Obstruction in the brush head or pipe.	Check and remove any blockages.
Water not dispensing from mop tank.	Water tank is empty.	Refill the water tank.
	Mop function switch is OFF.	Slide the switch on the water tank to 'ON'.
Unusual noise during operation.	Obstruction in the brush head or main unit.	Turn off the vacuum and check for any foreign objects.

If the problem persists after trying these solutions, please contact Airpher customer support.

9. SPECIFICATIONS

Feature	Specification
Brand	Airpher
Model	HS827D
Suction Power	55000Pa
Battery Capacity	6600mAh Lithium Battery
Continuous Runtime	Approx. 33 minutes (on full charge)
Charging Time	Approx. 4.5 hours
Noise Level	<70dB
Filter Type	Washable HEPA Filter
Weight	Approx. 1.3kg
Mop Tank Capacity	250ml
Voltage	100V
Wattage	500W
Product Dimensions (L x W x H)	20 x 18 x 27 cm (Main Unit/Package)

10. WARRANTY AND SUPPORT

Airpher is committed to providing high-quality products and excellent customer service.

- **2-Year Quality Warranty:** Your Airpher HS827D comes with a 2-year warranty from the date of purchase. If any defects or malfunctions occur during this period, please contact us for support.
- **30-Day Return/Refund Guarantee:** If the product performance does not meet your expectations, you may be eligible for a return or refund within 30 days of purchase.
- **Customer Support:** For any questions, concerns, or issues, please contact our customer support team. We are available from 10:00 to 20:00 on weekdays.
- **Warranty Extension:** Register your product as an Airpher member to extend your warranty by an additional year.

Airpher



Figure 10.1: Airpher Warranty and Support Information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DWDLX14P>

More documents and user manuals: <https://manuals.plus/>