



[Manuals.plus](#) /

> [WLIVE](#) /

> WLIVE 5 Drawer Dresser TV Stand User Manual

WLIVE ASNG103HH

WLIVE 5 Drawer Dresser TV Stand User Manual

Model: ASNG103HH | Brand: WLIVE

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your WLIVE 5 Drawer Dresser TV Stand. Designed for versatility, this unit combines storage with a media console, featuring an integrated power outlet for convenience. Please read this manual thoroughly before assembly and use to ensure safe and proper operation.



Image: The WLIVE 5 Drawer Dresser TV Stand, showcasing its design with electronics and decorative items on the top shelf, and the integrated power outlet visible.



Image: The dresser integrated into a bedroom environment, demonstrating its aesthetic appeal and functional placement.

SAFETY INFORMATION

To prevent injury or damage, adhere to the following safety guidelines:

- **Anti-Tipping Device:** Always install the included anti-tipping components to securely fix the dresser to the wall. This is crucial for preventing accidental tipping, especially in households with children or pets.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 50 pounds for the tabletop. Overloading can compromise the unit's stability and structural integrity.
- **Power Outlet Safety:** The integrated power outlet is UL/ETL certified. Ensure that connected devices do not exceed the specified electrical ratings (125V/2A). Avoid using damaged cords or overloading the outlets.
- **Stable Placement:** Place the dresser on a flat, level surface. Use the adjustable feet to ensure stability and prevent wobbling.
- **Assembly:** Follow all assembly instructions carefully. Do not skip steps or use unauthorized parts.



Image: Detailed view of the dresser's structural features, including the anti-tilt device for wall attachment, solid drawer slides for smooth operation, and 360-degree adjustable feet for stability on uneven floors.

COMPONENTS LIST

Before beginning assembly, verify that all parts are present and undamaged. Refer to the detailed assembly guide

included in your package for specific part identification.

- Metal Steel Frame Components
- P2 Grade Artificial Wood Top Panel
- P2 Grade Artificial Wood Middle Shelf
- Fabric Drawers (5 total: 3 small, 2 large)
- Integrated Power Outlet Unit with 1.5m Cable
- Adjustable Feet (4 total)
- Anti-Tipping Kit (Wall anchors, strap)
- Assembly Hardware (Screws, bolts, Allen wrench, etc.)
- Instruction Manual

SETUP AND ASSEMBLY

Assembly of the WLIVE 5 Drawer Dresser TV Stand is designed to be straightforward and can typically be completed within an hour. All necessary tools and clearly marked parts are included.

1. **Unpack and Verify:** Carefully unpack all components and compare them against the provided parts list in the assembly guide.
2. **Assemble Frame:** Begin by assembling the metal steel frame according to the step-by-step diagrams in the assembly guide. Ensure all connections are secure.
3. **Install Shelves:** Attach the P2 grade artificial wood top and middle shelves to the assembled frame.
4. **Insert Power Outlet:** Secure the integrated power outlet unit into its designated slot on the top shelf.
5. **Assemble Drawers:** Construct the fabric drawers by inserting the fiberboard bases and ensuring they are rigid.
6. **Insert Drawers:** Place the assembled fabric drawers into their respective compartments within the frame.
7. **Attach Adjustable Feet:** Screw the adjustable feet into the bottom of the frame. Adjust them to ensure the unit is level and stable on your floor.
8. **Install Anti-Tipping Kit:** For safety, attach the anti-tipping device to the back of the dresser and secure it to a wall stud using the provided hardware.

For detailed visual instructions, please refer to the assembly manual provided in the packaging.



Image: An exploded view highlighting the sturdy steel frame construction, the anti-tipping kit for wall mounting, the multi-layered fabric drawer structure, and the adjustable feet.

OPERATING INSTRUCTIONS

The WLIVE 5 Drawer Dresser TV Stand features a convenient integrated power outlet for your electronic devices.

- **Power Connection:** Plug the dresser's power cord into a standard 125V wall outlet. The 1.5-meter flexible cable provides ample reach.
- **Using AC Outlets:** The unit is equipped with 3 AC sockets. Plug your TV, game console, router, or other electronic devices into these outlets.
- **Controllable Switch:** Use the integrated switch to turn the power to the outlets on or off, providing easy control and energy saving.
- **Drawer Usage:** The 5 detachable fabric drawers (3 small, 2 large) provide ample storage. The smooth slide tracks and ergonomic curved handles ensure easy opening and closing.



Image: A detailed view of the integrated power strip, showing the three AC outlets, the on/off switch, and the 5-foot power cord, with devices charging.



Image: The open shelf area of the dresser, highlighting the integrated power strip and its utility for charging various electronic devices.

MAINTENANCE

Proper care will extend the life and appearance of your dresser.

- **Cleaning Surfaces:** The desktop is made of P2 grade artificial wood, which is scratch-resistant and easy to clean. Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Cleaning Drawers:** The fabric drawers can be spot cleaned with a mild detergent and water. Allow them to air dry completely before reinserting. Do not machine wash.
- **Dusting:** Regularly dust all surfaces with a dry, soft cloth to prevent buildup.
- **Check Connections:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary.

3-TIER DESIGN




Image: An illustration of the drawer's construction, detailing the layers of breathable non-woven fabric and the sturdy MDF board, emphasizing their wear-resistant and durable qualities.

TROUBLESHOOTING

If you encounter any issues with your dresser, refer to the following common solutions:

Problem	Possible Cause	Solution
Dresser is wobbly.	Uneven floor; loose connections.	Adjust the leveling feet at the bottom of the frame. Ensure all assembly screws are tightened.
Drawers do not slide smoothly.	Drawer not properly inserted; obstruction in slide track.	Remove the drawer and reinsert it, ensuring it aligns correctly with the slides. Check for any debris in the tracks.
Power outlets are not working.	Power cord not plugged in; switch is off; circuit overload.	Ensure the power cord is securely plugged into a wall outlet. Check that the controllable switch on the dresser is in the "ON" position. Unplug some devices if overloaded.

SPECIFICATIONS

Feature	Detail
Model Name	ASNG103HH
Product Dimensions	11.73"D x 39.61"W x 30.63"H
Item Weight	27.5 Pounds
Color	Dark Gray
Mounting Type	Floor Mount
Room Type	Bedroom, Closet, Living Room, Playroom
Special Features	Adjustable Feet, Safety Stop (Anti-Tipping), Scratch Resistant
Assembly Required	Yes
Included Components	5-drawer dresser, all parts for installation
Power Outlet	3 AC Sockets, 125V/2A, 1.5m (5-foot) cable, Controllable Switch, UL/ETL Certified
Material	Metal Steel Frame, P2 Grade Artificial Wood, Non-woven Fabric Drawers
TV Size Compatibility	Up to 45 inches

PRODUCT SIZE




Image: A visual representation of the dresser's overall dimensions and the individual drawer sizes, including weight capacities for the top shelf and drawers.

Suitable For TV Size Up To 45"



Image: The dresser with a television placed on top, illustrating its suitability for TVs up to 45 inches in size.

WARRANTY AND SUPPORT

WLIVE is committed to providing high-quality products and excellent customer service. If you have any questions, concerns, or require assistance with assembly or product issues, please do not hesitate to contact our professional after-sales team.

For support, please refer to the contact information provided in your product packaging or visit the official WLIVE store on Amazon: [WLIVE Amazon Store](#).