

Devoko 250063BK

Devoko 80 Gallon Outdoor Storage Deck Box Instruction Manual

Model: 250063BK

1. PRODUCT OVERVIEW

The Devoko 80 Gallon Outdoor Storage Deck Box is designed for outdoor storage. Constructed from waterproof resin with a rattan pattern, it resists fading and rusting, maintaining its appearance in various weather conditions. This storage box offers ample space for items such as furniture cushions, gardening tools, and pool supplies. It can also serve as a two-person seating bench.



Image: Devoko 80 Gallon Deck Box with lid open, filled with cushions and a blanket.

Key Features:

- **Resistant Resin Material:** Waterproof resin construction with a rattan pattern design, preventing fading and rusting.
- **Large Storage Space:** 80-gallon internal capacity suitable for various outdoor items.
- **Clever Function Design:** Features integrated handles for easy mobility, a hydraulic hinge for safe lid operation, and a lockable lid for added security.
- **Dual Purpose:** Functions as both a storage box and a two-person seating bench.

2. SAFETY INFORMATION

- Do not allow children to climb inside the box to prevent entrapment.
- Ensure the box is placed on a stable, level surface to prevent tipping.
- Do not store flammable or hazardous materials inside the box.
- Keep the lid closed when not in use to protect contents from weather and to prevent accidental closure on hands or fingers.
- Observe the weight limit if using as a bench.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.



Hydraulic Hinge



Easy to Move



Securely Locked

Image: Exploded view of the Devoko Deck Box components.

- Side Panels (2)
- Front Panel (1)
- Back Panel (1)
- Bottom Panel (1)
- Lid (1)
- Hydraulic Hinges (2)
- Assembly Instructions (1)

4. ASSEMBLY INSTRUCTIONS

Assembly of the Devoko 80 Gallon Deck Box is designed for quick and easy setup, primarily utilizing a slide-and-click mechanism without requiring additional tools.

1. **Prepare the Base:** Place the bottom panel on a clean, flat surface. Ensure the textured side is facing upwards.
2. **Attach Side Panels:** Align the grooves of the side panels with the edges of the bottom panel. Slide and click them into place. Repeat for all four side panels (front, back, and two sides). Ensure all connections are secure.
3. **Install the Lid:** Position the lid over the assembled base. Attach the hydraulic hinges to the designated points on the back panel and the lid. Ensure the hinges are securely fastened to allow for smooth opening and closing.
4. **Final Check:** Gently open and close the lid to confirm proper function of the hydraulic hinges. Verify all panels are firmly connected.



Image: Illustrative step of connecting side panels during assembly.

5. OPERATING INSTRUCTIONS

Opening and Closing the Lid:

- To open, lift the lid from the front. The hydraulic hinges will assist in a smooth, controlled opening.
- To close, gently pull the lid down. The hydraulic hinges will prevent it from slamming shut.

Using the Lockable Feature:

- The deck box features a designated hole on the front of the lid for a padlock (not included).
- Insert a padlock through the hole to secure the contents of the box.

Mobility:

- Integrated handles are located on both sides of the box for easy lifting and repositioning.
- When moving the box, ensure it is empty or that the weight is manageable to prevent injury.

Using as a Bench:

- The sturdy lid allows the deck box to be used as a two-person seating bench.
- Ensure the lid is fully closed and securely latched before sitting on it.

All Weather Resistant



UV Protection



Waterproof



Image: Close-up of hydraulic hinge, side handle, and lockable latch.

6. MAINTENANCE

- **Cleaning:** Wipe down the exterior with a damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals that could damage the resin. Rinse thoroughly with water.
- **Inspection:** Periodically check the hinges and panel connections for any signs of wear or damage. Ensure the lid seals properly to maintain waterproof integrity.
- **Winter Storage:** While designed for all-weather use, consider storing the box in a sheltered area during extreme winter conditions to prolong its lifespan. Ensure it is clean and dry before storage.

7. TROUBLESHOOTING

- **Lid not closing properly:** Check for any obstructions around the hinges or along the rim of the box. Ensure the box is on a level surface.

- **Water inside the box:** Verify that the lid is fully closed and sealed. Inspect the seals around the lid for any damage or gaps. Ensure the box is not placed in an area where water can pool around its base.
- **Panels separating:** Re-check all snap-together connections. Apply firm pressure to ensure they are fully engaged.

8. SPECIFICATIONS

Attribute	Detail
Brand	Devoko
Model Number	250063BK
Color	Black
Material	Resin
Product Dimensions (L x W x H)	45.3" x 19.2" x 20.8"
Capacity	80 Gallons
Closure Type	Flip Top
Water Resistance Level	Waterproof
Special Feature	Lockable
Item Weight	30 Pounds

Product Dimension



Image: Product dimensions diagram.

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the product packaging or contact Devoko customer service directly. Keep your purchase receipt for warranty claims.