

RAPSUAR 91580060

RAPSUAR 88 oz Slushie Maker Machine Instruction Manual

Model: 91580060

INTRODUCTION

Thank you for choosing the RAPSUAR 88 oz Slushie Maker Machine. This appliance is designed to create a variety of frozen beverages, including slushies, smoothies, milkshakes, and more, without the need for pre-chilled ice. Please read this manual thoroughly before operating the machine to ensure safe and efficient use. Keep this manual for future reference.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions carefully.

- **Electrical Safety:** Ensure the voltage rating on the appliance matches your local power supply. Do not immerse the appliance, cord, or plug in water or other liquids.
- **Supervision:** Close supervision is necessary when any appliance is used by or near children.
- **Moving Parts:** Avoid contact with moving parts. Keep hands and utensils out of the container while operating to prevent injury and damage to the machine.
- **Maintenance:** Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- **Damage:** Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Contact customer support for assistance.
- **Intended Use:** Use the appliance only for its intended household purpose. Do not use outdoors.
- **Placement:** Place the machine on a stable, flat, heat-resistant surface, away from edges and heat sources.

PRODUCT OVERVIEW

The RAPSUAR Slushie Maker Machine features an 88 oz capacity, a user-friendly control panel, and a robust cooling system for efficient frozen drink preparation.



Figure 1: Front view of the RAPSUAR 88 oz Slushie Maker Machine. This image displays the main unit with a clear liquid container, dispensing spout, and control panel on the front, alongside two glasses of prepared frozen drinks.

One-Touch Smoothie Maker

5 Preset: Slushie / Frappe/Spiked Slush
Milk Shake/Frozon Juice



Figure 2: Close-up of the control panel. The panel features a digital display and buttons for 5 smart presets: Slush, Spiked Slush, Frappe, Milkshake, and Frozen Juice, along with a Rinse function.

Key Components:

- **Liquid Container:** Transparent container for holding ingredients (88 oz capacity).
- **Control Panel:** Digital display and buttons for program selection and operation.
- **Dispensing Spout:** For serving prepared frozen drinks.
- **Lid:** Covers the liquid container.
- **Cooling System:** Internal mechanism that freezes the liquid without external ice.

SETUP AND FIRST USE

1. **Unpacking:** Carefully remove all packaging materials and ensure all components are present.
2. **Cleaning:** Before first use, clean the liquid container, lid, and dispensing spout with warm, soapy water. Rinse thoroughly and dry. The removable parts are dishwasher safe.

3. **Placement:** Place the machine on a clean, dry, and stable surface. Ensure there is adequate ventilation around the machine.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

OPERATING INSTRUCTIONS

The RAPSUAR Slushie Maker Machine simplifies the creation of frozen beverages with its 'no ice needed' technology and smart presets.



Figure 3: Visual guide for the three-step process to make a slushie. Step 1 shows pouring liquid into the machine. Step 2 shows selecting a program on the control panel. Step 3 shows dispensing the finished slushie.

Making a Frozen Drink:

1. **Prepare Ingredients:** Pour your desired liquid (juice, milk, coffee, cocktail, etc.) into the liquid container. Ensure the liquid level is between the MIN and MAX fill lines. No ice cubes are required.
2. **Select Program:** Close the lid securely. Turn on the machine. Use the control panel to select one of the 5 smart

preset programs:

- **SLUSH:** For classic slushies.
- **SPIKED SLUSH:** Optimized for alcoholic frozen drinks.
- **FRAPPE:** For coffee-based frozen drinks.
- **MILKSHAKE:** For creamy milkshakes.
- **FROZEN JUICE:** For fruit-based frozen beverages.

You can also use the '+' and '-' buttons to adjust the thickness across 10 custom levels, if available for the selected mode.

3. **Start Process:** The machine will begin the freezing process. This typically takes 15-30 minutes, depending on the selected program and initial liquid temperature. The innovative cooling technology rotates liquid 360° around a chilling cylinder to maintain ideal temperature and texture.



Rapidchill Technology

Liquid is rotated 360° around a chilling cylinder to maintain the ideal temperature and texture.

Figure 4: Illustration of the Rapidchill Technology. Liquid is shown being poured into the machine, which then circulates around an internal chilling cylinder to achieve the desired frozen consistency.

4. **Dispense:** Once the program is complete and the desired consistency is reached, place a glass under the dispensing spout and pull the handle to serve.

Recipe Inspiration:

The machine can transform various liquids into delicious frozen treats:

- **Watermelon Juice to Watermelon Smoothie:** Simply pour watermelon juice and select the appropriate program.
- **Iced Coffee to Coffee Frappé:** Use your favorite iced coffee blend.
- **Milk to Milkshake:** Add milk and desired flavorings for a creamy milkshake.
- **Cocktails to Frozen Mimosa/Margarita:** Prepare your cocktail mix and let the machine freeze it to perfection.
- **Red Wine to Wine Slushie:** A unique way to enjoy your favorite wine.

MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygiene of your slushie maker.

Self-Cleaning Mode:

The machine features a convenient self-cleaning mode.

1. **Empty Container:** Ensure the liquid container is empty after use.
2. **Add Water:** Fill the container with clean water up to the MIN line.
3. **Activate Rinse:** Select the 'RINSE' function on the control panel. The machine will run a cleaning cycle for approximately 5 minutes.
4. **Drain:** After the cycle, drain the water through the dispensing spout.

Self-Cleaning Mode Streamline Cleaning and Save Time



Figure 5: Depiction of the self-cleaning mode. Water is shown swirling inside the liquid container, indicating the automated cleaning process.

Manual Cleaning:

- **Unplug:** Always unplug the machine from the power outlet before cleaning.
- **Disassemble:** Carefully remove the liquid container, lid, and dispensing spout components.
- **Wash:** Wash these removable parts with warm, soapy water. A soft brush may be used for hard-to-reach areas. These parts are also dishwasher safe.
- **Wipe Base:** Wipe the main unit (base) with a damp cloth. Do not immerse the base in water.
- **Dry:** Ensure all parts are completely dry before reassembling and storing.

TROUBLESHOOTING

If you encounter issues with your RAPSUAR Slushie Maker Machine, refer to the following table for common problems

and solutions.

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; power outlet issue; machine fault.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. If the problem persists, contact customer support.
Liquid is not freezing.	Incorrect program selected; insufficient time; ambient temperature too high.	Ensure the correct program is selected for the desired consistency. Allow the full 15-30 minutes for freezing. Operate in a cool environment.
Dispensing spout is blocked.	Residue buildup; frozen solid ingredients.	Run the self-cleaning cycle. If still blocked, disassemble and manually clean the spout. Ensure ingredients are fully dissolved before adding.
Machine is noisy during operation.	Normal operation sound; unstable surface.	Some operational noise is normal. Ensure the machine is on a stable, flat surface. If noise is excessive or unusual, contact customer support.

If the issue is not resolved by the above steps, please contact RAPSUAR customer support for further assistance.

SPECIFICATIONS

Detailed technical specifications for the RAPSUAR 88 oz Slushie Maker Machine.

Modern Design & Compact Size



Capacity: 68 oz



Weight: 23.14 LBS



A Recipe Book



17.32"



Figure 6: Diagram showing the dimensions of the RAPSUAR Slushie Maker Machine. The height is approximately 17.32 inches, width 15.75 inches, and depth 7.87 inches.

Feature	Detail
Model Number	91580060
Capacity	88 oz (approximately 2.6 Liters)
Dimensions (L x W x H)	Approximately 15.75 x 7.87 x 17.32 inches
Weight	Approximately 50 Pounds
Power	330W stable compressor (as indicated in product images)
Presets	5 Smart Presets (Slush, Spiked Slush, Frappe, Milkshake, Frozen Juice)
Cleaning	Self-Cleaning Mode, Removable Dishwasher-Safe Parts

WARRANTY AND SUPPORT

RAPSUAR products are manufactured to high-quality standards. For warranty information, please refer to the warranty card included with your purchase or visit the official RAPSUAR website. If you have any questions, require technical assistance, or need to report a problem, please contact RAPSUAR customer support.

Customer Support Contact: Please refer to your product packaging or the RAPSUAR official website for the most current contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question