Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

COMHOMA CH511/CH510

COMHOMA Big and Tall Office Chair

Model: CH511/CH510

Introduction

This instruction manual provides detailed guidance for the assembly, operation, and maintenance of your COMHOMA Big and Tall Office Chair. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your chair. This chair is designed to provide ergonomic support and comfort for extended periods of use, featuring a robust construction suitable for users up to 400 lbs.

Safety Information

Maximum weight capacity: 400 lbs. Please ensure the chair is used within its weight limit for safety. Do not stand on the chair. Do not use the chair if any parts are damaged or missing. Keep children away from moving parts during assembly and operation. Always ensure all bolts and screws are securely tightened before use.

Package Contents

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Backrest Assembly
- Seat Cushion Assembly
- Armrests (Left and Right)
- Chair Base (5-star)
- Casters (5 pieces)
- Gas Lift Cylinder
- Gas Lift Cover
- Mechanism Plate
- Footrest Assembly
- Hardware Pack (screws, washers, Allen wrench)

Assembly Instructions

Follow these steps carefully for proper assembly. It is recommended to assemble the chair on a soft, clean surface to prevent scratches.

1. **Attach Casters to Base:** Insert the five casters into the holes at the end of each leg of the chair base. Push firmly until they click into place.




Image: Illustration showing the sturdy metal base and silent casters, highlighting their durability and quiet movement.

2. **Install Gas Lift:** Place the gas lift cylinder into the center hole of the chair base. Cover it with the gas lift cover.
3. **Attach Mechanism Plate to Seat:** Align the mechanism plate with the pre-drilled holes on the underside of the seat cushion. Ensure the front of the mechanism faces the front of the seat. Secure with the provided screws and Allen wrench.
4. **Attach Armrests to Seat:** Secure the armrests to the sides of the seat cushion using the designated screws. Do not fully tighten yet.
5. **Attach Backrest to Seat and Armrests:** Align the backrest with the mounting points on the seat cushion and armrests. Secure with screws. Once all screws are in place, tighten all armrest and backrest screws firmly.
6. **Attach Footrest:** Slide the footrest assembly into the designated slots under the seat. Ensure it can extend and retract smoothly.
7. **Connect Seat Assembly to Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring the center hole of the mechanism plate aligns with the top of the gas lift. Press down firmly to secure.
8. **Final Check:** Wiggle the chair to ensure all connections are secure and stable.

For a visual reference of the assembled product, please refer to the main product image:



Image: The fully assembled COMHOMA Big and Tall Office Chair in ebony black, showcasing its ergonomic design and integrated footrest.

Operating Instructions

Your COMHOMA office chair offers several adjustable features to customize your seating experience:

- **Height Adjustment:** Locate the lever on the right side, beneath the seat. Pull the lever upwards while seated to lower the chair, or pull the lever upwards while standing to raise the chair. Release the lever at your desired height.
- **Reclining Function (90°-150°):** The chair features a recline function from 90 degrees (upright) to 150 degrees (deep recline). Pull the recline lever (typically on the left side) to unlock the backrest, then lean back to your desired angle. Push the lever down to lock the backrest in place.

Image: A person demonstrating the chair's 90-150 degree adjustable reclining function, highlighting the armrest adjustment for elbow support.

- **Adjustable Armrests:** The armrests can be adjusted vertically by 3.15 inches. Locate the button or lever on the side of each armrest. Press it to unlock, adjust the armrest to your preferred height, and release to lock.

Image: A close-up of the adjustable armrests, showing the 3.15-inch height adjustment range for optimal elbow support.

- **Integrated Footrest:** To extend the footrest, pull it out from beneath the seat. To retract, push it back in until it is fully stored. The footrest provides additional comfort when reclining.
- **Pocket Spring Lumbar Support:** The chair features built-in pocket springs in the backrest for elastic lumbar support. This feature automatically conforms to your lower back, providing continuous support and relieving pressure during prolonged sitting.



Image: A cutaway view illustrating the pocket coils built into the backrest, designed to provide gentle touch and elastic support for the lower back.

The chair's design promotes a comfortable, sofa-like seating experience with its extra-wide seat and thick cushioning.



Image: A person sitting comfortably in the COMHOMA chair, demonstrating the spacious and supportive seating feel.



Image: Diagram highlighting the 21.26-inch extra-wide seat and thick cushions, designed for free leg placement and sustained comfort.

Maintenance

Regular maintenance helps preserve the appearance and functionality of your chair.

- **Cleaning:** For the PU leather, wipe with a soft, damp cloth. For tougher stains, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Fastener Check:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability and prevent squeaking.
- **Caster Care:** Clean casters regularly to remove dust, hair, and debris that can impede smooth movement.

Troubleshooting

If you encounter any issues with your chair, refer to the following common problems and solutions:

- **Chair Squeaks:**
  Solution: Check and tighten all assembly screws, especially those connecting the backrest, seat, and mechanism. A small amount of silicone lubricant can be applied to moving parts if the squeaking persists.
- **Chair Does Not Adjust Height:**
  Solution: Ensure the gas lift lever is fully engaged. If the issue persists, the gas lift cylinder may need replacement. Contact customer support.
- **Chair Feels Unstable/Wobbly:**
  Solution: Verify that all screws are securely tightened. Ensure the chair base is properly assembled and the gas lift is fully inserted.
- **Recline Function Not Working:**
  Solution: Check if the recline lock lever is fully disengaged. Ensure no obstructions are preventing the backrest from moving.
- **Casters Not Rolling Smoothly:**
  Solution: Remove any hair or debris wrapped around the caster wheels. Clean the wheels and axles.

Specifications

Detailed specifications for your COMHOMA Big and Tall Office Chair:

Feature	Detail
Brand	COMHOMA
Model Name	CH511/CH510
Color	02-ebony Black
Product Dimensions	19.68"D x 22"W x 45.1"H
Back Style	Wing Back
Special Features	Adjustable armrests, Big and Tall design
Maximum Weight Recommendation	400 Pounds
Reclining Position Count	3 (90°-150° adjustable)
Fill Material	Memory Foam, Foam
Seat Depth	19.68 inches
Item Weight	44 pounds
UPC	810170304750

For a visual representation of the chair's dimensions, refer to the diagram below:



Image: Detailed diagram showing the various dimensions of the COMHOMA Big and Tall Office Chair, including height, width, and depth.

Warranty and Support

COMHOMA is committed to providing excellent support for your product. Your COMHOMA Big and Tall Office Chair includes a one-year quality repair service.
If you have any questions, require assistance with assembly, or need to report a missing/damaged part, please do not hesitate to contact our dedicated customer support team. We are committed to ensuring your satisfaction.
Please refer to your purchase documentation for specific contact details or visit the official COMHOMA website for the most up-to-date support information.

© 2025 COMHOMA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DWFSZ7NR

More documents and user manuals: **https://manuals.plus/**