

[Manuals.plus](#) /

> [iRobot](#) /

> iRobot Roomba 105 Vac Robot Vacuum with AutoEmpty Dock - Self-Empties for 75 Days, Easy to use, Intense Power-Lifting Suction, LiDAR Navigation, Multi-Surface Cleaning, Cleans in Neat Rows

iRobot Q352020

iRobot Roomba 105 Vac Robot Vacuum with AutoEmpty Dock - User Manual

INTRODUCTION

The iRobot Roomba 105 Vac Robot Vacuum with AutoEmpty Dock is designed for efficient and hands-free dry floor cleaning. It features a self-emptying dock that can hold up to 75 days of debris, ensuring a clean home with minimal effort.

Key features include:

- **Up to 75 Days Hands-Free Cleaning:** The AutoEmpty dock securely stores debris, trapping 99% of allergens.
- **70X More Power-Lifting Suction:** A 3-Stage Cleaning system with a Multi-Surface brush and Edge-Sweeping brush ensures thorough cleaning.
- **Super-Smart Mapping and Navigation:** ClearView™ LiDAR maps your home for precise coverage and obstacle avoidance.
- **Fully Custom & Targeted Cleaning:** Schedule and target specific rooms, adjusting cleaning passes and suction power via the app.
- **Easy-to-Use Roomba Home App:** Control your robot, set schedules, and create keep-out zones from your smartphone.
- **3 Easy Ways to Control:** Operate your Roomba using voice commands (Alexa, Siri, Google Assistant), the mobile app, or the robot's physical buttons.



The iRobot Roomba 105 Vac Robot Vacuum with its AutoEmpty Dock.

SETUP

Follow these steps to set up your Roomba 105 Vac Robot Vacuum:

1. **Unboxing:** Carefully remove all components from the packaging, including the robot vacuum, AutoEmpty Dock, filter, and side brush.
2. **Dock Placement:** Place the AutoEmpty Dock in an open area with good Wi-Fi coverage, away from obstacles and stairs. Ensure it is plugged into a power outlet.
3. **Initial Charge:** Place the Roomba robot onto the charging contacts of the AutoEmpty Dock. Allow it to fully charge before its first use.
4. **App Download & Setup:** Download the 'Roomba Home' app from your device's app store. Follow the in-app

instructions to connect your Roomba to your home Wi-Fi network and create an account.

5. **Mapping Your Home:** Use the app to initiate a mapping run. The ClearView™ LiDAR system will quickly map your home's layout for efficient cleaning.

Devours dirt for hassle-free cleaning



VACUUMS WITH
INTENSE SUCTION



70X MORE
SUCTION POWER*

*AS COMPARED TO ROOMBA®
600 SERIES ROBOTS



FAST, SMART,
MAPPING



TARGETED
CLEANING



AUTO-EMPTYES
UP TO 75 DAYS



4 SUCTION
LEVELS

The Roomba Home app provides easy setup and control options.



Captures debris for up to 75 days.
WITHOUT RELEASING A CLOUD OF DUST



The AutoEmpty Dock's internal dust bag for hands-free disposal.

[Official Roomba 105 Vac + AutoEmpty Overview Video](#), demonstrating key features and setup.

OPERATING

Your Roomba 105 is designed for intelligent and efficient cleaning. It uses ClearView™ LiDAR for precise navigation, ensuring thorough coverage of your home.

- **LiDAR Navigation:** The robot uses advanced LiDAR technology to map your home, allowing it to clean in neat rows and avoid obstacles.
- **Cleaning Modes:** Select from various cleaning modes via the Roomba Home app, including scheduled cleaning, targeted room cleaning, and spot cleaning for concentrated messes.
- **App Control:** Use the intuitive Roomba Home app to start/stop cleaning, view cleaning history, set custom cleaning preferences, and define keep-out zones.

- **Voice Assistant Integration:** Connect your Roomba to Alexa, Siri, or Google Assistant-enabled devices for convenient voice control.

3
STAGES

Cleaning has
never been so simple




Edge-
Sweeping
Brush



Intense
Suction



Multi-Surface
Bristle Brush



ClearView™ LiDAR quickly maps your home for precise coverage.



Devours dirt with 70X more
power-lifting suction*




*AS COMPARED TO ROOMBA® 600 SERIES ROBOTS

The Edge-Sweeping brush ensures thorough cleaning along walls and in corners.



ClearView™ LiDAR

quickly maps your home
STEERS AROUND FURNITURE AND OBSTACLES



The robot automatically recharges and resumes cleaning when needed.



20% better edge
and corner cleaning*



*AS COMPARED TO ROOMBA® 600 SERIES ROBOTS

Schedule cleaning sessions and receive maintenance alerts through the app.



Recharges and returns to cleaning



Control your Roomba using voice commands, the app, or directly on the robot.

MAINTENANCE

Regular maintenance ensures optimal performance of your Roomba 105. The Roomba Home app will provide alerts when maintenance is due.

- **AutoEmpty Dock Bag:** The dock holds up to 75 days of debris. Replace the bag when full by lifting it out and disposing of it.
- **Dustbin & Filter:** The robot's internal dustbin is automatically emptied into the dock. Periodically check and clean the filter located within the robot's dustbin.
- **Brushes:** Regularly inspect and clean the Multi-Surface brush and Edge-Sweeping brush to remove tangled hair and debris.
- **Sensors:** Keep the robot's sensors clean to ensure proper navigation and obstacle avoidance.

NEW easy-to-use Roomba® Home app.
Designed for how you clean:

SCHEDULE CLEANING

SUNDAY

11:45

MONDAY

12:00

SET

TUESDAY

12:15



**MAINTENANCE
ALERTS**



**CLEAN
BY ROOM**



Underside view of the Roomba 105, showing the main brush and side brush.

3 WAYS

Control your way



VOICE
ASSISTANT



PRODUCT
BUTTONS



EASY-TO-USE
APP



The robot's dustbin with its removable filter for easy cleaning.

TROUBLESHOOTING

If your Roomba encounters an issue, the Roomba Home app will often provide specific alerts and troubleshooting steps. Common issues include:

- **Navigation Problems:** Ensure the LiDAR sensor is clean and free from obstructions. Clear any tangled cords or small objects from the cleaning path.
- **Charging Issues:** Verify that the robot is properly docked and the charging contacts on both the robot and the dock are clean.
- **Poor Cleaning Performance:** Check the dustbin and filter for fullness or clogs. Clean the main brushes and side brush to remove debris.
- **Error Messages:** Refer to the Roomba Home app for detailed explanations of error codes and recommended

solutions.

SPECIFICATIONS

Brand	iRobot
Model Name	Roomba 105 Vac + AE
Item Model Number	Q352020
Color	Black
Product Dimensions	13.2"L x 13.2"W x 4.1"H
Item Weight	6.24 pounds
Battery Life	200 minutes
Control Method	App, Push Button, Voice
Special Features	LiDAR Navigation, Dirt Detection Sensor, Edge Cleaning, Eco Mode, Anti-Fall

WARRANTY AND SUPPORT

iRobot is committed to providing reliable products and excellent customer service. Your privacy is a priority, and the company uses the highest standards of data encryption.

Please note that iRobot does not certify the quality or authenticity of products purchased from non-authorized resellers on Amazon. Warranty claims, service, or replacements will only be covered for products purchased from authorized resellers.

For support, please refer to the Roomba Home app or visit the official iRobot website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DWG1K24K>

More documents and user manuals: <https://manuals.plus/>