

Timex TW2Y29500VQ

Timex Men's Waterbury Classic 40mm Watch User Manual

Model: TW2Y29500VQ

1. PRODUCT OVERVIEW

The Timex Waterbury Classic 40mm Watch is a timepiece designed with attention to craftsmanship and detail, featuring a stainless-steel case and a natural leather strap. This model includes a clean white dial with Roman numerals, luminant hands for enhanced visibility, and a day and date window.

Key features include:

- **Stainless-steel Case:** Resistant to corrosion, rust, and daily wear.
- **Natural Leather Strap:** Crafted from supple leather, designed to soften with wear.
- **Day and Date Window:** Conveniently located beside the 3 o'clock marker for easy tracking.
- **Luminant Hands:** Ensures readability in low-light conditions.
- **Clean White Dial:** Features bold Roman numerals for clear time-telling.





Figure 1.1: Front view of the Timex Waterbury Classic 40mm Watch, showcasing the white dial, Roman numerals, and brown leather strap.

2. SETUP AND INITIAL USE

2.1 Setting the Time and Date

1. **Pull the Crown:** Gently pull the crown (the small knob on the side of the watch case) out to position 2 (first click) for date adjustment, or position 3 (second click) for time adjustment.
2. **Set the Date (Position 2):** Rotate the crown clockwise or counter-clockwise to adjust the day and date. If your watch has a day/date function, you may need to rotate it to set both. Avoid setting the date between 9 PM and 3 AM, as this is when the watch's internal mechanism is changing the date, and manual adjustment can cause damage.


3. **Set the Time (Position 3):** Rotate the crown to move the hour and minute hands. Rotate the hands past 12 o'clock to determine if it is AM or PM for correct date change.
4. **Push the Crown In:** Once the time and date are set, push the crown back into position 1 (normal operating position) to start the watch movement.



Figure 2.1: Side view of the watch, highlighting the crown used for setting time and date.

2.2 Adjusting the Strap

The natural leather strap is designed for comfort and durability. To adjust the fit, simply use the buckle to select the appropriate hole that provides a snug yet comfortable fit on your wrist. The leather will soften and conform to your wrist over time.





3. OPERATING THE WATCH

Your Timex Waterbury Classic watch is designed for reliable timekeeping. Once set, the watch will operate continuously. The luminant hands provide visibility in low-light conditions, allowing you to read the time without external illumination.

The day and date window will automatically advance at midnight. If the watch is not worn for an extended period, you may need to reset the time and date as described in Section 2.1.

4. MAINTENANCE AND CARE

4.1 Cleaning Your Watch

- **Case and Crystal:** Wipe the stainless-steel case and crystal (watch face) with a soft, lint-free cloth. For stubborn dirt, a slightly damp cloth can be used, but ensure no water enters the watch.
- **Leather Strap:** Avoid prolonged exposure to water, direct sunlight, and harsh chemicals, as these can damage the leather. Wipe the strap with a dry, soft cloth. For cleaning, use a specialized leather cleaner or a very mild soap solution applied sparingly with a damp cloth, then wipe dry immediately. Allow to air dry completely before wearing.

4.2 Water Resistance

This watch has a water resistance rating of 50 meters (5 ATM / 164 feet). This means it is suitable for short periods of recreational swimming, but not for diving or snorkeling. Do not operate the crown or pushers when the watch is wet or submerged.



Figure 4.1: Engravings on the watch back indicating water resistance (WR 50M) and material.

4.3 Battery Replacement

The watch is powered by a quartz movement and requires a battery. When the watch stops running, it indicates the battery needs replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

5. TROUBLESHOOTING

- Watch Not Running:

- Check if the crown is fully pushed in (position 1).
- The battery may need replacement. Refer to Section 4.3.

- **Incorrect Time/Date:**

- Reset the time and date as described in Section 2.1.
- Ensure the crown is fully pushed in after setting.

- **Condensation Under Crystal:**

- This may indicate a breach in the water resistance. Avoid further exposure to water and seek professional service immediately.

6. SPECIFICATIONS

Brand	Timex
Model Number	TW2Y29500VQ
Case Material	Stainless Steel
Strap Material	Natural Leather (Brown)
Dial Color	White
Case Diameter	40mm
Water Resistance	50 meters (5 ATM)
Movement Type	Quartz
Date First Available	February 7, 2025
Package Dimensions	4.06 x 4.02 x 3.11 inches; 7.41 ounces



Figure 6.1: Detailed view of the watch's back case and unbuckled strap.

7. WARRANTY AND SUPPORT

Timex watches are manufactured to high-quality standards. For specific warranty information, please refer to the warranty card included with your purchase or visit the official Timex website. The warranty typically covers manufacturing defects under normal use.

For customer support, service, or to inquire about repairs, please visit the official Timex website or contact





their customer service department directly. Ensure you have your model number (TW2Y29500VQ) and proof of purchase available when seeking support.

Note: No official product videos were provided in the available data for this manual.

© 2025 Timex. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Related Documents

	<p>Руководство по эксплуатации часов Timex</p> <p>Подробное руководство по эксплуатации часов Timex, охватывающее настройку времени, использование хронографа, водонепроницаемость, регулировку браслета и функции подсветки INDIGLO® для различных механизмов Timex.</p>
	<p>Timex Kids Digital Watch User Guide - Operation and Features</p> <p>Comprehensive user guide for the Timex Kids digital watch (model 791-095007). Covers features, basic operations, setting time and date, chronograph, alarm, timer, INDIGLO night light, water resistance, strap adjustments, battery information, and warranty details.</p>
	<p>Timex Watch User Manual and Warranty Information</p> <p>A comprehensive guide for Timex watches, covering setup, operation, features like INDIGLO night-light, bracelet adjustment, water and shock resistance, battery care, and international warranty details.</p>
	<p>Timex Model 262 Watch Movement Service Manual: Disassembly & Reassembly</p> <p>Comprehensive service manual for the Timex Model 262 electric watch movement, detailing disassembly, parts identification, and reassembly procedures. Includes diagrams and step-by-step instructions.</p>