## X-ALL XAMCleaner5xG

# X-ALL Multi-Purpose Cleaner Kit Instruction Manual

Model: XAMCleaner5xG

### Introduction

The X-ALL Multi-Purpose Cleaner Kit provides an effective and versatile cleaning solution for various surfaces in your home. This kit includes a durable, reusable spray bottle and five concentrated cleaning tablets, designed to simplify your cleaning routine while reducing plastic waste.

The powerful formula is designed to tackle grease, grime, and stubborn odors, leaving surfaces clean and fresh. It is suitable for use in kitchens, bathrooms, living areas, and even vehicles.

### Setup Instructions

1. **Prepare the Bottle:** Ensure the reusable spray bottle is clean and empty.
2. **Add Water:** Fill the spray bottle with warm water. Warm water helps the tablet dissolve more quickly.
3. **Insert Tablet:** Open one of the individually wrapped X-ALL Multi-Purpose Cleaning Tablets and drop it into the water-filled bottle.
4. **Dissolve:** Allow the tablet to fully dissolve. This may take a few minutes. The solution will turn blue as the tablet dissolves.
5. **Attach Sprayer:** Once the tablet is completely dissolved, securely attach the spray nozzle to the bottle.




Image: Components of the X-ALL Multi-Purpose Cleaner Kit, showing the reusable spray bottle and a packet of cleaning tablets.




Image: A cleaning tablet dissolving in water within the X-ALL spray bottle, illustrating the preparation process.

## Operating Instructions

The X-ALL Multi-Purpose Cleaner is designed for effortless and effective cleaning on a variety of hard surfaces. Follow these steps for optimal results:

1. **Spray:** Turn the nozzle to the "spray" position. Spray the cleaning solution directly onto the surface to be cleaned. For tough stains, allow the solution to sit for a few moments.
2. **Wipe:** Using a clean cloth or sponge, wipe the surface thoroughly. The streak-free, rinse-free formula means no additional rinsing is typically required.
3. **Repeat if Necessary:** For heavily soiled areas, repeat the spraying and wiping process.
4. **Storage:** After use, turn the spray nozzle to the "off" position to prevent accidental spraying and leakage.

## Recommended Surfaces:

- Countertops
- Tiles
- Glass (Note: Some users report streaking on mirrors; test in an inconspicuous area first.)
- Wood surfaces
- Ovens and stovetops
- Bathroom fixtures (effective on soap scum and hard water stains)





Image: A person spraying and wiping a kitchen stovetop with the X-ALL Multi-Purpose Cleaner, demonstrating its use on hard surfaces.




Image: Collage showing the X-ALL cleaner being used in a kitchen, bathroom, and other areas, highlighting its versatility.

## Maintenance

The X-ALL Multi-Purpose Cleaner Kit is designed for sustainability and ease of use. The spray bottle is reusable, reducing the need to purchase new plastic bottles with every refill.

- **Refilling:** When the cleaning solution runs out, simply follow the "Setup Instructions" to create a new batch using a fresh cleaning tablet and warm water.
- **Bottle Care:** Periodically rinse the reusable spray bottle with clean water to prevent residue buildup.
- **Sprayer Care:** If the sprayer becomes clogged, rinse the nozzle under warm water.




Image: A visual guide illustrating the four simple steps: Drop Tablet, Mix, Spray, Wipe, for using the X-ALL cleaner.

## Troubleshooting

| Issue | Possible Cause | Solution |
|---|---|---|
| Tablet not dissolving quickly | Water is too cold. | Use warm water for faster dissolution. Allow more time for the tablet to fully dissolve before use. |
| Streaks on mirrors/glass | Excess product or specific surface type. | Use a minimal amount of product and wipe with a clean, dry microfiber cloth. Test on an inconspicuous area first. |

| Issue | Possible Cause | Solution |
|---|---|---|
| Sprayer leaks | Nozzle not securely attached or manufacturing defect. | Ensure the spray nozzle is tightly screwed onto the bottle. If leakage persists, contact customer support. |
| Cleaner not effective on tough stains | Insufficient dwell time or extremely stubborn grime. | Allow the cleaner to sit on the stain for a longer period (5-10 minutes) before wiping. For baked-on spills, a non-scratch pad may be used gently. |

## Specifications

**Product Dimensions:** 2 x 2 x 2.7 inches

**Item Weight:** 6.35 ounces

**Model Number:** XAMCleaner5xG

**Manufacturer:** X-ALL

**Item Form:** Tablet

**Scent:** Fresh

**Specific Uses:** All-Purpose Cleaning

**Surface Recommendation:** Multi-surface (e.g., countertops, tile, glass, wood, ovens)

**Special Features:** Fume-Free, Cruelty-Free

**Contains Liquid Contents:** No (tablets only)

**Item Volume (when mixed):** 16 Fluid Ounces

**Unit Count:** 1.0 Count (referring to the kit)

**Number of Items:** 1 (kit includes bottle and 5 tablets)

**UPC:** 850064546279

## Safety Information

- **Non-Toxic Formula:** The X-ALL Multi-Purpose Cleaner tablets are formulated to be non-toxic and free from harsh components, making them suitable for homes with children and pets.
- **Ingredients:** Contains Citric Acid.
- **General Precautions:**
  - Keep out of reach of children and pets.
  - Avoid contact with eyes. In case of contact, rinse thoroughly with water.
  - Do not ingest. If swallowed, seek medical attention immediately.
  - While generally safe, it is recommended to wear gloves for prolonged use or if you have sensitive skin.
  - Store tablets in a cool, dry place away from direct sunlight and moisture.

© 2026 X-ALL. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question