

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [PlayStation](#) /

› [PlayStation 5 Console - ASTRO BOT Bundle \(Model CFI-2015A01X\) Instruction Manual](#)

PlayStation CFI-2015A01X

PlayStation®5 Console – ASTRO BOT Bundle

Model: CFI-2015A01X | Brand: PlayStation

INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your PlayStation®5 Console – ASTRO BOT Bundle. The PlayStation®5 console offers lightning-fast loading with an ultra-high speed SSD, deeper immersion with support for haptic feedback, adaptive triggers, and 3D Audio, and access to an all-new generation of incredible PlayStation games. This bundle includes the award-winning ASTRO BOT game, offering a supersized space adventure.

WHAT'S INCLUDED

Your PlayStation®5 Console – ASTRO BOT Bundle package contains the following items:

- PlayStation®5 Console (1TB SSD, Disc Drive)
- ASTRO BOT full game voucher* (Account for PlayStation Network and internet connection required to redeem voucher)
- Wireless Controller
- 2 Horizontal Stand Feet
- HDMI Cable
- AC Power Cord
- USB Cable
- Printed Materials (including this manual)
- ASTRO's PLAYROOM (Pre-installed game)

KEY FEATURES

- **Lightning Speed:** Harness the power of a custom CPU, GPU, and SSD with Integrated I/O that redefine console capabilities.
- **Stunning Games:** Marvel at incredible graphics and experience new PS5 features, including a back catalog of supported PS4 games.
- **Breathtaking Immersion:** Discover a deeper gaming experience with support for haptic feedback, adaptive triggers, and 3D Audio technology.

- **ASTRO BOT Adventure:** Embark on a galactic quest across 50+ planets, utilizing ASTRO's new power-ups for enhanced immersion.
- **PlayStation Camaraderie:** Reunite with over 150 iconic PlayStation heroes, celebrating 30 years of PlayStation history.

SETUP GUIDE

1. Unboxing and Initial Inspection

Carefully remove all components from the packaging. Ensure all items listed in the 'What's Included' section are present and undamaged. The console and accessories are designed for safe transport.



Front view of the PlayStation 5 Console and ASTRO BOT Bundle box, showing the console, controller, and game art.



Side view of the PlayStation 5 Console and ASTRO BOT Bundle box, highlighting the console's profile.

2. Attaching the Stand

The PS5 console can be placed in either a vertical or horizontal position using the included stand feet. Refer to the quick start guide for detailed instructions on attaching the stand for your preferred orientation. For the horizontal position, place the console with the rear side facing up, align the base with the marked area on the console, and press the base in firmly. For vertical position, you may need to remove a screw from the bottom of the console and attach the base with the screw.

3. Connecting Cables

Connect the HDMI cable from the PS5 console to your TV's HDMI input. Then, connect the AC power cord to the console and plug it into an electrical outlet. Ensure all connections are secure.

4. Installing the Disc Drive (if applicable)

If you have the Digital Edition and wish to add a disc drive, follow these steps. First, ensure the console is powered off and unplugged. Remove the console's cover plate. Align the disc drive clips with the two holes on the console and firmly push until you hear a click. Replace the cover plate and attach the larger feet for stability.

Video demonstrating how to install the disc drive on a PlayStation 5 console, converting a Digital Edition to a Disc Edition.

Video providing an overview of the PlayStation 5 console and its contents, including initial setup components.

OPERATING INSTRUCTIONS

1. Powering On/Off

Press the power button on the console or the PlayStation button on your DualSense wireless controller to power on the system. To power off, hold the PlayStation button on your controller to access the Control Center, then select the power icon and choose 'Turn Off PS5'.

2. Navigating the User Interface

The PS5 features a clean and modern user interface. Use the DualSense controller's directional buttons or analog sticks to navigate through the 'Games' and 'Media' tabs, access your game library, PlayStation Store, and various settings.

Video showcasing the PlayStation 5 console and its user interface, demonstrating navigation and game selection.

3. DualSense Wireless Controller

The DualSense controller provides immersive haptic feedback and adaptive triggers, enhancing gameplay. It is rechargeable via the included USB-C cable. The controller also features a built-in microphone for voice chat.




Image illustrating the DualSense wireless controller and its haptic feedback capabilities for enhanced immersion.

Video highlighting the top 10 features of the PlayStation 5, likely including controller functionalities and UI aspects.

MAINTENANCE

To ensure optimal performance and longevity of your PlayStation®5 console, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the console and controller with a soft, dry cloth to remove dust and fingerprints. Avoid using harsh chemicals or abrasive materials.
- **Ventilation:** Ensure the console is placed in a well-ventilated area, free from obstructions that could block airflow. Do not place it on carpet or in enclosed spaces.
- **Software Updates:** Keep your console's system software updated to the latest version for improved performance, features, and security.
- **Disc Care:** Handle game discs by the edges to avoid scratches. Store them in their cases when not in use.

TROUBLESHOOTING

If you encounter any issues with your PlayStation®5 console, try the following basic troubleshooting steps:

- **No Power:** Check all power cable connections. Ensure the power outlet is functional.
- **No Display:** Verify the HDMI cable is securely connected to both the console and the TV. Try a different HDMI port or cable.
- **Controller Not Responding:** Ensure the controller is charged. Try resetting the controller by pressing the small reset button on the back with a pin.
- **Game Freezing/Crashing:** Ensure the game and system software are updated. Try restarting the console.

- **Disc Drive Issues:** Ensure the disc is clean and inserted correctly.

For more detailed troubleshooting or persistent issues, please refer to the official PlayStation support website or contact customer service.

SPECIFICATIONS

Feature	Specification
ASIN	B0DWGLDS2V
Release Date	March 13, 2025
Product Dimensions	16.99 x 14.25 x 6.99 inches
Item Weight	10.65 Pounds
Item Model Number	CFI-2015A01X
Manufacturer	Sony Interactive Entertainment
Language	English
Rated	Teen
Batteries	1 Lithium Ion batteries required. (included)

WARRANTY & SUPPORT

Your PlayStation®5 Console – ASTRO BOT Bundle is covered by a limited manufacturer's warranty. Please refer to the printed materials included in your package for specific warranty terms and conditions.

For technical support, warranty claims, or additional assistance, please visit the official PlayStation support website or contact PlayStation customer service directly. Contact information can be found in your product documentation or on the PlayStation website.