

[Manuals.plus](#) /

› [Roku](#) /

› Roku Smart TV 2025 – 43-Inch Select Series, 4K HDR TV – RokuTV with Enhanced Voice Remote – Flat Screen LED Television with Wi-Fi for Streaming Live Local News, Sports, Family Entertainment 43" User Manual

Roku 43R4C5

Roku Smart TV 2025 – 43-Inch Select Series User Manual

Comprehensive guide for setting up, operating, and maintaining your Roku Smart TV 2025 (Model 43R4C5).

1. INTRODUCTION

Welcome to the world of simplified entertainment with your new Roku Smart TV 2025. This manual provides essential information to help you get the most out of your 43-inch Select Series 4K HDR TV, featuring the intuitive RokuTV platform and an enhanced voice remote. Designed for seamless streaming and a clear viewing experience, this TV integrates effortlessly into your home entertainment setup.

2. WHAT'S IN THE BOX

- Roku Select Series 43" 4K TV
- Stands and screws
- Roku Enhanced Voice Remote with batteries (2 AAA batteries included)
- Quick Start Guide

Enhanced voice remote



Lost remote
finder



Customizable
shortcuts



Live TV in
a click



Image: The Roku Smart TV 2025 packaging and its included components, such as the TV, remote, and stands.

3. SETUP GUIDE

3.1 Attaching the TV Stands

1. Carefully place the TV screen-down on a soft, clean surface to prevent scratches.
2. Identify the left and right stands. They are typically marked or shaped to fit specific slots on the TV's bottom edge.
3. Align each stand with the corresponding screw holes on the TV.
4. Secure each stand using the provided screws. Ensure they are tightened firmly but do not overtighten.

3.2 Connecting Peripherals

Your Roku Smart TV features multiple ports for connecting external devices. Refer to the image below for port locations.

- **HDMI Ports:** Connect gaming consoles, Blu-ray players, cable boxes, or other HDMI-enabled devices. This model includes 3 HDMI ports.
- **USB-C Port:** For connecting compatible USB-C devices.

- **Antenna/Cable Input:** Connect an antenna for over-the-air broadcasts or a cable connection.
- **Ethernet Port:** For a wired internet connection, though Wi-Fi is also available.




Image: Rear view of the Roku Smart TV showing the various input and output ports.

3.3 Initial Power-On and Network Setup

1. Plug the power cord into an electrical outlet.
2. The TV will power on automatically. Follow the on-screen instructions to select your language and connect to your Wi-Fi network.
3. You will be prompted to activate your Roku account or create a new one. This is essential for accessing streaming channels.
4. The TV will guide you through scanning for live TV channels if you connected an antenna or cable.



Image: The Roku Smart TV 2025 with its home screen interface, showing various streaming applications.

4. OPERATING YOUR ROKU SMART TV

4.1 Navigating the Roku Interface

The Roku interface is designed for simplicity. The home screen provides quick access to your installed apps, inputs, and various content categories.

- Use the directional pad on your remote to move between options.
- Press the **OK** button to select an item.
- The **Home** button returns you to the main screen.
- The **Back** button navigates to the previous screen.

A smart TV that makes sense

Powered by the delightfully simple Roku experience



Brilliant 4K picture



Bluetooth® Headphone Mode



Dolby Audio®

Image: The Roku TV interface with navigation options and content categories.

4.2 Enhanced Voice Remote

Your Roku TV comes with an enhanced voice remote for convenient control.

- Press and hold the **Voice button** to search for content, launch apps, or control playback using voice commands.
- Utilize the **Lost remote finder** feature via the Roku mobile app if your remote is misplaced.
- Set **personal shortcuts** for your favorite apps or functions using the customizable quick launch buttons.
- Access **Live TV** directly with a dedicated button.

Unbelievably free live TV

Enjoy 500+ channels with live news and weather, sports coverage, and more—totally free.



24/7 streaming channels

Image: Detailed view of the Roku Enhanced Voice Remote, highlighting its various buttons and functions.

4.3 Streaming Content

Access thousands of streaming channels and free content.

- **Apps:** Popular streaming apps like Netflix, Hulu, Disney+, and Prime Video are readily available. You can add more from the Streaming Store.
- **Free Live TV:** Roku offers over 500 free live TV channels, including news, sports, and entertainment.
- **Roku Smart Picture:** This feature automatically optimizes incoming TV signals and selects the best picture mode (movie, sports, vivid, or standard) for optimal viewing.
- **Bluetooth Headphone Mode:** Connect your wireless headphones via Bluetooth to listen to audio without disturbing others.
- **Dolby Audio:** Enjoy clear speech and louder sound with integrated Dolby Audio technology.

America's #1 TV streaming platform

Based on hours streamed—Hypothesis Group



Plus 1000s more

Image: The Roku TV home screen displaying a selection of popular streaming applications.

Easily discover new favorites

When you're out of old favorite movies and shows,
easily find new ones.



What to watch



Save List



Zones / Genres



Recommended




Image: An example of the free live TV channels available on Roku, featuring news and entertainment programs.

4.4 Smart Home Integration

Your Roku Smart TV is compatible with various smart home ecosystems.

- **Voice Assistants:** Enjoy easy voice control with Roku Voice, Siri, Alexa, or Google Assistant.
- **Apple AirPlay:** Effortlessly share videos, photos, music, and more from your Apple devices to your smart TV.

A perfect fit for any smart home

Sports

Search

Streaming Store

Settings

"Alexa, show me comedies on living room Roku."



Roku, the Roku logo, Roku Smart Home, and the Roku Smart Home logo are the trademarks or registered trademarks of Roku, Inc. Only supports English language. Apple, Apple Home, AirPlay, and Siri are trademarks of Apple Inc., registered in the U.S. and other countries and regions. The Works with Apple Home badge is a trademark of Apple Inc. Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates. Alexa enabled device is required to work with Alexa. Google and Google Home are trademarks of Google LLC. Third party features and services may be subject to change or removal without notice.

Image: The Roku Smart TV demonstrating its compatibility with various smart home platforms and voice assistants.

5. MAINTENANCE

5.1 Cleaning Your TV

- Always unplug the TV before cleaning.
- Use a soft, lint-free cloth to gently wipe the screen and frame. Do not use abrasive cleaners, waxes, or solvents.
- For stubborn marks, lightly dampen the cloth with water or a screen-cleaning solution specifically designed for electronics.

5.2 Software Updates

Your Roku Smart TV receives automatic software updates to ensure you have the newest apps, features, and performance improvements. Ensure your TV is connected to the internet for these updates to download and install.

6. TROUBLESHOOTING

If you encounter issues with your Roku Smart TV, try the following common troubleshooting steps:

Issue	Possible Solution
No Power / TV Not Turning On	Ensure the power cord is securely plugged into both the TV and a working electrical outlet. Try a different outlet.
No Picture / Black Screen	Check HDMI cable connections for external devices. Ensure the correct input source is selected. Try restarting the TV by unplugging it for 30 seconds and plugging it back in.
No Sound	Check the volume level on the TV and any connected audio devices. Ensure the TV is not muted. Verify audio settings in the TV menu.
Remote Not Responding	Replace the batteries in the remote. Ensure there are no obstructions between the remote and the TV. Repair the remote if necessary (refer to the Quick Start Guide). Use the Roku mobile app as an alternative remote.
Buffering / Poor Streaming Quality	Check your internet connection speed. Move the TV closer to your Wi-Fi router or use a wired Ethernet connection. Restart your router and modem.

7. SPECIFICATIONS

Feature	Detail
Brand	Roku
Model Number	43R4C5
Screen Size	43 Inches (110 cm diagonal)
Display Technology	4K UHD, LED
Resolution	4K
Refresh Rate	60 Hz
Product Dimensions (D x W x H)	9.2"D x 37.7"W x 24.5"H
Item Weight	14.4 Pounds
Connectivity Technology	Bluetooth, Ethernet, USB-C, Wi-Fi
Special Features	Bluetooth Headphone Mode, Game Mode, Art Mode, Voice Remote, Variable Refresh Rate (VRR), Flat Screen
Power Consumption	118 watts
Batteries Required	2 AAA batteries (included for remote)

8. WARRANTY AND SUPPORT

8.1 Product Warranty

Your Roku Smart TV is covered by a manufacturer's warranty. Please refer to the warranty card included with your product for specific terms, conditions, and duration. Keep your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please visit the official Roku support website or contact their customer service. You can often find detailed FAQs, video tutorials, and contact information on their support portal. For general inquiries related to your purchase, you may also refer to the customer support options provided by your retailer, such as [Amazon Customer Support](#).

© 2025 Roku. All rights reserved. Roku and the Roku logo are trademarks or registered trademarks of Roku, Inc.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question