

Roku 50R4C5

Roku Smart TV 2025 – 50-Inch Select Series User Manual

Model: 50R4C5

INTRODUCTION

Welcome to the user manual for your new Roku Smart TV 2025, 50-Inch Select Series. This guide provides essential information for setting up, operating, maintaining, and troubleshooting your television. The Roku Smart TV is designed to provide a seamless and intuitive entertainment experience with stunning 4K HDR picture quality and integrated streaming capabilities.

WHAT'S IN THE Box

Please ensure all components are present before proceeding with setup:

- Roku Select Series 50" 4K TV
- Stands and screws
- Roku Enhanced Voice Remote with batteries
- Quick Start Guide



Image: The Roku Smart TV 2025 50-Inch Select Series, shown with its retail packaging, highlighting its 4K HDR capabilities and sleek design.

SETUP

1. Physical Setup

Carefully remove the TV from its packaging. Attach the included stands to the bottom of the TV using the provided screws. Ensure the TV is placed on a stable, flat surface or securely mounted to a wall (wall mount sold separately).




Image: The Roku Smart TV 2025 50-Inch Select Series positioned on a media console, demonstrating a typical setup.

2. Connecting Peripherals

Connect your external devices (e.g., cable box, gaming console, soundbar) to the appropriate ports on the back of the TV. The TV features multiple HDMI inputs, a USB-C port, and an Ethernet port.



Image: A detailed view of the connectivity ports on the side of the Roku Smart TV, including USB-C, HDMI, and antenna inputs.

3. Initial Power On & Network Connection

Plug the power cord into an electrical outlet. The TV will power on and guide you through the initial setup process. Follow the on-screen instructions to connect to your Wi-Fi network or use an Ethernet cable for a wired connection.

4. Roku Account Setup

You will be prompted to create or link a Roku account. This is essential for accessing streaming channels, apps, and software updates. Follow the on-screen instructions to complete this step.

OPERATING YOUR ROKU SMART TV

1. Enhanced Voice Remote

Your Roku Smart TV comes with an Enhanced Voice Remote, offering convenient control and search capabilities.

- **Voice Control:** Press and hold the voice button to search for content, launch channels, or control playback using voice commands.
- **Lost Remote Finder:** Use the Roku mobile app to locate your misplaced remote.
- **Customizable Shortcuts:** Set personal shortcuts for your favorite apps or functions.

Unbelievably free live TV

Enjoy 500+ channels with live news and weather, sports coverage, and more—totally free.



ABC
NEWSLIVE



ROKU ORIGINAL
**THE GREAT
AMERICAN
BAKING SHOW**



**THE
RICH
EISEN
SHOW**

24/7 streaming channels

Image: The Roku Enhanced Voice Remote, showcasing its sleek design and dedicated voice button.

Easily discover new favorites

When you're out of old favorite movies and shows, easily find new ones.





Image: A detailed diagram illustrating the functions of each button on the Roku Enhanced Voice Remote, including TV power, volume, voice button, and app shortcuts.

2. Home Screen Navigation

The Roku Home Screen provides easy access to all your entertainment. Use the directional pad on your remote to navigate through channels, inputs, and settings.

- **Home**: Returns you to the main home screen.
- **What to Watch**: Discover trending movies and shows.
- **Featured Free**: Access free content available on Roku.
- **Live TV**: Browse and watch live television channels.
- **Streaming Store**: Download new apps and channels.

America's #1 TV streaming platform

Based on hours streamed—Hypothesis Group



Plus 1000s more

Image: The Roku Smart TV 2025 50-Inch Select Series displaying its intuitive home screen interface with various streaming app icons.

3. Streaming Content

Enjoy a vast library of entertainment with your Roku Smart TV.

- 4K HDR Picture:** Experience sharp detail and vivid colors with 4K resolution and HDR10 support. Roku Smart Picture optimizes incoming signals for the best viewing experience.
- Free Entertainment:** Access over 500 free TV channels, including live news, sports, and Roku Originals.
- App Ecosystem:** Dive into thousands of streaming apps like Netflix, Disney+, Prime Video, Hulu, and more.

Home sweet home screen

Jump right in with a home screen that easily gets you to what you want to watch fast.




Image: A collage of popular streaming service logos, including Netflix, Disney+, and Prime Video, illustrating the wide range of content available on Roku TV.

4. Picture and Sound Settings

Customize your viewing and listening experience:

- **Picture Mode:** Adjust settings like brightness, contrast, and color. Roku Smart Picture automatically selects the best mode (e.g., Movie, Sports, Vivid).
- **Bluetooth Headphone Mode:** Connect your wireless headphones via Bluetooth for private listening without disturbing others.
- **Dolby Audio:** Enjoy clear speech and enhanced sound quality from the TV's built-in speakers.

A perfect fit for any smart home


Sports

Search

Streaming Store

Settings

“Alexa, show me comedies on living room Roku.”



Roku, the Roku logo, Roku Smart Home, and the Roku Smart Home logo are the trademarks or registered trademarks of Roku, Inc. Only supports English language. Apple, Apple Home, AirPlay, and Siri are trademarks of Apple Inc., registered in the U.S. and other countries and regions. The Works with Apple Home badge is a trademark of Apple Inc. Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates. Alexa enabled device is required to work with Alexa. Google and Google Home are trademarks of Google LLC. Third party features and services may be subject to change or removal without notice.

Image: The on-screen picture settings menu of a Roku TV, showing options like Roku Smart Picture, Low Power, Standard, Vivid, Sports, and Movie modes.



What's in the box

- Roku Select Series 50" 4K TV
- Stands and screws
- Roku Enhanced Voice Remote with batteries
- Quick Start Guide

Image: A person wearing wireless headphones while watching the Roku TV, demonstrating the Bluetooth Headphone Mode feature.

5. Smart Home Integration

Your Roku Smart TV seamlessly integrates with popular smart home ecosystems:

- **Voice Assistants:** Control your TV using Roku Voice, Siri, Alexa, or Google Assistant.
- **Apple AirPlay:** Effortlessly share videos, photos, and music from your Apple devices to the TV.




Image: A Roku TV screen displaying a voice command, with logos indicating compatibility with Roku Smart Home, Apple Home, Apple AirPlay, Alexa, and Google Home.

MAINTENANCE

To ensure optimal performance and longevity of your Roku Smart TV:

- **Software Updates:** The TV receives automatic software updates to provide the newest apps, features, and performance improvements. Ensure your TV is connected to the internet for these updates.
- **Cleaning:** Gently wipe the screen with a soft, dry, lint-free cloth. For stubborn marks, use a screen cleaner specifically designed for electronics. Do not use abrasive cleaners or solvents. Clean the TV's exterior with a soft, damp cloth.

- **Ventilation:** Ensure proper ventilation around the TV. Do not block the ventilation openings.

TROUBLESHOOTING

If you encounter issues with your Roku Smart TV, refer to the following common solutions:

- **No Power:** Ensure the power cord is securely plugged into both the TV and a working electrical outlet. Try a different outlet.
- **No Picture/Sound:** Check all cable connections (HDMI, antenna). Ensure the correct input source is selected on the TV. Verify volume is not muted or too low.
- **Remote Not Responding:** Replace the batteries in the remote. Ensure there are no obstructions between the remote and the TV. For the Enhanced Voice Remote, use the lost remote finder feature via the Roku mobile app if applicable.
- **Wi-Fi Connectivity Issues:** Restart your Wi-Fi router. Go to *Settings > Network > Set up connection* on your TV to re-establish the network connection. Ensure your TV is within range of your Wi-Fi signal.
- **App Crashing/Freezing:** Try restarting the app. If the issue persists, restart the TV by unplugging it from the power outlet for 30 seconds and plugging it back in.
- **Poor Picture Quality:** Check your internet speed for streaming content. For external devices, ensure you are using high-quality HDMI cables. Adjust picture settings (*Settings > TV inputs > Picture settings*).

For more detailed troubleshooting, visit the official Roku support website or consult the Quick Start Guide.

SPECIFICATIONS

Feature	Detail
Brand	Roku
Model Number	50R4C5
Screen Size	50 Inches
Display Technology	4K UHD, LED
Resolution	4K
Refresh Rate	60 Hz
Aspect Ratio	16:9
Product Dimensions	10.6"D x 43.8"W x 27.8"H
Item Weight	18.4 Pounds
Connectivity Technology	Bluetooth, Ethernet, USB-C, Wi-Fi
Special Features	Bluetooth Headphone Mode, Game Mode, Art Mode, Voice Remote, Variable Refresh Rate (VRR), Flat
Batteries	2 AAA batteries required (included)
Voltage	120 Volts (AC)

Wattage	120 watts
Energy Consumption	146.0 Kilowatt Hours Per Year

WARRANTY & SUPPORT

Warranty Information

For specific warranty details, please refer to the documentation included with your product or visit the official Roku support website. Protection plans are available for extended coverage:

- 3-Year Protection Plan
- 4-Year Protection Plan
- Complete Protect (monthly plan)

Returns

This product is eligible for 30-day free returns, refund/replacement.

Customer Support

For further assistance, technical support, or to access additional resources, please visit the official Roku support website or contact their customer service. You can also visit the [Roku Store on Amazon](#) for more information.

© 2025 Roku. All rights reserved.