

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [KASUE](#) /

› [KASUE Portable Infrared Steam Sauna Box \(Model SNFF-a1\) Instruction Manual](#)

KASUE SNFF-a1

KASUE Portable Infrared Steam Sauna Box

Model: SNFF-a1 | Brand: KASUE

INTRODUCTION

Thank you for choosing the KASUE Portable Infrared Steam Sauna Box. This manual provides essential information for the safe and effective assembly, operation, and maintenance of your new sauna. Please read all instructions carefully before use and retain this manual for future reference.

Safety Warnings

- Always use distilled water in the steamer to prevent mineral buildup and ensure longevity.
- Ensure the sauna is placed on a flat, stable, and dry surface.
- Do not operate the sauna if any components are damaged.
- Keep children and pets away from the sauna during operation.
- Consult a physician before use if you have any medical conditions, are pregnant, or are taking medication.
- Avoid prolonged exposure to high temperatures. Limit sessions to recommended durations.
- Unplug the steamer and red light unit when not in use and before cleaning.

PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- Sauna Cloth Cover
- Folding Chair
- Fumigation Machine (Steamer)
- Red Light Strip
- Clear Hose x 2
- Remote Control
- Corner Connector x 4
- Three-way Interface x 8
- Components 32.3in x 8 (Short Pipes)
- Components 33.9in x 8 (Long Pipes)

Portable Sauna



Figure 1: All components included in the KASUE Portable Infrared Steam Sauna Box package.

SETUP INSTRUCTIONS

Frame Assembly

1. Connect the short pipes (32.3in) to the corner connectors and three-way interfaces to form the base frame. Ensure all connections are secure.
2. Insert the long pipes (33.9in) into the vertical openings of the base frame's corner connectors and three-way interfaces.
3. Assemble the top frame using the remaining short pipes, corner connectors, and three-way interfaces.

Carefully place and secure the top frame onto the vertical long pipes.

4. Drape the sauna cloth cover over the assembled frame, ensuring it fits snugly and the zippers align with the openings.
5. Place the folding chair inside the sauna box.
6. Position the red light strip inside the sauna, attaching it to the designated hooks or bars at the top.



Figure 2: Front view of the assembled sauna box.

Benefits of sauna



Skin Purification



Better Sleep



Less Muscular Pain



Improved Circulation



Reduce Inflammation



Immune System Support



Reduce stress & Fatigue



Figure 3: Side view illustrating the frame structure.

Portable Red Light Sauna

PRODUCTS			
SIZE	⌚ 71*35.4*35.4	71*32*32	67*31*31
RED LIGHT THERAPY	⌚ YES (REMOVABLE)	NO	NO
RAPID HEATING	⌚ 5-10MINS	10-20MINS	10-20MINS
STABILITY	⌚ UPGRADE	ORDINARY	ORDINARY
MATERIAL	⌚ 304 STAINLESS STEEL + DETACHABLE RED LIGHT BAR	PE POLES	PE POLES

Figure 4: Interior view of the sauna box before use.

Multifunctional Steam Engine

Upgraded Steam Engine

Thickened and lengthened mist outlet pipe

9 Levels of Temperature

Adjustment Faster heating

Higher temperature

Power: **1400W**

Capacity: **3L**



Note:

Requires 120V voltage to achieve 1400W power output.



Remote control settings



Steam box



Stainless steel steamer

Figure 5: Sauna interior with the folding chair in place.

Steamer Connection

1. Place the fumigation machine (steamer) outside the sauna box on a stable surface.
2. Connect one end of the clear hose to the steam outlet on the fumigation machine.
3. Feed the other end of the clear hose through the designated opening at the bottom of the sauna box and connect it to the steam box inside.
4. Fill the fumigation machine with distilled water up to the maximum fill line. Do not overfill.
5. Securely close the lid of the fumigation machine.
6. Plug the fumigation machine and the red light unit into a standard electrical outlet.

16 stainless steel pipes

The structure is more stable



Figure 6: Proper setup of the steamer unit and hose connection.

Setup Videos

Your browser does not support the video tag.

Video 1: "How to Install the Portable Sauna for Home" - A step-by-step guide on assembling the sauna box and connecting the steamer.

Your browser does not support the video tag.

Video 2: "Installation steps for our sauna box" - Visual instructions for the assembly process.

OPERATING INSTRUCTIONS

Steamer Operation

1. Ensure the steamer is filled with distilled water and properly connected to the sauna box.
2. Press the power button on the steamer unit or the remote control to turn it on.
3. Use the 'Timer' buttons on the unit or remote to set the desired session duration (up to 99 minutes).
4. Use the 'Heating' buttons to adjust the steam temperature (9 adjustable settings).
5. Allow a few minutes for the water to heat up and steam to begin filling the sauna.
6. Enter the sauna, close the zippers, and enjoy your session.

Red Light Therapy

The integrated red light strip provides red light therapy (660nm + 850nm). This feature can be turned on independently or in conjunction with the steam function. Use the dedicated controls for the red light unit to activate it.

Remote Control

The included remote control allows you to conveniently adjust the timer and heating settings of the steamer without needing to exit the sauna. Familiarize yourself with the remote's buttons for power, timer adjustment, and heating level control.



Figure 7: User enjoying the sauna experience.

Your browser does not support the video tag.

Video 3: "Portable Sauna Box for Home" - Demonstrates the sauna in use, highlighting its features and ease of operation.

Your browser does not support the video tag.

Video 4: "Steam Sauna Box" - Shows the steam generation and overall functionality of the sauna box.

MAINTENANCE

Cleaning

- After each use, unplug the steamer and red light unit.
- Allow the sauna to cool down completely.
- Wipe down the interior of the sauna cover with a damp cloth. For stubborn stains, use a mild, non-abrasive cleaner.
- Empty any remaining water from the steamer and wipe its interior dry.
- Regularly descale the steamer using a citric acid solution to prevent mineral buildup (refer to steamer manual for specific instructions).

Storage

- Ensure all components are completely dry before disassembling.
- Disassemble the frame by reversing the setup steps.
- Fold the sauna cover and store all components in their original packaging or a dry, cool place away from direct sunlight.

TROUBLESHOOTING

Issue	Possible Cause	Solution
No steam production	Steamer not powered on; insufficient water; hose kinked or disconnected.	Ensure power is on; fill water to appropriate level; check hose connections.
Sauna not heating sufficiently	Low temperature setting; zippers not fully closed; sauna cover not properly installed.	Increase temperature setting; ensure all zippers are closed; check cover installation.
Red light not working	Red light unit not powered on; loose connection.	Ensure red light unit is plugged in and powered on; check connections.
Water leakage	Hose not securely connected; steamer lid not properly sealed.	Verify all hose connections are tight; ensure steamer lid is securely closed.

SPECIFICATIONS

- **Model:** SNFF-a1
- **Product Dimensions:** 35.4 x 35.4 x 71 inches
- **Item Weight:** 19.16 pounds
- **Steamer Capacity:** 3 Liters
- **Steamer Power:** 1400W (requires 120V voltage)
- **Temperature Settings:** 9 levels
- **Maximum Timer:** 99 minutes
- **Material:** 5-Layer Waterproof & Heat-Insulating Fabric, Stainless Steel Frame
- **Red Light Therapy:** 660nm + 850nm

WARRANTY & SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the KASUE official website. Please have your model number (SNFF-a1) and purchase date available when contacting support.